

REFERENCE

NBS PUBLICATIONS

NBS TECHNICAL NOTE 1092

U.S. DEPARTMENT OF COMMERCE / National Bureau of Standards

Design, Evaluation, and Use of a Reverberation Chamber for Performing Electromagnetic Susceptibility/Vulnerability Measurements

> M. L. Crawford G. H. Koepke

QC 100 •U5753 No•1092

1986

he National Bureau of Standards¹ was established by an act of Congress on March 3, 1901. The Bureau's overall goal is to strengthen and advance the nation's science and technology and facilitate their effective application for public benefit. To this end, the Bureau conducts research and provides: (1) a basis for the nation's physical measurement system, (2) scientific and technological services for industry and government, (3) a technical basis for equity in trade, and (4) technical services to promote public safety. The Bureau's technical work is performed by the National Measurement Laboratory, the National Engineering Laboratory, the Institute for Computer Sciences and Technology, and the Institute for Materials Science and Engineering.

The National Measurement Laboratory

Provides the national system of physical and chemical measurement; coordinates the system with measurement systems of other nations and furnishes essential services leading to accurate and uniform physical and chemical measurement throughout the Nation's scientific community, industry, and commerce; provides advisory and research services to other Government agencies; conducts physical and chemical research; develops, produces, and distributes Standard Reference Materials; and provides calibration services. The Laboratory consists of the following centers:

- Basic Standards²
- Radiation Research
- Chemical Physics
- Analytical Chemistry

The National Engineering Laboratory

Provides technology and technical services to the public and private sectors to address national needs and to solve national problems; conducts research in engineering and applied science in support of these efforts; builds and maintains competence in the necessary disciplines required to carry out this research and technical service; develops engineering data and measurement capabilities; provides engineering measurement traceability services; develops test methods and proposes engineering standards and code changes; develops and proposes new engineering practices; and develops and improves mechanisms to transfer results of its research to the ultimate user. The Laboratory consists of the following centers:

- Applied Mathematics
- Electronics and Electrical Engineering²
- Manufacturing Engineering
- Building Technology
- Fire Research
- Chemical Engineering²

The Institute for Computer Sciences and Technology

Conducts research and provides scientific and technical services to aid Federal agencies in the selection, acquisition, application, and use of computer technology to improve effectiveness and economy in Government operations in accordance with Public Law 89-306 (40 U.S.C. 759), relevant Executive Orders, and other directives; carries out this mission by managing the Federal Information Processing Standards Program, developing Federal ADP standards guidelines, and managing Federal participation in ADP voluntary standardization activities; provides scientific and technological advisory services and assistance to Federal agencies; and provides the technical foundation for computer-related policies of the Federal Government. The Institute consists of the following centers:

- Programming Science and Technology
- Computer Systems Engineering

The Institute for Materials Science and Engineering

Conducts research and provides measurements, data, standards, reference materials, quantitative understanding and other technical information fundamental to the processing, structure, properties and performance of materials; addresses the scientific basis for new advanced materials technologies; plans research around cross-country scientific themes such as nondestructive evaluation and phase diagram development; oversees Bureau-wide technical programs in nuclear reactor radiation research and nondestructive evaluation; and broadly disseminates generic technical information resulting from its programs. The Institute consists of the following Divisions:

- Inorganic Materials
- Fracture and Deformation⁵
- Polymers
- Metallurgy
- Reactor Radiation

¹Headquarters and Laboratories at Gaithersburg, MD, unless otherwise noted; mailing address Gaithersburg, MD 20899.

²Some divisions within the center are located at Boulder, CO 80303.

Located at Boulder, CO, with some elements at Gaithersburg, MD.

NBS technical note

Design, Evaluation, and Use of a Reverberation Chamber for Performing Electromagnetic Susceptibility/Vulnerability Measurements

RESEARCH INFORMATION CENTER
NBSR
QUIDO
.US753

M. L. Crawford G. H. Koepke

Electromagnetic Fields Division Center for Electronics and Electrical Engineering National Bureau of Standards Boulder, Colorado 80303

Supported in part by
Naval Surface Weapons Centers (NSWC)
Dalgren, Virginia
and
Rome Air Development Center (RADC)
Griffiss Air Force Base
Rome, New York



U.S. DEPARTMENT OF COMMERCE, Malcolm Baldrige, Secretary

NATIONAL BUREAU OF STANDARDS, Ernest Ambler, Director

National Bureau of Standards Technical Note 1092 Natl. Bur. Stand. (U.S.), Tech Note 1092, 146 pages (Apr. 1986) CODEN:NBTNAE

U.S. GOVERNMENT PRINTING OFFICE WASHINGTON: 1986

FOREWORD

The research described in this report represents the culmination of over 3 years of work at the National Bureau of Standards (NBS), Electromagnetic Fields Division, Boulder, Colorado, to carefully evaluate, develop (when necessary), describe, and document the methodology for performing radiated susceptibility/vulnerability (EMS/V) measurements using a reverberation chamber. This effort was jointly funded by the Naval Surface Weapons Center (NSWC), Dahlgren, Virginia; Rome Air Development Center (RADC), Griffiss Air Force Base, Rome, New York; and the NBS. Three major tasks were outlined. These were to:

- 1. Determine how well a shielded enclosure could be made to operate as a reverberation chamber to establish time averaged (statistically determined), randomly polarized, uniform EM fields as a function of spatial position, frequency and chamber quality factor (Q);
- 2. Evaluate interaction effects between the chamber and equipment under test (EUT) placed inside the chamber to determine:
 - a. The range of applications of the measurement techniques (i.e., where the technique could or should not be used),
 - b. Whether measurement results obtained using the reverberation chamber could be correlated with results obtained using anechoic chambers or open field sites, and
 - c. To identify pertinent chamber calibration parameters;
- 3. Develop a technique applications and use manual.

These tasks were addressed sequentially in three major phases. The first phase was to design, construct, assemble and evaluate an empty (without the presence of an EUT inside) reverberation chamber with associated instrumentation and software to evaluate its electrical performance characteristics. This phase of the work began in January 1982 and was completed by the end of 1983. Results of this effort are contained in Section 2 of this report. Section 2 discusses the modification of a $2.74~\mathrm{m}$ x $3.05~\mathrm{m}$ x $4.57~\mathrm{m}$ welded steel shielded enclosure located at NBS into a reverberation chamber. Information given includes theoretical concepts, physical design and construction details, and the evaluation of the empty chamber's electrical parameters. These parameters are excitation and reference receiving antennas voltage standing wave ratio (VSWR), loss, Q factor, wave impedance, spatial E-field distribution versus frequency, and determination of the test field level.

The second phase of the work was to evaluate the interaction effects between the chamber and the EUT placed in the chamber. This effort occupied the latter part of 1983 through 1984. The results are contained in Section 3 of this report. The third phase was to develop methodology and evaluate the use of the reverberation chamber for susceptibility measurements and compare the results to other more conventional measurements techniques such as anechoic chambers and to other reverberation chambers. This study included the selection and susceptibility evaluation of four samples of EUTs: a one centimeter dipole probe, a ridged horn antenna, a series of rectangular TEM transmission cells with apertures and a modified 7.0 cm (2.75") diameter folded fin aircraft rocket (FFAR). The first three "reference standard" EUT's were selected because they could be characterized theoretically. The fourth EUT (FFAR) was more typical of an operational EUT which is more indicative of the actual type of equipment routinely tested for EM susceptibility. Results were obtained for this phase of the effort during 1984 and 1985. Details of how the measurements were performed, including setups, approaches, and instrumentation and software requirements are contained in Section 4. The final task was to document these results, presented in Section 5, and to produce a reverberation measurement technique applications and use manual. This, of course, is one of the purposes of this report. Section 6 gives a brief summary and conclusions drawn from this study. Some of the more significant are: 1) the NBS chamber lower useful frequency limit is 200 MHz; 2) the spatial variation in the statistically determined E-field established in the chamber is approximately \pm 8 dB at 200 MHz and decreases to \pm 2 dB at 2 GHz; 3) the preferred measurement approaches are mode tuned (explained in section 4.3.2) at frequencies below 2 GHz and mode stirred (also explained in section 4.3.2) at frequencies above 2 GHz; 4) the loading effect, of lowering the chamber's Q by inserting the EUT, should be limited to an increase in chamber loss ≤ 6 dB or a minimum tuner effectiveness ≥ 20 dB; 5) the average wave impedance in the chamber is approximately 120π ; 6) the maximum E-field is approximately 7-8 dB greater than the average E-field established in the chamber; 7) scattering from EUT does not significantly influence the E-field statistical, spatial distribution; 8) the directional characteristics of antenna or EUT placed inside the chamber are effectively lost; 9) the response of EUT measured inside a reverberation chamber is less than when measured inside an anechoic chamber (open space) in proportion to the EUT open space gain; 10) the response of EUT to an interference

field after it has penetrated the EUT's shield appears to be equivalent in both reverberation and anechoic chambers; and 11) the experimental error analysis suggests that Root Square Sum (RSS) errors in establishing the test field inside a reverberation chamber range from approximately \pm 10 dB at 200 MHz to \pm 4 dB at 18 GHz.

Section 7 provides suggestions for future research and Section 8 acknowledges the significant contribution of others to this project. References cited are given in Section 9.

CONTENTS

	ra	ġ
Abst	ract	1
1.	Background and Introduction	1
2.	Development of an Operational Reverberation Chamber 2.1 Theoretical Concepts. 2.2 Physical Design Considerations. 2.2.1 Chamber Physical Shape and Volume. 2.2.2 Chamber Quality Factor (Q). 2.2.3 Chamber Auxiliary Needs. 2.2.4 Tuner Design. 2.2.5 Chamber Excitation and Field Monitoring. 2.3 Determination of Wave Impedance and E-Field Amplitude Distribution Inside Reverberation Chamber. 2.3.1 Determining the Test Field and Wave Impedance Amplitudes. 2.3.2 Maximum Versus Average Amplitude Responses. 2.4 Spatial E-Field Distribution. 1 2.5 Multiple Excitation of the Chamber. 1	2566667 8890
3.	Interaction Effects Between Chamber, Source and Reference Antennas, and EUT	1 1
4.	Performing Immunity Measurements	2444
5.	Experimental Test Results	9 9 0 0
6.	Summary and Conclusions	1 1 2 2 4
7.	Suggestions for Future Research Efforts2	5
8.	Acknowledgments20	5
9.	References	6
	List of Figures and Tables2	В
	Appendix89	5



Design, Evaluation, and Use of a Reverberation Chamber for Performing Electromagnetic Susceptibility/Vulnerability Measurements

M.L. Crawford and G.H. Koepke

Electromagnetic Fields Division National Bureau of Standards Boulder, Colorado 80303

This report presents the results of work at the National Bureau of Standards, Boulder, Colorado, to carefully evaluate, document, develop (when necessary), and describe the methodology for performing radiated susceptibility/vulnerability measurements using a reverberation chamber. The report describes the reverberation chamber theory of operation, construction, evaluation, functional operation, and use for performing immunity measurements. It includes an estimate of measurement uncertainties derived empirically from test results and from comparisons with anechoic chamber measurements. Finally, it discusses the limitations and advantages of the measurement technique to assist potential users in determining the applicability for this technique to their electromagnetic compatibility (EMC) measurement needs.

Key Words: electromagnetic susceptibility/vulnerability; estimated uncertainty; evaluation; measurement procedures; reverberation chamber

1. Background and Introduction

The use of mode tuned or stirred reverberation chambers for performing EMC measurements is a relatively new method which appears to have considerable potential for electromagnetic susceptibility/vulnerability testing [1-7]. The idea of reverberating a shielded enclosure as a way to improve the EMC measurement results obtained using the enclosure was first proposed in 1968 [1]. Since then measurement procedures have been developed for implementing the technique for both radiated susceptibility and emission testing, but with considerable skepticism and a general lack of acceptance on the part of many EMC engineers. Reasons given include: 1) a lack of information about interaction effects between the EUT, reverberation chamber, and sources used to excite the chamber, 2) significant unanswered questions concerning the interpretation and accuracy of the measurement results, and 3) the lack of clear correlation of test results with other more conventional measurement techniques. Emphases for performing the work described in this report result from numerous advantages suggested for use of a reverberation chamber. These include:

- 1. Electrical isolation from or to the external environment;
- Accessibility (indoor test facility);
- 3. The ability to generate high level fields efficiently over large test volumes;
- 4. Broad frequency coverage;
- Cost effectiveness;
- 6. Potential use for both radiated susceptibility and emission testing with minor instrumentation changes; and
- 7. No requirement of physical rotations of the equipment under test (EUT).

These advantages are somewhat offset by limitations which include loss of polarization and directivity information relative to the EMC/EMI profile of the EUT and reduced measurement accuracy. However, this technique does offers a time efficient, cost effective way to evaluate EMC performance of large equipment using existing shielded enclosures with only minor modifications. The concept utilizes the shielded, high-Q, multimoded environment to obtain uniform (time averaged) fields that may simulate "real world", near field environments.

This report describes efforts to answer some of the questions referred to above and outlines an approach using this technique for EMS/V testing. It also describes efforts to identify a "correlation factor" between reverberation chamber and anechoic chamber obtained results, and outlines a detailed, step by step procedure for performing EMS/V tests. An experimental error analysis is given to provide insight into the magnitude of the measurement uncertainties expected for tests performed using this method.

2. Development of an Operational Reverberation Chamber

2.1 Theoretical Concepts

A reverberation chamber is a large (in terms of wavelength) high quality (Q) cavity whose boundary conditions are continuously and randomly perturbed by means of a rotating conductive tuner or stirrer. The time averaged field inside such a cavity, when a sufficient number of modes are excited, is formed by uniformly distributed plane waves coming from all directions. This property causes the polarization of the field to vary randomly hence eliminating the need, or the utility of physical rotation of test objects in the field. This has its obvious advantages and disadvantages as is apparent from the results and conclusions given in this report.

Two analytical approaches can be used to provide basic knowledge for designing a reverberation chamber. One involves the direct solution of Maxwell's equations with time varying boundary conditions. A formal solution using this direct approach is rather difficult to obtain. In the second approach, suitable linear combinations of basic eigenmodes of the unperturbed cavity (without mode stirrer or tuner) with time-dependent expansion coefficients are taken to represent the field and to satisfy approximately the boundary condition on the surface of the rotating mode stirrer or tuner [8]. The main advantage of this latter approach is that the unperturbed eigenfrequencies and eigenmodes are much easier to calculate, and the problem can be reduced to a more familiar one under special conditions. A necessary condition for the validity of this method is, however, that the total number of eigenmodes which can exist inside a chamber be large for a specified frequency and chamber size. Thus, the measurement technique using reverberating chambers is good for high frequency application. Typical frequencies of operation are from a few hundred MHz to 18 GHz and above.

The frequencies at which particular modes can exist inside a shielded, rectangular enclosure of dimensions a, b, and d are given as [9]

$$f_{mnp} = 150 \sqrt{\left(\frac{m}{a}\right)^2 + \left(\frac{n}{b}\right)^2 + \left(\frac{p}{d}\right)^2}$$
 (MHz)

where m, n, and p are integers.

Figure 2.1 gives the distinct frequencies of resonances of the first few modes for the NBS reverberation chamber. There are 26 resonant modes at distinct frequencies below 150 MHz and 63 resonant modes at distinct frequencies below 200 MHz.

As expected, the total possible number of eigenmodes, N(f), inside an unperturbed, lossless, rectangular chamber increases in steps with frequency. A smooth approximation to N(f) has been given by [8,10,11]:

$$N_s(f) = \frac{8\pi}{3} \text{ abd } \left\{ \frac{f}{c} \right\}^3 - (a + b + d) \frac{f}{c} + \frac{1}{2},$$
 (2)

where abd in m^3 represents the chamber volume, f is the operating frequency in Hz, and c is the speed of wave propagation in the chamber medium (usually air) in m/s. Note that the first term in (2) is identical to the well-known Weyl's formula derived originally for the same problem by a different approach, and is proportional to the chamber volume and the third power of frequency. The second term is the edge term, which is proportional to the sum of the linear dimensions of the chamber. This term may by used to modify Weyl's result, especially in the lower frequency range. Also, the inner surface area of the chamber, 2(ab + bd + da), is not involved in (2). An example is given in figure 2.2 showing N(f) as curve 1, $N_c(f)$ as curve 2, and Weyl's formula as curve 3 for the NBS chamber. Note that none of the dimensions of the NBS chamber (2.74 m x 3.05 m x 4.57 m) are equal. Equivalent examples for a squarebased chamber (2.17 m x 4.19 m x 4.19 m) and a cubic chamber (3.37 m) 3 , both of which have the same volume as that of the NBS chamber, are shown respectively in figures 2.3 and 2.4 for comparison purposes. Clearly, wider steps for curve 1 in figures 2.3 and 2.4 as compared with figure 2.2 are observed. This is true even though the smooth approximation $N_{s}(f)$ remains almost identical for all the three chambers. The main reason for this is due to the increased mode degeneracy for the last two chambers, under which the total number of distinct eigenmodes with respect to a given operating frequency and chamber size decreases.

While the total number of eigenmodes inside an unperturbed chamber is an important design criterion, another equally important factor to consider is the mode density function, dN/df, which represents the change in number of modes in a given frequency interval. Ideally, the chamber should be designed, if possible, so that the distribution of the modes is uniform. To determine the exact shape of dN/df involves using impulse functions since they are the derivatives of step functions. It is not difficult to see that within a given frequency interval, the average distance between the different impulses for the NBS chamber is shorter than that for the other two chambers having the same volume. An alternative quantity to examine for exhibiting this property is

$$\Delta N = \int_{\Delta F} \frac{dN}{df} df , \qquad (3)$$

which represents the increase or decrease in mode number within a frequency interval of Δf .

Results of ΔN when Δf = 1 MHz are presented respectively in figures 2.5 through 2.7 for the NBS chamber, the square-based chamber, and the cubic chamber. The uniformity of mode distribution in the frequency interval of 1 MHz is better for the NBS chamber (figure 2.7). This is the reason that the NBS chamber was designed with unequal dimensions. As a consequence, more uniformity for the electromagnetic field is expected within the NBS chamber than for chambers that have two equal sides or that are cubic, with the same volume and frequency of operation. Or, the NBS chamber should be capable of being operated with an extended lower frequency limit than other chambers of the same volume, in order to meet a given degree of uniformity for the final, expected field distribution. Thus, one of the general design criteria for a reverberating chamber is to make the volume as large as possible and the ratio of squares of linear dimensions as nonrational as possible.

A third design criterion, namely, the quality or Q factor, must also be considered in designing a reverberation chamber. Since there are so many eigenmodes which may exist in an unperturbed chamber with each mode carrying its own Q value [8,10,11], it is not always trivial to define a quality factor for the chamber as a whole. A composite quality factor for an unloaded chamber (without an EUT in it) within a specified frequency range can be obtained approximately from the equation [8],

$$\tilde{Q} = \frac{3}{2} S \delta_{s} \frac{V}{1 + \frac{3\lambda}{16} (\frac{1}{a} + \frac{1}{b} + \frac{1}{d})}$$
 (4)

where V is the chamber's volume in cubic meters, S is the internal surface area in square meters, and $\delta_S = \sqrt{\frac{2}{\omega\mu\sigma}}$ is the skin depth in meters, λ is the wavelength in meters, and a, b, and d, are the chamber's internal dimensions in meters.

The physical meaning of (4) may be interpreted by comparing it with the individual Q values of all the modes in the form of a cumulative distribution. Since V/(S $_{\rm S}$) is a common factor whether the composite quality factor defined above or the quality factor for individual modes is considered, it is more convenient to present the results in terms of 1/Q values normalized with respect to S $_{\rm S}/{\rm V}$. Thus, the variable used herein is

$$\alpha = \frac{1}{Q} (V/S \delta_S) . \tag{5}$$

Examples of the cumulative distribution of α for the NBS chamber are given respectively in figures 2.8 - 2.10 for three different frequency bands. For the frequency band of 180 to 200 MHz in figure 2.8, the total number of modes existing in this band of 20 MHz is 69, with each mode having its own Q-value. The probability of having a high upper-bound value of $\alpha \le 0.80$ (or a lower-bound for Q) is almost 100%, and that for a low value of $\alpha \le 0.48$ (or a high value for Q) is only about 10%. This implies that almost all of the 69 modes in this frequency band have $\alpha \le 0.80$. The arithmetic mean of 0.623 and the standard deviation of 0.090 are also indicated in the figure. The probability of having $\alpha \le 0.623$ (arithmetic mean) is 50%, meaning that at least one half of the 69 modes have $\alpha \le 0.623$.

For the case presented in figure 2.9, where the frequency band is from 330 to 350 MHz, also of a bandwidth of 20 MHz, there are 261 modes, an increase in number of modes relative to that in figure 2.8. This is because of higher frequency. A similar interpretation of the α values (or Q values) carried by these modes in terms of probability applies. There are now a small number of modes (low probability) carrying a value of α as low as 0.43 (high Q). The arithmetic mean and standard deviation are, respectively 0.630 (higher than the corresponding value in figure 2.8) and 0.085 (lower than the corresponding value of figure 2.8). A higher value of arithmetic mean implies that one half or more of the 261 modes carry a higher value of α (lower Q) compared to the frequency band considered in figure 2.8. A decrease in standard deviation reveals that a greater number of modes have α -values closer to the arithmetic mean.

If we consider a still higher frequency band 480 to 500 MHz such as that illustrated in figure 2.10, 534 possible modes will exist in the same bandwidth of 20 MHz. The arithmetic mean increases further to 0.646 while the standard deviation decreases further to 0.074, indicating that a greater number of modes will have still higher α values near the arithmetic mean. This tendency, increasing in arithmetic mean and decreasing in standard deviation with increased frequency, yields a limiting mean of $\alpha \le 0.667$ with a 50% probability, which also agrees precisely with the limiting value for composite α derived from (4) and (5).

Thus, even though there are a large number of possible modes existing in a specified operating frequency band for a reverberating chamber, with each mode carrying its own value of α or Q, the probability that $\alpha \leq 0.667$ (or Q ≤ 1.5 V/S $_{\rm S}$) is 50%. This implies that one half of the modes have $\alpha\text{-values}$ less than 0.667. Preliminary estimation of a quality factor to characterize the reverberating chamber as a whole, based on the simple expression of Q in (4), for the purpose of predicting the field strength level to be generated in the test zone is indeed very useful.

Finite Q values also imply that more than 1 mode can be excited at a single frequency. The extent to which modes not specifically resonant at a given frequency are excited is, of course, dependant upon the particular modes' Q, and how close the modes' resonant frequencies are to the given frequency.

The composite Q estimated from (4) is considered an upper-bound value because it does not take into account losses other than that due to wall conductivity. In reality, some loss will also occur due to leakage from the chamber, loss in antenna support structures, etc., and loss in the chamber's wall coatings. Hence an alternative means of determining chamber Q can be achieved from measuring the chamber's loss. Chamber loss is determined experimentally by measuring the difference between the net input power, $P_{\rm t}$, delivered to the chamber's transmitting antenna, and the power available, $P_{\rm r}$, at the reference antenna terminals. A photograph showing the interior of the NBS reverberation chamber is shown in figure 2.11. If the energy is uniformly distributed over the volume of the chamber, an empirical value (Q') can be obtained [6] using the equation,

$$Q' \approx 16 \pi^2 \frac{V}{\lambda^3} \frac{P_r}{P_t} , \qquad (6)$$

where V and λ are as previously defined.

Typical losses for the NBS chamber are shown in figure 2.12. The two curves show the average and minimum loss as a function of frequency. These results were determined statistically by rotating the chamber's tuner through 200 increments of 1.8 degrees and measuring the chamber's loss at each position for all test frequencies. The smooth curves are an estimated curve fit for the data.

Results obtained using (4) to calculate the composite Q and by using the data shown in figure 2.12 and (6) to calculate the experimental Q' are shown in figure 2.13. Figure 2.13a gives the curves for the calculated values of Q and Q' and figure 2.13b shows the ratio of Q to Q'. At frequencies above approximately 1 GHz the ratio approaches a constant value approximately equal to 3 or a loss equivalent of approximately 5 dB.

The Q factor of the chamber, of course, influences the rf input power requirements to generate the EM field levels inside the chamber for performing susceptibility tests. The average power received by the reference antenna, \bar{P}_r in watts, is related to the average power density, \bar{P}_d in watts per square meter, of the EM field inside the chamber by the equation,

$$P_{d} = \bar{P}_{r}/\bar{A}_{r} (W/m)^{2} , \qquad (7)$$

where A_{r} is the average effective aperture in square meters of the receiving antenna.

If the receiving antenna is subjected to EM energy coming from all aspect angles and random polarizations, the average gain of the antenna over 4 π solid angle is unity. (i.e., The field distribution at each point in the antenna aperture plane is assumed to be a composite of randomly polarized plane waves. This implies that the orientation of the receiving antenna will not influence the measured response and hence the effective gain of the antenna is unity.) The effective aperture of the antenna then is given as, $\bar{A}_r = \lambda^2/8\pi$ [12]. However, data obtained, as shown later in this report, indicates that these conditions are not achieved ideally (the field is not completely randomly polarized and incident at all aspect angles and the assumption that the average gain for the antenna is one is not exact). Hence, a more practical value to use for the effective aperture appears to be $\lambda^2/4\pi$. This value has been suggested previously for use in reverberation chambers for determining the "equivalent" average power density, \bar{P}_d [4]. Equation (7) then becomes,

Combining (6) and (8), we can obtain an expression for comparing the average, equivalent power density inside chambers of different size, assuming equal net input power, or

$$\frac{\bar{P}_{d_1}}{\bar{P}_{d_2}} = \frac{V_2}{V_1} \frac{Q_1^1}{Q_2^1} = \frac{S_2}{S_1} \frac{\delta_2}{\delta_1}, \qquad (9)$$

where the subscripts 1 and 2 refer to the two different enclosures, #1 and #2. For example, assume the #1 enclosure is the NBS enclosure with S_1 = 69.63 m² and the #2 enclosure is a larger chamber constructed of the same metal (δ_1 = δ_2) with dimensions, 3.51 m x 5.18 m x 10.82 m, or S_2 = 224.42 m²; this would give a ratio in average power densities (assuming the same net input power) of $\bar{P}_d^{\dagger}/\bar{P}_d^{\dagger}$ = 3.22 (i.e., the average power density inside the larger enclosure would be approximately 1/3.22 or 0.311 times as much as that in the NBS enclosure). Note that the validity of (9) is dependent upon a number of assumptions alluded to in its derivation.

2.2 Physical Design Considerations

A number of criteria should be considered in physically designing a reverberation chamber EM susceptibility/vulnerability measurement system. They can be addressed under the following categories:

- 1. Chamber physical shape and volume,
- 2. Chamber quality factor (Q),
- 3. Chamber auxiliary needs (venting, electrical power, EUT visual monitoring, EUT operational and functional monitoring requirements),
- 4. Tuner/stirrer(s) design, and
- 5. Chamber excitation and field monitoring.

2.2.1 Chamber Physical Shape and Volume

This criterion was addressed in Section 2.1. For optimum chamber performance (i.e., spatial field uniformity and accuracy in determining the test field level), especially at the low end of the frequency intended for use, the volume of the chamber should be as large as possible and the ratio of the squares of the chamber's linear dimensions should be as nonrational as possible. Choice of chamber size would be dictated by test volume size requirements, lowest test frequency, and budget considerations.

2.2.2 Chamber Quality Factor, (Q)

The second criterion, that of chamber Q, is established by carefully considering tradeoff options. If one has the option of designing and constructing a new shielded chamber, it is advantageous to use solid welded aluminum or copper construction since this will result in a higher Q than if sheet steel is used. Presumably one can always lower the Q of the chamber, if desired, by inserting material such as lossy wall coatings or a limited amount of rf anechoic material. The reason for lowering the chamber Q is to increase the bandwidth of the chamber's modes, thus improving mode overlap and smoothing the EM field uniformity vs. frequency response characteristics, especially at the lower test frequencies. Doing this, however, increases the rf input power needed to generate the required field strengths and reduces the effectiveness of the chamber's tuner to redistribute energy uniformly into modes in all three axes of the chamber. In addition, the time required for the chamber test field to arrive at its steady state condition, after the input power to the chamber is applied, is a function of chamber Q. The higher the Q the longer the settling or charging time. This could have significant implications if the reverberation chamber is to be used for pulsed rf susceptibility testing. Regardless of the metal used in the chamber's construction (aluminum, copper or steel) it should be standard practice to keep the chamber clear of lossy material such as wood or absorbing materials except for special purposes.

2.2.3 Chamber Auxiliary Needs

The third criterion, chamber auxiliary needs, must be established based upon the intended use and the upper test frequency for use. Venting panels should use screens with apertures significantly smaller than waveguide below cutoff at the maximum intended test frequency. Electrical power supplied to outlets inside the chamber, EUT visual monitoring, and EUT operational and functional monitoring requirements are similar to conventional shielded enclosure requirements. A bulkhead panel similar to that shown for the NBS reverberation chamber in figure 2.14 can be used to access the excitation and reference receiving antennas, and the EUT. Care must be taken to ensure that the shielding integrity of the enclosure is not compromised by access holes or cables, etc. This may require the use of high resistance (carbon impregnated) lines [13] or fiber optic links for monitoring the EUT. In addition, waveguides below cutoff access ports can be very useful.

2.2.4 Tuner Design

The fourth criterion is to design the tuner to ensure its effectiveness to redistribute the energy inside the enclosure and hence to tune the field. To achieve this, the tuner must be electrically large ($>\lambda/2$ at the lowest frequency of operation) and be shaped or oriented to distribute energy into all possible modes. Three such tuners are shown in figures 2.15a, 2.15b, and 2.15c. The first tuner (figure 2.15a) was developed by McDonnell Douglas Corp. [2,14,15] after extensive testing to optimize the design for use in their translational electromagnetic environment chamber (TEMEC) facility. The second tuner (figure 2.15b) is used by the Naval Surface Weapons Center in their reverberation chamber [16]. The third tuner (figure 2.15c) is used in the NBS reverberation chamber. The tuner is mounted as shown in figure 2.16, with the blades bent at an angle of approximately 45 degrees to the ceiling to improve its scattering of the field evenly in all directions. The tuner mounting includes a shielded housing with internal metal wipers to prevent rf leakage from the chamber via the tuner shaft to the stepping motor. Details of the housing and motor mounting arrangement are shown in figure 2.17. The tuner controller system which includes the stepping motor and a computer accessed controller, allows movement of the tuner in increments as small as 0.113 degrees (3200 steps per revolution) at rates from seconds up to hours per revolution. The motion was optimized for as smooth a motion of the tuner as possible.

A test to determine how effectively the tuner is functioning is to measure the ratio of the maximum to minimum received power of the receiving antenna as a function of tuner position. This is done while maintaining a constant net input power to the enclosure's

transmitting antenna. The results of such measurements made with the NBS tuner are shown in figures 2.18a and 2.18b. The magnitude of the ratio is dependent upon a number of factors including tuner shape, size, orientation, and the Q of the enclosure. The average value of the maximum to minimum ratio is higher in the empty chamber. (Data for figure 2.18b were obtained with 4 pieces of 66 cm x 61 cm x 61 cm rf absorber placed in the center of the chamber 0.5 meter above the floor). The purpose for inserting the absorber was to simulate a gross loading effect of an EUT placed in the enclosure. A lower loss (ratio) is indicative of a higher Q and more effective mode tuning. This influences the spatial uniformity of the test field (statistically) as is shown in section 2.3. A reasonable guideline for proper operation of the tuner is a minimum tuning ratio of 20 dB.

Multiple tuners have been used in some reverberation chambers [3,6]. Typically they are mounted on opposite walls to improve the stirring of the fields in the chamber. This is especially important if the tuners are flat, thus acting as scatterers in only one plane. The tuner controller system used in the NBS system allows for control of several tuners simultaneously. This may be particularly advantageous if the reverberation chamber is especially large or is compartmentalized (multiple sections). Examples of compartmentalized chambers are a large chamber divided into two sections by a separating wall or a small chamber placed inside a large chamber. Both arrangements have been proposed for using the reverberation chamber method for measuring shielding effectiveness of materials and enclosures [17].

2.2.5 Chamber Excitation and Field Monitoring

The fifth consideration in designing a reverberation chamber EMC measurement system is in the selection and mounting of appropriate antennas for exciting and monitoring the EM fields inside the chamber. The following parameters are used in selecting the antennas:

- a) frequency range of interest,
- b) input power rating (>200 watts),
- c) bandwidth (>10:1 if possible),
- d) minimum VSWR (low as possible),
- e) efficiency for exciting modes inside chamber,
- f) minimum size, and
- g) durability.

The typical frequency range of application is from 200 MHz to 18 GHz or higher. A number of candidate antennas could be used in this range. No single antenna has sufficient bandwidth to cover the full range with the possible exception of the long wire antenna. Based upon the above and, to a certain extent, the antennas available at the Electromagnetic Fields Division of NBS, the following were selected for evaluation.

- a) Long wire antenna (200 MHz 18 GHz),
- b) Log periodic antenna (200 MHz 2 GHz),
- c) Monopole antenna (200 MHz 1 GHz),
- d) Bow-tie antenna (200 MHz 1 GHz),
- e) Leaky 50 ohm coaxial cable (200 MHz 1 GHz),
- f) Ridged horn (1.0 GHz 12 GHz),
- g) Double ridged circular horn (2.0 GHz 18 GHz).

The efficiency with which energy can be injected into or coupled out of the chamber via transmitting or receiving antennas is determined by: 1) the voltage standing wave ratio (VSWR) of the antennas (i.e., the impedance match between the rf source and the transmitting antenna or between the receiving antenna and its output detector), and 2) the ability of the antennas to couple energy into or out of the particular modes that exist at the test frequencies of interest. Rotating the tuner changes the chamber's boundary conditions and hence, shifts the mode excitation frequencies. This, of course, changes the characteristics of the field inside the enclosure which in turn influences the effective VSWR of the antennas. The Q factor of the enclosure as a resonant cavity also has considerable effect upon the VSWR of the antenna. This is particularly true at frequencies below a few GHz.

The placement and orientation of the transmitting and receiving antennas can also influence the operation of the chamber [18]. Two positions or orientations are recommended:

1) position the transmitting and receiving antennas in different corners of the chamber, oriented toward the corners as shown in figure 2.19, or 2) position one of the antennas in a corner oriented toward the corner, for example the reference receiving antenna, with the other antenna (transmitting antenna) sufficiently far away and oriented toward the tuner. The first

arrangement was selected for use in the NBS chamber. The purpose for these configurations is to couple energy into and out of all chamber modes as efficiently and uniformly as possible without significantly favoring particular modes or favoring a direct path coupled signal between the transmitting and receiving antennas.

Installation of a long wire antenna inside the chamber is different from other antennas because it uses the chamber wall as its ground plane to obtain as close to a 50 ohm impedance as possible. Details for designing the taper transition region of the long wire antenna are shown in figure 2.20. A photograph of the long wire antenna installed inside the NBS chamber is shown in figure 2.21. The long wire extends around two surfaces of the chamber. This is done to achieve, however somewhat limited, the purpose of the locations and orientation configurations referred to above for other conventional antennas.

G Based upon the results of data obtained for various antenna pairs selected from the above list, the following four antennas were chosen for use in the NBS chamber in the following frequency ranges:

- 1) Long wire (200 MHz 1000 MHz), receiving mode,
- 2) Log Periodic (200 MHz 1000 MHz), transmitting mode,
- 3) Ridged horn (1.0 GHz 10 GHz), transmitting and receiving modes,
- 4) Double ridged circular horn (2.0 GHz 18 GHz), transmitting and receiving modes.

Within the recommended frequency bands of operation, the long wire and log periodic antennas can accommodate up to 1000 watts input power, and the ridged horns and double ridged circular horns can accommodate up to 200 watts input power.

A number of preliminary tests were performed to determine the operational parameters of the NBS reverberation chamber using these antennas and to evaluate the interactions between EUT, the chamber, and the rf sources used in performing these measurements. Some of these tests and their results were previously published [19]. The VSWRs and coupling efficiency of these four antennas placed inside the empty NBS chamber are given in figures 2.22 and 2.23. Figure 2.22 shows the maximum, average, and minimum VSWR obtained statistically by measuring return loss from the antennas, operating in the transmitting mode, as a function of tuner position at discrete frequencies from 200 MHz to 18 GHz. The tuner was stepped at 1.8 degree increments (200 steps) through a complete revolution. Figure 2.22a is for the long wire antenna operating over the complete frequency range. Figure 2.22b, is the composite VSWR of three antennas (#2, #3, and #4) used within the frequency bands shown in the figure's caption. In the past a long wire antenna has been used quite extensively as a reference receiving antenna across the full frequency range [4,14,17,]. Its input VSWR is not as low, especially at frequencies above 1 GHz, as for the composite of the three antennas. Also, at frequencies above approximately 2 GHz, rotation of the tuner appears to have a minor influence on the VSWR of the antennas. This feature can have considerable impact upon the decision as to what approach to use in performing susceptibility measurements as discussed in section 4.1 of this report. Figure 2.23 shows the coupling efficiency or loss between the long wire antenna transmitting (200 MHz - 18 GHz), and a composite of the three antennas receiving. This figure is provided for comparison with figure 2.12. The long wire antenna is not as efficient in coupling energy into the chamber and hence, the loss is greater, particularly above 1 GHz.

The quality factor of the chamber as a resonant cavity also has considerable effect upon the VSWR and coupling efficiency of the antenna placed inside, especially at frequencies below a few GHz. This is shown in figures 2.22c and 2.24. These data were obtained with four pieces of 66 cm x 61 cm x 61 cm rf absorber placed in the center of the chamber's test zone. Note the significant reduction in the VSWR variations of the transmitting antenna associated with the substantially lower Q in the enclosure and the significant increase in the chamber loss.

- 2.3 Determination of Wave Impedance and E-Field Amplitude Distribution Inside Reverberation Chamber
- 2.3.1 Determining the Test Field and Wave Impedance Amplitudes

The field strength in the chamber can be determined in two ways. The first is to measure the power received by the reference antennas, and then determine the equivalent power density in the enclosure from (8). The equivalent electric field, \bar{E}_a , is then found using the expression,

$$\bar{E}_{a} = \sqrt{\bar{n}' \bar{P}_{d}} \approx \frac{4\pi}{\lambda} \sqrt{30 \bar{P}'_{r}} (V/m), \qquad (10)$$

where n' is the statistically averaged wave impedance in the chamber. This averaged wave impedance is assumed to be approximately equal to 120π ohms. Obviously, the wave impedance inside the reverberation chamber will have large variations as a function of tuner orientation and chamber location. To test the validity of (10), independent measurements were made of the maximum, average, and minimum magnetic and electric fields in the chamber. These measurements were made using a one centimeter diameter loop probe and a one-centimeter long dipole probe. The probes were rotated through three orthogonal orientations aligned with the chamber axes and located at the center of the test zone. The magnitudes of the total magnetic and electric fields were then determined as the square root of the sum of the squared values of each of the three components respectively for both the magnetic and electric fields. The corresponding ratios of the electric-field and magnetic-field amplitudes for a data base of 200 positions of the tuner were then used to determine an "equivalent" wave impedance. The results are shown in figure 2.25. Four curves are given. Three curves show the maximum, average and minimum wave impedance determined as a function of frequency. The fourth curve shows the wave impedance calculated from the ratio of E to H when the electric-field was a maximum. Even though the wave impedance varies widely as expected with frequency, the average wave impedance at frequencies above 200 MHz (the lower frequency limit recommended for this chamber) is approximately 120π ohms. This then, provides evidence that (10) is valid, at least for determining the average E-field in the chamber. The fourth curve was included because, as will be discussed later in this report, the convenient parameter for comparing reverberation chamber with anechoic chamber obtained EUT susceptibility data is the EUT's peak response. This typically corresponds to a maximum electric field in the reverberation chamber. Note that the wave impedance corresponding with the maximum E-field typically is greater than 120π ohms and was found to be as large as 1600 ohms thus contributing to an error as large as 6 dB in determining the maximum E-field if (10) is used.

The second method used to determine the field strength in the reverberation chamber is to measure the electric field using an electrically small dipole probe that has been previously calibrated in a standard uniform field. This is the same dipole probe, referred to above, that was used to determine the chamber's wave impedance. The assumption made in using the probe is that since it is electrically small, the fields measured in the reverberation chamber over the aperture of the dipole will be uniform (i.e., "equivalent" to the standard uniform field used in the probe's calibration); and hence the probe's response will give an accurate measurement of the "equivalent" field strength in the chamber. Results of the measurements comparing the electric-field strength generated in the chamber based upon these two methods are shown in figure 2.26. The maximum and average E-field strength data were normalized to one watt net input power. The agreement shown is typical of the random variations in the data used to determine the field in a reverberation chamber. The systematic offset difference between the field determined using the reference antenna and that determined using the probe is, however, less than 3 dB. This result also strengthens the validity of (10).

2.3.2 Maximum Versus Average Amplitude Responses

Another important observation from figure 2.26 is the approximate 7-8 dB difference in signal amplitude between the maximum and average field strengths. This can be explained simply in terms of the structure of the cavity modes in the chamber [20]. For a cavity of dimensions, a, b, and d, modes in all three dimensions can be represented as

$$\phi_{mnp}$$
 (x,y,z) α $\sin \frac{m\pi x}{a} \sin \frac{n\pi y}{b} \sin \frac{p\pi z}{d}$, (11)

where x, y, and z correspond to the three orthogonal axes of the chamber and m, n, and p are the associated mode numbers.

An antenna typically responds to a specific field component, or in the reverberation chamber case, to the composite field impinging upon its aperture. However, measured power is related to ϕ_{mnp}^2 x,y,z). The maximum value of ϕ_{mnp}^2 (x,z,z) occurs when each component is a maximum or

$$\max (\phi_{mnp}^2(x,y,z)) \le 1.$$
 (12)

The average value of ϕ_{mnp}^2 (x,y,z) is given by

Ave
$$(\phi_{mnp}^2 (x,y,z)) = \frac{1}{abd} \int_V \phi_{mnp}^2 (x,y,z) dxdydz \approx \frac{1}{8}$$
. (13)

The ratio of Max $(\phi_{mnp}^2 \ (x,y,z))$ /Ave $(\phi_{mnp}^2 \ (x,y,z))$ in the limit then is 8 which corresponds to 9 dB (i.e., this is the theoretical maximum difference that can exist between the maximum and average responses of an antenna or EUT measured in a reverberation chamber). In practice, the mode mixing is not 100 percent efficient to achieve a perfect average nor does one obtain a perfect maximum in all three dimensions. Hence the average difference of 7 to 8 dB shown in figure 2.26 is expected.

In the past, a question regarding the validity of maximum or "peak" reverberation chamber results has been raised. However, this question seems to be resolved as apparent by examining the relationship between maximum and average measurements in the reverberation chamber exhibited in figure 2.26 and from the implications of (12) and (13). These results suggest one can extract one set of data (e.g., average) from the other (e.g., maximum) quite accurately (within \pm 2 dB), assuming of course, that the response of the EUT is linear.

2.4 Spatial E-Field Distribution

Tests were made to determine the uniformity of the maximum and average values of the Efield in the chamber as a function of spatial position and frequency. Seven NBS isotropic probes [21] designed to operate at frequencies up to 2 GHz were placed inside the enclosure as shown in figures 2.19 and 2.21. Each probe has three orthogonally oriented dipoles aligned with the enclosure axes. Measurements were made of the field strength of each orthogonal component at the seven locations for each tuner position (200 steps of 1.8 degree increments). The maximum and average values for each component and the corresponding amplitudes were then determined from the complete data set for a normalized net input power to the chamber of 1 watt. The results of these measurements are shown in figure 2.27. These measurements were made in 50 MHz increments from 100 MHz to 2.0 GHz. The spread of the data points show the spatial field variation inside the enclosure at the indicated frequencies. Note at 200-300 MHz the spread and potential errors in determining E-field amplitude is as great as ±8 dB, decreasing to approximately ±2 dB at 2.0 GHz. Note also the large difference in the three orthogonal components at frequencies below 150 MHz. This is especially apparent from inspecting figure 2.28 which shows the average values of the seven statistically determined average and maximum E-fields for each component and their composite total determined from figure 2.27. Strong mode structure is indicated in the chamber at frequencies below 150 MHz (i.e., the presence of a dominant mode with its associated directional properties). Hence, there are insufficient modes for proper operation at these frequencies. At frequencies above 150 MHz, the relative amplitudes of the field components are approximately the same and the composite total of the average E-field components is approximately 4.8 dB greater than the individual components. This indicates that the measured value of the average of each component is independent of polarization of the dipole. (i.e., $E_{x(ave)}$ is independent of

$$E_{y(ave)}$$
, etc.). Thus,
$$E_{t(ave)} = \sqrt{(E_{x(ave)})^2 + (E_{y(ave)})^2 + (E_{z(ave)})^2} \approx \sqrt{3} (E_{(x,y,or\ z)ave}).$$

The composite total however, of the E-field components' maxima (figure 2.28b) is less than 4.8 dB. This indicates that the maximum measured values for each component are not independent. (i.e., $E_{x(total)}$ is a function of $E_{y(total)}$, etc.). The implication is that if multiple receptors are involved in establishing the maximum susceptibility of an EUT (or for example in measuring the E-field in the chamber by using an isotropic probe with 3 orthogonal dipoles), the difference between the maximum and average response may be less than the typical 7 to 8 dB referred to in section 2.3.

2.5 Multiple Excitation of the Chamber

Electromagnetic fields were generated inside the chamber using two separate antennas simultaneously excited in the frequency ranges, (200-400) MHz, and (1000-2000) MHz. The antennas used for the frequency range (200-400) MHz were a log periodic and a long wire described previously. Two ridged horns were used in the frequency range (1.0-2.0) GHz. The spatial, statistical, E-field uniformity did not improve significantly over using a single antenna excitation in the 200-400 MHz frequency range; however, it did improve slightly (from approximately ± 2 dB to ± 1.5 dB variations) in the frequency range (1.0-2.0) GHz.

The E-field amplitude in the chamber decreased when using two excitation antennas, in both frequency ranges, assuming the same net input power as for a single antenna. The decrease was approximately 1 dB in the frequency range (200-400) MHz and approximately 1.5 dB in the frequency range (1.0-2.0) GHz. This loss however, can be accounted for in the losses in the additional rf transmission line cables and the second excitation antenna (i.e., the antennas are not 100% efficient in converting input rf power to radiated power).

3. Interaction Effects Between Chamber, Source and Reference Antennas, and EUT.

3.1 Placement Constraints of EUT

Constraints on the placement of EUT inside the reverberation chamber are a result of the proximity effect of the chamber walls on the test field and upon the EUT. Measurements were made of the E-field close to the chamber's walls for comparison with measurements made of the E-field within the test zone outlined by the matrix of seven probes shown in figure 2.21 Two locations were selected: 1) 0.5 m from the chamber's side and back wall, 1.0 m above the floor; and 2) 0.12 m from the side wall approximately mid-way between the chamber's ends and 0.5~m above the floor. Location 1 was selected so the EUT test zone would be clear of obstructions but also with the probe far enough from the chamber's walls, hopefully, to avoid significant proximity effects. Location 1 measurements were consistent with the measurements made at the 7 probe locations. Location 2 was selected to determine just how significant the proximity effect is at distances less than one third wavelength (<800 MHz). The average Efield measured at location 2 was approximately 2 dB lower at frequencies from 200 to 400 MHz than the E-field measured in the test zone. The field close to the chamber wall then increased as a function of frequency, approaching the test zone measured field strength at frequencies above 1 GHz. These results indicate a need to maintain a minimum spacing for the reference antenna, field measurement probe(s), and/or EUT of at least $\lambda/3$ from the chamber's walls at the lowest test frequency. This equates to approximately 1/2 meter at 200 MHz for the NBS chamber. An exception to this guideline may be a desired spacing between the EUT and the chamber floor or walls. This spacing may be dictated by the test plan. If the EUT is electrically large (many wavelengths) it may be necessary to have a separation distance from the chamber walls greater than $\lambda/3$ at frequencies where $\lambda/3$ is less than 1/2 meter or greater than 1/2 meter under some test conditions to prevent shadowing effects from influencing the spatial distribution of the test field. Results of scattering effects measurements discussed in section 3.2 suggest shadowing is not a signficant problem, if the EUT is placed in the center of the test zone as far from the walls as possible.

3.2 Scattering Effects of Metal Objects upon E-field Distribution

Two test objects were selected to simulate an EUT placed in the chamber to evaluate their scattering effect upon the field distribution inside the chamber. The first object was a solid welded aluminum box 30 cm x 50 cm x 60 cm in size. The second was an electronic equipment rack 56 cm x 67 cm x 114 cm in size. Tests were made to determine the E-field uniformity or distribution over the test zone matrix defined earlier using 6 isotropic probes (figure 2.19) with each of the two test objects placed at the center of the test zone. (The probe at the center of the test zone was removed to accommodate the test objects.) Figures 3.1a and 3.1b show the two test objects placed inside the enclosure. The mean value of the maximum and average values for each E-field component (vertical, longitudinal, and transverse) and their composite total were determined for each of the 6 probes. The results, shown in figure 3.2, give a comparison with the empty chamber E-field distribution measurements shown in figure 2.28. Little or no difference was noted in the statistical (average and maximum) values measured.

3.3 Loading Effects of EUT on Chamber

One of the concerns expressed about using a reverberation chamber for EMC measurements was the realization that if the EUT absorbed energy from the chamber (i.e., demonstrates susceptibility) it would reduce the Q of the chamber and thus affect the measurement results. Typically this is compensated for by simply increasing the net input power to the chamber transmitting antennas as required. This may not be sufficient if inserting the EUT lowers the chamber's Q to the extent that the chamber no longer reverberates or the tuner will no longer sufficiently stir the modes, (i.e., the chamber no longer functions properly). Recall that the absolute amplitude of the test field level inside the chamber is determined from the reference antenna received power measurements. The assumption is that this measurement is unaffected by the loading effect of the EUT. Two simple tests were used to evaluate the loading effect: the first was to insert a 500 MHz, half-wave, resonant dipole near the center of the chamber's test zone to determine if energy coupled from the chamber to the dipole would

reduce the field strength in the chamber. This test was intended to simulate the loading effect of a simple resonant EUT. Field strength measurements were made again using the seven probe matrix and the long wire antenna as a reference receiving antenna to determine the level of the test field, before and after inserting the resonant dipole. A constant normalized input power of 1 watt was applied at the input of the chamber log periodic transmitting antenna to establish the field in the chamber. The following observations were made:

- 1) Energy is conserved (i.e., power coupled from the chamber via the dipole results in a proportional decrease in the E-field in the room).
- 2) The 500 MHz resonant dipole and the long wire receiving antenna coupled approximately the same amount of power from the room.

The seven probe matrix used to determine the spatial distribution of the E-field inside the chamber, also load or reduces the Q factor in a similar fashion to the resonant dipole. Each of these probes couple a small amount of energy out of the test field. In addition, they have lossy transmission lines made up of carbon loaded teflon that serve to convey their detected dc signals to their instrumentation located outside the chamber. These lossy transmission lines increase the chamber's loss up to 5 dB at 2.0 GHz. However, this amount of loss did not seem to significantly influence the ability to determine the field level in the chamber, with or without the presence of the probes by using the reference receiving antenna. The field level simply was lower for the same net input power due to the loading effect of the probes in the chamber.

The second test used to evaluate the loading effect was to place varying amounts of rf absorbing material inside the chamber. This was done to get an indication of just how much loading the chamber could tolerate before it fails to operate properly and/or large errors existed in determining test field level and EUT response. Progressively greater amounts of absorber were added until approximately 90 percent of the net input power was being absorbed (i.e., the chamber loss was increased by approximately 10 dB). The amount of rf absorber required was four pieces of 66 cm pyramidal high performance absorber 61 cm x 61 cm square. Results for tuner effectiveness, VSWR and chamber loss with absorber loading were shown in figures 2.18b, 2.22c, and 2.24. As indicated earlier, lowering the chamber Q reduces the test field level in the chamber for a given net input power. Inserting the 4 pieces of absorber in the chamber lowers the field considerably as shown in figure 3.3. This figure compares the maximum E-field strength in the test volume defined by the 7 probe matrix inside the empty chamber with the field strength after the chamber is loaded with the 4 pieces of absorber.

In summary, the following observations can be made from the data obtained (figures 2.18b, 2.22c, 2.24 and 3.3). Lowering the chamber Q:

- 1) decreases the effectiveness of the tuner (lower Max/ in ratio),
- 2) improves the VSWR of the transmitting and receiving antennas,
- 3) increases the chamber loss and hence increases the rf power required to obtain test fields of the same level.
- 4) increases the uncertainty in determining the test field level and EUT response (indicated by the larger variations in the E-field data obtained with absorber, figure 3.3), and
- 5) decreases the spatial, statistical E-field uniformity.

In conclusion, the following guidelines are suggested. Inserting the EUT should not lower the maximum or average received power from the chamber's reference antenna for the same net input power into the chamber (before and after inserting the EUT) excessively. If these ratios, net input power/received power(max or ave), increase more than 6 dB, or if the tuner's average effectiveness decreases to less than 20 dB, use of the reverberation chamber is not recommended.

- 4.0 Performing Immunity Measurements
- 4.1 Planning the Measurements

A number of considerations are important in planning the measurements, writing the test plan, and documenting the test results. One is the amount of data required to accurately

characterize the EUT. Equipment susceptibility to EMI is primarily determined by the degree to which the interference field couples into and interacts with the equipment's components. This undesired coupling is influenced by a number of equipment parameters such as: input/output, power line, and circuit lead impedances and lead lengths; impedances of circuit components (especially those terminating lead wires); type of circuit components (particularly active components); and amount and type of EMI shielding and filtering used. The susceptibility of any particular equipment is usually a function of frequency, suggesting resonance effects within the equipment with its input/output leads and other interconnected equipment. These resonances may be caused, for example, by the reactance of the connecting leads acting as an antenna, coupling with the input impedance of the terminating circuit components. The quality factor (Q) of such a resonant circuit determines the maximum spacing or increment between frequencies at which susceptibility tests must be performed. Automated systems such as required by the reverberation chamber test methods are (by their digital nature) discrete frequency systems. The number of test points one can obtain using such a system are limited by the memory or storage capacity of the computer, the measurement system bandwidth, and the measurement time constraints. Thus, care must be exercised in choosing frequency and amplitude measurement intervals compatible with the test system and the number of test points required.

A second consideration is the test-field time duration versus reaction time of the EUT. Some EUTs have components with relatively slow thermal time constants. This equipment must be exposed to test fields with sufficient duration to allow reaction and interaction; otherwise susceptibility tests may not be true indicators of the equipment's vulnerability. For example, thermocouple devices used to simulate electro-explosive devices may require one to two seconds exposure time for maximum response. EUT soak time requirements influence the approach (section 4.2) selected for performing the tests using the reverberation chamber method.

Another important consideration relates to the need to simulate as closely as possible "real world" operating conditions. Ideally, susceptibility tests should be performed with the EUT connected and operated in its operational environment. Since this, most likely, is not possible, these operational conditions should be carefully simulated. This normally includes making certain the EUT is tested with its wiring harness in the same configuration (as nearly as possible) as when in actual use. (Actually, one of the advantages of the reverberation chamber method is that the test results are independent of EUT wiring harness , input/output and power lead orientation.) In addition, all connecting leads should be terminated with equivalent impedances as when in actual use. Failure to simulate these conditions can result in data that are misleading. An additional problem is the EUT-antenna-enclosure interaction that exists inside any shielded enclosure. Antenna radiation or receiving characteristics are altered when enclosed inside a shielded environment. One should realize that the EUT always interacts somewhat with the exposure field in any environment. What is difficult is sorting out the normal open-field scattering effect from the unknown perturbation effects of the EUTantenna-enclosure interaction that is typically ignored in shielded room susceptibility testing. Efforts to quantify this effect for reverberation chamber obtained results are discussed in section 5.

How to sense and telemeter the performance of the EUT from the test environment without perturbing the EUT, the test environment or sensitive test equipment is another important consideration. This is usually done by using either fiber optics lines or "invisible" wire [13] (carbon impregnated Teflon) with appropriate readout devices.

Finally, one obvious purpose for performing susceptibility tests is to determine EUT compliance with pre-established performance criteria. For production item sampling, a worst case EMI exposure environment with pass-fail criteria may be appropriate. However, for engineering development of EMI-hardened equipment or for correcting EMI problems discovered in existing equipment, diagnostic testing is needed. This type of testing requires knowledge of the exposure field parameters, such as: frequency, repetition rates, and wave shape of test signal; type and percent of modulation imposed; and polarization, amplitude and signal waveform time variations. These parameters must be carefully selected, as part of the test plan, controlled, and (for some tests) statistically characterized for the testing to be meaningful. One obvious limitation of the reverberation chamber method for susceptibiltiy testing is the loss of polarization information. However, this is in part compensated for because worst case response characteristics of the EUT can be determined without repositioning or orienting the EUT in the reverberation chamber since the test field is rotated around the EUT. If carefully controlled tests are performed, resonances and susceptible EUT circuit components can be determined, from which cause and effect relationships can be established. These can then be modified or eliminated to improve the immunity of the EUT.

important consideration in performing diagnostic testing is the desirability of determining how the EMI is coupled into the EUT. This requires separating, if possible, the sources of interference reception, such as EUT input/output and power line leads, leakage through the EUT case housing, or internally generated and coupled EMI. This can be achieved by a systematic process of shielding and filtering various leads and functional sections of the EUT's circuit, etc., while conducting the susceptibility tests.

4.2. Measurement Approach (Tuned vs. Stirred)

Two approaches are used for performing EMC measurements using the reverberation chamber. The first approach, mode tuned, steps the tuner at selected, uniform increments, permitting measurements of the net input power, reference antenna received power, field measuring probe response and the EUT response at each tuner position. This allows corrections and normalization of the received power, field measurements and EUT response to be made for variations in the net input power to the chamber. These variations are due to changes in the input VSWR of the transmitting antenna as a function of the tuner position. The number of tuner steps per revolution that must be used is a function of frequency and chamber Q. Typically, at least 200 steps or more are required to provide sufficient sampling to accurately determine the statistical parameters of the test field and EUT response (maximum and average amplitudes). If the sample size is too small, the fidelity of the measurements suffers and true maxima, minima, etc. are not recorded. The mode tuned approach also allows the operator to select long test field exposure times as needed to accommodate some EUT response times.

The second approach, mode stirred, rotates (steps) the tuner continuously while sampling the reference antenna received power, field probe response and EUT response at rates much faster than the tuner revolution rate. These measurements are made using a spectrum analyzer, diode detectors, and "smart" voltmeters with their own microprocessors capable of data storage and calculation of statistical functions such as mean values and standard deviations. The mode stirred approach allows large data samples (up to 9,999) for a single tuner revolution. Tuner revolution rates are adjusted to meet EUT response time and output monitor response time requirements. Typical revolution periods are from 1 to 12 minutes. This large sample, as compared to mode tuned, improves the accuracy in determining the statistics of the measured parameters, however, at the expense of increased uncertainty due to failure to correct for net input power variations.

Hence a trade-off exists between mode tuned and mode stirred operation. An examination of figure 2.22 suggests this trade-off occurs approximately between 1-2 GHz. (i.e., The mode tuned approach would be more accurate below 1-2 GHz where the mode density is not as great and corrections can be made for variations in the net input power caused by large variations in the input VSWR of the transmitting antennas. Mode stirring is more accurate at frequencies above 1-2 GHz where VSWR variations in the transmit antenna as a function of tuner position are small and large data samples of the test field and EUT response can be taken.)

4.3 Measurement System

4.3.1 Measurement Setup and Instrumentation Requirements

A block diagram of the basic NBS reverberation chamber EMC measurement system is shown in figure 4.1. The test field is established by means of rf source(s) connected to transmitting antenna(s) placed inside the chamber. Antennas used are discussed in section 2.2.5. Modes excited inside the chamber are then tuned or stirred by rotating the mode tuner which functions as a field-perturbing device. The EUT may be placed anywhere convenient within the chamber provided no point on the EUT is closer than 1/2 meter to any wall, or ceiling. Placement relative to the floor is dependent upon a number of factors including intended use configuration relative to ground-planes etc., and should be specified by the test plan. Test, power, and control cables are routed to appropriate monitors, etc., outside the chamber via shielded or filtered cables and feed-through connectors, high resistance lines, and fiber optic lines as required to prevent leakage of fields to the outside environment. Note that a precision 10 dB attenuator is used with the power detector or spectrum analyzer, whenever possible, to measure the receiving antenna power. This is done to minimize impedance mismatch with the receiving antenna. The calibrated bidirectional coupler at the input to the transmitting antenna allows measurements of the net input power so corrections can be made for changes in net input power resulting from antenna-rf generator impedance mismatch and rf generator output variations that occur during the rotation of the tuner. As referred to earlier, these corrections are made when using the mode tuned measurements approach for each incremental change in tuner rotation. For mode stirred, the net input power is measured only

at the beginning of the measurement cycle. Details of how the measurement cycle proceeds under computer control, how the data are managed, recorded, and processed for presentation are contained in the next section describing the software used for these functions.

4.3.2 Software Requirements and Measurement Procedures

The computer code used in the evaluation of the reverberating chamber has evolved from simple routines that record only the measurement data to the present complex programs that have abilities to recover from many common system failures and operator errors. The more sophisticated programming is made possible by using modern laboratory computers containing large amounts of memory. The primary function of recording the measurement data however, remains unchanged and is outlined in this section, with some discussion of the supporting activities and refinements.

A general overview of the software is shown in figure 4.2. The major tasks of accumulating data using the two primary methods (mode tuned and mode stirred), saving the measured results, and preparing the data graphics are shown. The measurement routines are supported by the module entitled System Calibrations. The data library is not actually program code, rather it indicates data storage that is available to the Data Graphics program and is added to by the measurement programs. Two major programs, detailed below, are used to implement the measurement approaches. They are quite different in how the instrumentation is programmed and the data managed and will be discussed separately. The basic computer code defining these measurements is listed in appendix A. The listings contain the details of the measurements as shown in figures 4.3 and 4.4. The instrument control modules have been omitted to avoid excessive detail.

Mode-Tuned Approach

The flow diagram for the mode-tuned measurement program is given in figure 4.3. This diagram is used to assist in guiding the operator systematically through the measurement procedure.

Step 1. Place the EUT inside the chamber and access at as required for operation and performance monitoring.

Details for placement of the EUT and accessing it are contained in sections 3.1, 4.1, and 4.3.1. The EUT should be placed at least one half meter away from the outer walls of the chamber unless specified in the test plan to simulate proximity to a ground plane.

- Step 2. Connect the measurement system as shown in figure 4.1.
- Step 3. Specify measurement and calibration parameters.

Calibration factors for the cables and directional couplers used must first be tabulated and stored in the computer for later access. All parameters used in the measurements are then specified using a menu of items from which the operator may select the values for the experiment. These parameters include: frequency range and increments, number of tuner steps, signal generator output level as required to obtain the desired field strength inside the chamber, the EUT output voltage considered as an upper bound for maximum safe EUT operation, and an estimate of the response time of the EUT. The experiment description, operator's name, and the system clock can be accessed in the menu also. When the operator is satisfied with the parameter values and exits the menu, these values plus all calibration values (e.g., cable loss, coupling factors, etc.) are tabulated for reference. The measurement hardware is then initialized and the measurement begins.

Step 4. Perform the measurement (automated measurement sequence).

The measurement sequence can be traced in figure 4.3. At the beginning of each test all the instruments are set to zero (if there is an internal auto-zeroing feature) or a reading is taken to determine the offset from zero with the field removed. These offset readings are then used to adjust the readings taken with the field applied. This should be done as often as needed to minimize errors resulting from zero drift.

It is important to have reached both mechanical and electrical stability at each step of the tuner before reading the instruments. As the mechanical time constant of the stepping motor and the chamber's tuner blades is typically much longer than the electrical response time of the measurement instrumentation or the EUT, the most efficient manner with which to

collect the data is to minimize the movements of the tuner. Any given measurement usually involves a sequence of frequencies at which to measure the response of the device. This routine is designed to collect the data for all frequencies at each tuner step before moving the tuner to another location. The data is then rearranged at the conclusion of the measurements such that data from all tuner positions for a given frequency is together before it is processed for final graphic presentation.

After the instruments are zeroed and their offset voltages recorded, the rf power is applied and the response of all devices which could be damaged by excessive field strength is measured. This checking is done as rapidly as possible for each frequency and provides one level of protection for the system. Typically, the operator should specify power levels that are appropriate for the EUT(s) being tested. Then this test will detect only those conditions which cause an unusually high response.

With the initial checking done, the program then proceeds to read the remaining instruments in the system. These include power meters, digital voltmeters, spectrum analyzer, specialized data acquisition systems, and/or any other monitoring device being used.

As mentioned above, all frequencies of interest are measured before the tuner is moved to the next position. There are many possible ways to group this data and save it on a mass storage device. The approach used here is to maintain all the data for a given tuner step (or several steps) together in one file. This file can then be recalled and the data rearranged such that all the information for a given frequency is together. Saving the data frequently allows the measurement to be continued, without starting over, should the system lose power or a fatal error occur.

The routines necessary for operation of the instruments are, of course, unique to the device but some general concepts are useful to discuss:

- a). The program should exercise some care to insure the validity of the readings. Most instruments will allow access to a status byte that will indicate many failures common to the device. This can be monitored during the read cycle and action taken if the measurement is not valid. Action is also necessary if the device fails to respond or hangs the interface bus. These situations may require operator assistance, but the program should be able to recover and repeat the operation if the condition is temporary.
- b). Readings taken within the limits of the instrument yet too quickly for the rest of the system to respond, for instance the tuner may still be vibrating or the sensor may be slow to respond, will cause erroneous results. For these measurements where the field being monitored is generated by a cw signal of constant amplitude, the response of a device should settle to a constant value, provided the tuner has stabilized and the device has had enough time to respond. The computer should be able to determine when to accept the reading based on the factors mentioned. One method is to install fixed wait statements that guarantee steady conditions. A more dynamic approach is to monitor the device and compare readings until steady conditions are reached. This optimizes the already lengthy measurement by avoiding long idle times that may not be necessary. A refinement to simply comparing readings is to compare the averages of several readings grouped together, referred to as a running average. This has a tendency to smooth noise that may be on the signal and also to make comparisons of low level readings (near the noise floor) more stable.

Step 5. Correct the data by applying the system calibration values and zero field offset readings.

The correction factors are applied to the measured quantities at the time the data are taken and key items are calculated. These items are then stored in the memory for later use in compiling the data. Items may include incident and reflected powers to the transmitting antenna corrected for cable loss and coupling factors, power received from the reference antenna (corrected), etc. Care must be taken at the beginning of the measurement to assure that calibration factors and cable loss correction to be used match the physical setup.

At the completion of the last tuner position, with all the data residing in mass storage, the measurement routine is complete. The remaining tasks are independent programs, freeing the measurement system for other measurements.

Step 6. Compile the corrected data by frequency, normalize to a constant net input power (for example 1 watt), perform the statistical calculations and present final results.

Normalization of the corrected measurement data for determining: a) the E-field in the chamber, and b) the EUT response, for a constant net input power is done for each tuner position. First the corrected net input power is determined and compared to the desired normalized value. The difference is then used to shift the corrected received power measurements and EUT response measurements as if the actual net input power had been the desired normalized value. This may involve a simple linear extrapolation as is the case for linear detectors, or it may require calibration of the nonlinear response characteristics of the received power detectors and/or EUT monitors thus resulting in appropriate corresponding nonlinear corrections.

The statistical calculations are performed using the corrected, normalized data. These calculations include the maximum, average, and minimum values as appropriate, of the desired parameters (net input power, received power, EUT output response, etc.). The calculations are made using data sets obtained by using the corrected normalized data at the selected number of descrete tuner positions for one complete revolution of the tuner, at each frequency of interest. These result are then, typically, presented in graphs as a function of frequency.

Mode Stirred Approach

The mode-stirred measurement (figure 4.4) begins in a similar manner to the mode-tuned discussed above. The automated measurements sequence of events is somewhat different and hence some of the parameters necessary for performing mode-stirred measurements differ from mode-tuned.

Step 1. Place EUT inside the chamber and access it as required for operation and performance monitoring.

This is the same as for mode tuned.

Step 2. Connect the measurement system as shown in figure 4.1

This step is similar to the setup for mode tuned except the spectrum analyzer is used to measure the reference antenna received power and the EUT monitors must be fast sampling devices such as "smart" voltmeters referred to earlier.

Step 3. Specify measurement and calibration parameters.

These parameters are similar to the mode tuned case with the following two exceptions:

- a) The specification of revolution time for the tuner determines the sample size and sampling parameters associated with the EUT monitoring equipment. Tuner steps (sampling size) are now given as a function of time for one complete revolution of the tuner from which the number of samples that will be taken during that single revolution, for each of the sampling instruments, is determined. These numbers require careful timing trials prior to automating a mode-stirred measurement. The instruments used for the tests detailed in this report, "smart" digital voltmeters, are capable of performing statistical operations on a large number of samples (up to 9999) using a single trigger command. This feature is very convenient for this type of measurement but requires that the number of samples needed to synchronize rotation time of the tuner and total sampling time of the voltmeter be known prior to triggering the measurement. The time required for taking each sample voltage varies slightly with the amplitude of the signal measured. This makes it difficult to estimate accurately the total time required for any given number of samples. Approximations are used and the program adjusts the sample count to insure the correct sampling time for a complete revolution. The sampling should be completed as near to the end of the tuner revolution as possible to avoid weighting the statistics with an incomplete data set or data taken as the tuner begins a second revolution. Typical rates for tuner rotation are in the range of 1 to 12 minutes per single revolution.
- b) The signal generator output level is now a range of values because this program has the ability to search for an optimum response of the device. The range of response values is also accessible in the mode-stirred menu and gives the operator control over minimum readable output from the EUT and also the level considered as the upper safe limit. The program will attempt to keep power levels adjusted such that the response is at some point above the minimum and never above a maximum.

Sometimes it is advantageous to monitor the EUT response using analog devices such as an xy recorder. If care is taken to insure that the response time of the recorder is short compared to the sampling rate or rotation rate of the tuner, the EUT output can be monitored in real time, thus allowing optimization of the sample rate to correspond to the EUT response time. Care must be taken to insure adequate sample time, otherwise the EUT response will be clipped yielding inaccurate results. This condition is easy to detect from the analog output plots and hence avoid.

When the operator is satisfied with the parameter values and exits the menu, these values plus all calibration values (e.g., cable loss, coupling factors, etc.) are tabulated for reference. The measurement hardware is then initialized and the measurement begins.

Step 4. Perform the measurement (automated measurement sequence)

The measurement sequence is shown in figure 4.4. At the beginning of each test all the instruments are set to zero (rf power is off), if possible, or the zero offset is recorded the same as for the mode-tuned approach. The rf power is then applied at the lowest specified level, the tuner motion is activated, and the EUT response is monitored. This first measurement attempt, at each specified frequency, results in a search for a threshold response from the EUT. If the EUT's response is below the preselected level, the rf power is increased in 1 dB increments and held constant allowing the tuner to rotate a few degrees, while searching for the threshold level. If the threshold value for the EUT's response is not reached, the generator level is increased again and the searching process repeated until the threshold level is reached or the maximum range selected for the generator output is achieved. Upon finding an acceptable power level, the instruments are triggered to begin a measurement cycle. Typically the instruments used include "smart" digital voltmeters as mentioned earlier and a spectrum analyzer looking for a peak response from the reference antenna. Any specialized detecting device would also be included. The response of the EUT is constantly monitored via a second fast sampling voltmeter (in addition to the "smart" voltmeter doing the statistics) to protect it from overload. If, during the test, the response should exceed the maximum safe value so that the power level is decreased or any other error condition is detected, the program will remember the correct power level to be used as the measurement is restarted.

At the time all the instruments are done sampling, the program checks to see if the tuner completed a full revolution before the measurements (sample) were finished. A comparison of the times taken for the tuner revolution and each meter's total sampling time is made. If these values agree to within a given tolerance and no other errors were detected, then the numbers are assumed to represent a valid measurement. On the other hand, if these conditions are not met, the sampling parameters are adjusted and the entire measurement process is repeated for the same frequency. Special care taken in the preparation of these sample parameters, as mentioned earlier, will minimize the need for repeat measurements.

The results from all the instruments are now read into the computer, corrected using the appropriate calibration factors and the necessary calculations are made. This includes the statistical parameters for the EUT monitored data, as determined by the "smart" voltmeters, and the peak value of the received power from the reference antenna as measured using the spectrum analyzer. Caution must be exercised if the test field is modulated since this may influence the accuracy of the measurement results depending upon the detector(s) response characteristics. The reference antenna received power data can be used to determine a normalized response for the EUT based upon a constant test field level as a function of frequency if desired. The net input power delivered to the chamber is measured after the acceptable power level is established at the beginning of the measurement cycle, just prior to triggering the "smart" voltmeters. These measurements may then be used to normalize the data to an equivalent constant input power level preselected for all test frequencies if desired. The entire process is then repeated until all frequencies have been measured.

The process by which the statistics are derived for the parameters monitored by the "smart voltmeters" consists of the following steps: 1) the measured analog data is converted to digital form; 2) the first data value is stored for future reference; 3) the second and subsequence data values are compared to the previous data values to determine maximum, minimum, and the running total values; 4) at the conclusion of the data collection, (completion of the data sample) the running total is divided by the sample size to calculate an average value for the data set; and 5) finally, the maximum, minimum, and average values stored in the "smart" voltmeter are transferred upon command to the computer for mass storage and future use as required.

Step 5. Compile the corrected data and present final results.

Data obtained using the mode stirring approach is not normalized at each tuner position. Corrections applied to this data to normalize it to a specified value of net input power must be applied to the maximum, average, and minimum values as determined by the "smart" voltmeters (EUT and other monitored responses) or the maximum value (reference received power) as determined by the spectrum analyzer. Correction made to the data for cable loss, etc., must also be made in a similar way. After these corrections are made, the data is compiled by frequency and presented typically in graph form usually showing only the maximum values as a function of frequency. For example see figures 5.15 and 5.16.

5. Experimental Test Results

5.1 Correlation of Results to Anechoic Chamber Tests - Some Examples

This section describes efforts to estimate a "correlation factor" between reverberation chamber and anechoic chamber obtained results. This was done first for reference standard EUTs and then for an EUT more typical of operational equipment. Tests were performed using the NBS reverberation chamber and a $4.9~\text{m} \times 6.7~\text{m} \times 8.5~\text{m}$ anechoic chamber also located at NBS. The EUTs included in this study are: 1) a one centimeter dipole probe antenna (200 MHz to 18 GHz), 2) a ridged horn antenna (800 MHz to 10 GHz), 3) a series of rectangular coaxial transmission line (TEM) cells with apertures, (200 MHz to 4000 MHz), and 4) a modified 7.0 cm (2.75 ") folded fin aircraft rocket, (FFAR) (200 MHz to 12.0 GHz).

5.1.1 Description of Anechoic Chamber Measurement System

A block diagram of the NBS anechoic chamber EMC measurement system is shown in figure 5.1. The test field is established inside the chamber by means of an rf source connected to a standard gain transmitting antenna. This "standard field" is computed from [22]

$$E = \frac{\sqrt{30 \, P_{\text{net}} G}}{D} , \qquad (14)$$

where $P_{\rm net}$ is the net power in watts delivered to the transmitting antenna, G is the effective gain for the transmitting antenna, and D is the separation distance in meters. Equation (14) assumes far-field conditions for a field point on axis of the transmitting antenna so that G is the maximum power gain.

The net power, $P_{\mbox{net}}$, is determined using calibrated power meters and bidirectional couplers from the expression

$$P_{\text{net}} = P_{\text{inc}} CR_{\text{F}} - P_{\text{ref}} CR_{\text{R}}$$
 (15)

where $P_{\rm inc}$ is the forward incident power, $P_{\rm ref}$ is the reverse reflected power measured on the sidearm of the coupler, and $CR_{\rm F}$ and $CR_{\rm R}$ are the forward and reverse coupling ratios for the coupler referenced to its output port.

The transmitting antennas used are open ended waveguides (200 to 500 MHz) and standard gain horns (500 MHz to 18 GHz).

Comparisons of the response or susceptibility characteristics of EUT (or antennas) obtained using an anechoic chamber and a reverberation chamber are typically made in terms of peak values. The main reasons for this are that typically the EUT's worst case performance or susceptibility is desired, and the practical consideration of the difficulty in obtaining a true average response for an EUT from anechoic chamber data. Even determining the EUT's peak response in an anechoic chamber (depending of course upon how well behaved the EUT radiation pattern characteristic is) can require considerable measurements involving complete pattern measurements.

5.1.2 Measurement of the Peak Response of a 1 cm Dipole and a Ridged Horn

A comparison of the peak output response data obtained for the 1.0 cm dipole using the NBS reverberation and anechoic chambers is given in figure 5.2. Note that the probe output response in the anechoic chamber is greater, in general, by about 2.5 dB than its output in

the reverberation chamber. This suggests that the correlation between the results may be related to the EUT's gain characteristics in the two chambers (i.e., the gain of the dipole probe in free space is approximately 2.5 dB). Determination of a far-field gain for a complex receptor (for example the EUT described in section 4.3.4) is extremely difficult. Therefore, a simple, well defined broadband receiving antenna (a ridged horn) was used as an EUT to repeat similar tests performed for the 1 cm dipole. The horn is designed to operate in the frequency range 800 MHz - 10 GHz. For these measurements in the anechoic chamber, the peak response (peak received power) of the horn occurs when the horn is bore-site aligned and polarization matched with the source antenna. These measurement results were then compared with the horn's peak received power in the reverberation chamber with the same level exposure field. The results are shown in figure 5.3a. Note that the horn's response is greater in the anechoic chamber. To see if this difference corresponded to the difference in the gain characteristics of the horn in the anechoic chamber, as compared to that in the reverberation chamber, the horn was calibrated to determine its far-field gain in the frequency range 800 MHz - 10 GHz. These results are shown in figure 5.3b. Again, note the general agreement between the difference in the horn's response measured in the two facilities and the horn's far-field gain.

5.1.3 Measurement of RF Coupling Through Apertures in TEM Lines

Measurements were made using the reverberation and anechoic chambers to evaluate the rf coupling through apertures cut into a series of TEM cells or transmission lines. Three TEM cells were used. Similar models (EUTs) have been used for evaluating shielding effectiveness of connector assemblies [23]. Electromagnetic energy coupled through the aperture in the TEM cell when exposed to the test field excites the fundamental TEM mode inside the cell. This results in rf power conducted to the cell's output ports which can then be measured. These results are compared with the theoretically predicted values based upon a planar field exposure to determine degree of correlation. The results obtained for one of the TEM cells, shown in the photograph of figure 5.4, are given in figure 5.5. The dimensions for this cell are 12 cm x 18 cm x 36 cm with a 5.1 cm x 5.1 cm aperture centered in the top of the outer conductor. The theoretically predicted peak coupling for a uniform field exposure is also shown on figure 5.5 [24]. Measurements were not made in the anechoic chamber at frequencies below 500 MHz because of the limitations of the anechoic chamber measurement system. The theoretical peak values should be essentially the same as the measured values in the anechoic chamber. Again, the anechoic chamber peak data are generally higher than the peak reverberation chamber data. Also, the average reverberation chamber data are approximately 7-8 dB lower than the peak data, similar to both the 1 cm dipole and ridged horn results.

Results obtained for the second cell, shown in figure 5.6, are given in figure 5.7. The dimensions for this cell are 12 cm x 12 cm x 24 cm with a 3.1 cm diameter aperture. The results are similar to those shown for the larger cell. Results obtained for the third cell, shown in figure 5.8, are given in figure 5.9. The dimensions for this cell are 3.0 cm x 6.0 cm x 11.4 cm with a 1.4 cm diameter aperture centered in the top of the outer conductor. Again the results are similar.

5.1.4 Measurements of the EM Susceptibility of a Modified 7.0 cm Folding Fin Aircraft Rocket (FFAR) [25].

A 7.0 cm diameter FFAR was modified with a thermocouple element to sense the response of the rocket's inserted electro-explosive device (EED). This was done to allow measurement of the rf current coupling into the EED's bridge wire circuit when the rocket is exposed to an rf field. The rocket was also modified with a 1.27 cm plastic spacer at the base of its fin (on the tail section) to increase the rf coupling to the bridge wire circuit. This lessened the requirements for high rf power to generate fields sufficient to perform these measurements. This modification was justified, realizing the purpose of this study was to compare susceptibility results obtained for the rocket in different environments and not to simply evaluate an EUT's susceptibility to EMI. Photographs showing the rocket placement inside the NBS reverberation chamber and the NBS anechoic chamber are shown in figures 5.10 and 5.11. Measurement results of the rocket's thermocouple peak output current resulting from rf coupling as a function of frequency are shown in figures 5.12a and 5.12b. These data were obtained using exposure fields normalized to 10 mW/cm2 in each of the chambers. The anechoic chamber data were obtained by rotating the rocket in azimuth in a planar far-field using both vertical and horizontal polarizations. The rocket was rolled a few degrees around its axis before each azimuth cut. Sufficient roll angles were used to determine the peak response. Examples of pattern data obtained in the anechoic chamber at three selected frequencies are shown in figure 5.13. A total of 719 patterns were obtained in the anechoic chamber from

which the peak response at each frequency was determined. These data were then used to plot curve A of figure 5.12a. Curve A (anechoic chamber data) indicated greater response or more susceptibility, except at one frequency (1800 MHz), than curve B (reverberation chamber peak response). Again, the proposed explanation for this is the difference between the gain characteristics of the rocket's response in the anechoic chamber (for example see figure 5.13) and its gain characteristics in the reverberation chamber. The rocket gain is lost in the reverberation chamber. Figure 5.12b shows the difference between curves A and B for figure 5.12a.

5.2 Comparison of Results Between Reverberation Chambers

Measurements were made of the EM susceptibility response of three different EUTs, using two additional, similar, but different size reverberation chambers. These measurements were made to give an indication of the repeatability in measurement results obtained using the same technique (reverberation chamber methods) but with totally different facilities. The second and third reverberation chambers are located at the Naval Surface Weapons Center, Dahlgren, Virginia. These chambers were made from a single large shielded enclosure partitioned into two compartments with a removable center panel. The two chambers consist of: 1) the half chamber, 3.51 m x 5.18 m x 5.86 m in size using a little over half of the full enclosure, and 2) the full chamber, 3.51 m x 5.18 m x 10.82 m in size, using the full enclosure. The NSWC enclosure was constructed of continuously welded steel sheeting similar to the NBS enclosure. Two basic insights are provided by a comparison of results obtained from the evaluation of these different enclosures. First, that the input power requirements of a chamber is a function of its size and can be estimated based upon the calibration of a chamber of similar construction. Second, susceptibility test results obtained for the same EUT in different reverberation chambers are comparable. These conclusions are demonstrated in figures 5.14 to 5.17. Figure 5.14 shows a comparison of the fields inside the NBS and NSWC chambers calculated from the chamber's reference antenna received power measurements and then measured by a calibrated 1 cm dipole probe. The net input power was normalized to one watt for all three chambers. Note that the field inside the NBS chamber is approximately 4 dB stronger than the NSWC half chamber and 6 dB stronger than the NSWC full chamber. Recall that the power density inside a second chamber can be estimated from a calibrated chamber by using (9). The ratio of the average power densities for the NBS to NSWC full size chamber for the same net input power (see section 2.1) was 3.22. This is equal to approximately 5 dB, a little less than that indicated by comparing figures 5.14a and 5.14c, but still within reason.

The second point of obtaining comparable susceptibility results using different chambers is demonstrated in figures 5.15 to 5.17. These graphs show the comparison in measuring the responses of the NBS 1 cm dipole probe and a rectangular single ridged horn to a normalized 37 dB V/m field inside the three different chambers and the peak response of the 7.0 cm FFAR to a normalized 10 mW/cm² power density inside the NBS and the NSWC half size reverberation chambers. In general, the agreement is within measurement tolerances except at 200 MHz for the FFAR. This frequency approaches the lower limit for using the reverberation chambers and is also where the FFAR is most susceptible and hence where one would expect the greatest difference.

- 6. Summary and Conclusions
- 6.1 Conclusions Drawn From Study
- 1. The practical lower frequency limit for using the NBS enclosure as a reverberation chamber is approximately 200 MHz. This lower limit is due to a number of factors including insufficient mode density, limited tuner effectiveness, and ability to uniformly excite all modes in the chamber. These factors are a function of both chamber geometry and size. Increasing the inside dimensions of the chamber will lower the useful frequency limit in an approximately proportional manner.
- Spatial variations in the E-field maximum and average values determined in the chamber's test volume are:

Frequency	(MHz)	Variation	in	Measured	E-Field
200			<±	8 dB	
500			<±	5 dB	
1000			<±	3 dB	
2000			<±	2 dB	

These data were determined using the mode tuned approach with 200 tuner increments for one complete tuner revolution. The limitation for determining the spatial E-field variation is most likely due to the increasing mode density and hence field complexity in the chamber as a function of frequency and the insufficient sampling of the field resulting from the limited number of tuner positions used. The spatial E-field variations should decrease less than 2 dB at frequencies above 2 GHz if sufficiently large data samples are taken.

- 3. Using a combination of antennas within their specified design frequency ranges for transmitting and as reference receiving antennas inside the chamber is preferred to the use of a long wire antenna. This is apparent because of the lower VSWR and greater efficiency in exciting the chamber and coupling energy from the chamber.
- 4. E-field data obtained using the mode stirred approach with the chamber empty have significantly less amplitude variations with frequency than data obtained using the mode tuned approach, particularly at frequencies above 1-2 GHz (e.g., <3 dB rather than <6 dB. Compare figure 2.26 to figure 3.3.) This implies that the mode stirring method is superior for some applications above these frequencies. This is significant since the stirred method is much simpler and faster to use. In comparing the two methods it is interesting to note the difference in the amplitude of the maximum fields at frequencies below 1-2 GHz. The mode tuned method is more accurate at these frequencies for determining the absolute amplitude of the test field since it allows for corrections due to changes in antenna VSWR. Because of these observations and other supporting data, the best results (accuracy versus measurement time considerations) for the NBS reverberation chamber can be obtained using the following approaches and tuner positions for susceptibility testing:

Frequency	Range	Method	#	Tuner	Positions	or	Samples
0.2-1.0		Mode Tuned			20	-	
1.0-2.0	GHz	Mode Tuned			40	0	
>2.0 G	Hz	Mode Stirred			500	0	

- 5. Lowering the Q of the enclosure: a) increases the rf power required to obtain the test field, b) increases the uncertainty in determining the test field level, and c) decreases the spatial, statistical field uniformity.
- 6. The statistically determined average wave impedance of the EM field in the chamber is approximately that of free space (377 ohms), thus confirming the validity of (10).
- 7. The maximum E-field is approximately 7 to 8 dB greater than the average E-field.
- 8. Scattering from the EUT does not seem to influence the statistical, spatial E-field distribution within the chamber.
- 9. Multiple source excitation (from more than one location) improves the spatial E-field distribution slightly, but not enough to justify additional hardware requirements and the additional rf power needed to compensate for the loss in the additional input transmission line required.
- 10. Energy is conserved in the chamber (i.e., power coupled from the chamber via loss in transmission lines, antennas, EUT, physical support materials, etc., reduce the power density in the chamber. Thus it is good practice to remove all that are not essential to the tests from the chamber.
- 11. The chamber (NBS) continues to operate (as a reverberation chamber) with loading that reduces the Q significantly (up to 90% of the total energy absorbed), however, with significant loss in measurement accuracy.
- 6.2 Summary of Measurement Uncertainties
- 6.2.1 Determining the Field Strength Inside the Chamber

Recall from section 2.3.1 that the susceptiblity/vulnerability test field established inside the chamber can be expressed either in terms of an "equivalent" power density (8) or an "equivalent" E-field strength (10). An estimate of the uncertainties in each of these quantities can be obtained by analyzing the contributing parameters involved in each

mode-tuned and mode stirred approaches respectively, within their appropriate frequency bands. Five major categories are identified. The first is the uncertainty in determining the received power from the chamber's reference antenna. This is broken up into four components: namely, cable loss, attenuator calibration, reference antenna efficiency and power meter or spectrum analyzer measurements uncertainties. Values shown are typical of estimated uncertainties stated for these type of measurements and instruments.

The second category is the impedance mismatch error that can occur between the reference receiving antenna(s) (source) and the power detector(s) (load). The actual power delivered to the load is a function of the impedance match between the source and load, with maximum power transfer occurring when a conjugate impedance match exists.

Power transfer between a source and a load is given as

P_f = available power absorbed =
$$\frac{(1 - |\Gamma_S|^2) (1 - |\Gamma_L|^2)}{|1 - \Gamma_S \Gamma_L|^2}$$
(16)

where Γ_S and Γ_L denote complex reflection coefficients. The magnitudes, $|\Gamma_S|$ and $|\Gamma_L|$ can be obtained from the appropriate VSWR by the expressions

$$|\Gamma_i| = \frac{VSWR - 1}{VSWR + 1}$$
, $i = S \text{ or } L$.

The VSWRs for the reference antennas (sources) and power detectors (loads) used in the NBS reverberation chamber are given in table 6.3. These values were used to calculate the estimated uncertainties shown for the mismatch error in tables 6.1 and 6.2. Note that different average and maximum values are given.

The third category of error, referred to as mixing or sampling efficiency, is divided into two parts. The first part relates to the ability to obtain a uniform spatial field distribution (statistically) inside the chamber and to effectively destroy the polarization characteristics of the exposure field. (i.e., the statistically determined response characteristics of the EUT and chamber reference antenna are independent of their directional properties.) The second part is the uncertainty due to limiting the number of tuner positions per revolution when performing the measurement. This source of uncertainty is different when determining the average as compared to the maximum field as shown in the tables. Data shown in figure 2.27 and table 6.4 were used in obtaining these estimates.

The fourth category of uncertainty relates only to determining the equivalent E-field strength in the chamber from the equivalent power density. Recall that (10) assumes that the equivalent wave impedance inside the chamber is 120π ohms. In reality this is not true as was shown in figure 2.25. This figure was then used to provide an estimate for this error taking into account that a significant amount of data obtained to date indicates that peak fields are approximately 7-8 dB greater than the average field strength inside the chamber (see section 2.3.2). i.e., An examination of figure 2.25 shows values of wave impedance as large as 1600 ohms at frequencies below 500 MHz when the maximum E-field was measured. This would require a large correction, up to 6.3 dB. However, experience indicates that a well behaved relationship (7-8 dB difference) exists between the measured peak and average values of the E-field. This suggests that the peak value of the wave impedance for maximum E-field inside the chamber decreases as the frequency increases thus lowering this source of error. These observations are reflected in the uncertainty estimates shown in the tables.

The fifth source of error occurs if one fails to correct for net input power variations due to the loading effect of the chamber on the VSWR of the source antennas. (See section 4.2 for more details.) Note that these corrections are made typically when using the mode tuned approach and hence are not included in the total or root-sum-square error estimates of table 6.1. They are shown on the table to provide insight to the estimated magnitude of error expected if this correction were not made. The basis for these estimates are the data shown in figures 6.1a and 6.1b. These figures show the average and maximum E-field strength measured inside the NBS reverberation chamber using an array of seven NBS isotropic probes. A comparison is shown between results obtained before and after the measurements were corrected for net input power variations and normalized for an equivalent constant net input power. Note from table 6.1 this error is the same order of magnitude as 2), the mismatch error between the receiving antennas and power detectors. This is as expected since the source and

receiving antennas used in the chamber have similar VSWRs and the power detector (load) and generator VSWRs are also similar. This error is included in table 6.2 and estimated to be the same as for the receiving mismatch error.

The total (worst-case) uncertainties for each approach (mode-tuned, and mode-stirred) are shown at the bottom of each table. This uncertainty should be regarded as a conservative estimate. The probability of the true value of $E_{\rm a}$ being near the extreme of such worst-case uncertainty is small. This is because the probability of every error source being at its extreme value and in the worst possible combination is almost zero.

A more realistic method of combining uncertainties is the root-sum-of-the-squares (rss) method. The rss uncertainty is based on the fact that most of the errors are independent of each other and hence are random with respect to each other and combine like random variables. The rss method of combining random variables is justified by statistical considerations (beyond the scope of this report) which are also inherent in the reverberation chamber measurement methods.

Finding the rss uncertainty requires that each individual uncertainty be expressed in fractional form. The method of calculation follows the name – square the components, sum those squares and then take the square root. The results are shown at the bottom of tables 6.1 and 6.2.

6.2.2 General Comments on Error Analysis.

Some general comments on interpreting immunity measurement results uncertainties based upon the above experimental error analysis are appropriate.

- 1) The mismatch error at frequencies below 2 GHz, (particularly if corrections are not made for either the transmitting antennas or the receiving antennas mismatch looking into their source or load), will cause the field determination inside the chamber to be low. This also causes the EUT response results to be lower than they actually are. For example, the low frequency data of figures 5.15, 1 cm dipole, and 5.16, ridged horn, should be corrected (response increased) proportionally to the systematic offset error estimates show in tables 6.1 and 6.2. (i.e., 3.46 dB at 1.0 GHz and 1.66 dB at 2.0 GHz).
- 2) The wave impedance, when the peak response of an EUT is measured, appears to be higher than 120π ohms. This means that if the free space wave impedance of 120π ohms is used in determining the corresponding peak amplitude of the exposure field, there will be a systematic offset error resulting in too low a calculated E-field exposure value, or, since the actual E-field is higher than the calculated value this results in too high a EUT response indication for a specified E-field exposure.
- The spatial variation in the measured, statistically determined E-field in the chamber resulting from a complete revolution of the tuner decreases from as great as \pm 8 dB at 200 MHz down to less than \pm 2 dB at 2.0 GHz. (See figure 2.27.) Logically, it is expected that this variation will continue to decrease as the frequency increases. However, high variations exist in the response data obtained for EUT at frequencies where the spatial E-field variations are small. This is probably due to the relatively large variations in the wave impedance as a function of tuner position. Some additional influence may be due to the mismatch characteristics of the antennas vs source and load as a function of frequency. A way to reduce this problem is to increase the number of frequencies at which data are taken (clustered around a particular frequency of interest) or increase the number of reference receiving antennas or probes used to determine the exposure field (for example see figure 2.27) and then average the data.

6.3 Measurement Technique Advantages and Limitations

Significant advantages do exist, as alluded to in the introduction, for using a reverberation chamber for EMC measurements. Specific advantages and limitations for which insight was obtain from this study include:

a) The ability to generate high level fields efficiently. For example, 1 watt net input power into the NBS reverberation chamber results in electric fields of approximately 70 V/m. This is approximately 1/10 the input power required to generate the same level field in the NBS anechoic chamber, assuming far-field separation distances.

- b) Large test zones, for example up to 2/3 of the volume inside a reverberation chamber can be available excluding an area approximately 1/2 meter spacing to the walls.
- c) Broad frequency coverage (from 200 MHz to at least 18 GHz in the NBS chamber).
- d) Testing is cost effective. This is especially true in comparison to anechoic chamber testing. Significant savings are realized in two major ways. First, the facility installation and measurement system procurement costs for a reverberation chamber are significantly less than for an anechoic chamber. Second, the time required to perform a complete EMC analysis of an EUT should be much less using a reverberation chamber. Again, from our experience in evaluating the susceptibility of the 7.0 cm FFAR, it required approximately 1/10 the test time to obtain the reverberation chamber results as compared to the anechoic chamber results shown on figure 5.13.
- e) The directional characteristics of antenna or EUT placed inside a reverberation chamber are lost resulting in an equivalent gain of unity.
- f) The response of an antenna or EUT measured inside a reverberation chamber is less than when measured inside an anechoic chamber (open space) in proportion to its gain. Hence, it appears that the EUT's gain is the desired correlation factor. This implies that susceptibility criteria determined for an EUT using a reverberation chamber must include an additional factor proportional to the EUT's estimated maximum gain as a function of frequency.
- g) The response of EUT to an electromagnetic field <u>after</u> it has penetrated the EUT's shield, appears to be equivalent in both the reverberation and anechoic chambers.

The advantages indicated above may well outweigh the disadvantages implied in items e and f, at least for some applications. The obvious trade off is one of measurement uncertainty that one can tolerate in determining the EMC/EMI characteristics of specific EUT and the inherent measurement uncertainties associated with determining the amplitude of the test fields inside the reverberation chamber.

7. Suggestions for Future Research Efforts

Because of the significant potential of the reverberation chamber method for performing immunity measurements, considerable interest has been expressed to further evaluate this technique with the intent of extending its range of applications. Specifically, the following suggestions are offered.

- 1) Evaluate the reverberation chamber measurement method for pulsed rf (down to 1 μ s pulse duration) immunity testing, (i.e., experimentally investigate pulse dispersion characteristics of the chamber). Measurement studies are in progress at NBS under the sponsorship of the NSWC and RADC to complete this task.
- 2) Determine the feasibility of extending the use of the chamber from 18 GHz to 40 GHz. A plan exists to undertake such an effort in late 1985 at NBS under sponsorship of RADC.
- 3) Evaluate reverberation chamber excited as a TEM transducer, (i.e., determine the feasibility of consolidating a TEM cell and reverberation chamber into a single facility for testing from 10 kHz to 18 GHz and beyond). This item is suggested because of the unique potential of developing a single, shielded facility that could be used for EMC/EMV testing over the complete frequency range listed above. This task is also planned at NBS under RADC sponsorship.
- 4) Investigate the feasibility of using the reverberation chamber for multiple frequency immunity testing. This is of interest because such complex fields of multiple frequencies can exist in typical operational environments.
- 5) Investigate the use of the reverberation chamber technique for measuring shielding effectiveness of connectors (evaluate MIL STD 1344 measurement technique), shielding materials, and enclosures in comparison to other techniques. This suggestion is included with the objective of improving the state of art in shielding measurements and to determine if correlation or agreement exists between results obtained using the reverberation chamber method and other established techniques.

8.0 Acknowledgments

The work described in this report was jointly funded by the Naval Surface Weapons Center (NSWC), Dahlgren, Virginia; Rome Air Development Center (RADC), Griffiss Air Force Base, Rome, New York; and the National Bureau of Standards,(NBS), Boulder, Colorado. The authors express appreciation especially to John Bean, NSWC; Charles Blank, RADC; and Mark T. Ma, NBS for their support, helpful comments and editorial review. Acknowledgement is also given to John L. Workman for his assistance in performing many of the measurements included in this study.

9.0 References

- [1] Mendes, H.A. A new approach to electromagnetic field-strength measurements in shielded enclosures. in Wescon Tech. Papers; Los Angeles, CA. 1968 August.
- [2] Cummings, J.R. Translational electromagnetic environment chamber, a new method for measuring radiated susceptibility and emissions. Proc. IEEE Int. Symp. on EMC; 1975; San Antonio, Texas.
- [3] Corona, P; Latmiral, G; Paolini E; Piccioli L. Performance of a reverberating enclosure for power measurements in the microwave range. 2nd Symp. Tech. Exhibition on EMC; 1977; Montreux, Switzerland. 419-427.
- [4] Bean, J.L.; Hall, R.A. Electromagnetic susceptibility measurements using a mode-stirred chamber. Proc. IEEE Int. Symp. on EMC; 1978; Atlanta, GA.
- [5] Corona, P. Electromagnetic reverberating enclosures: behavior and applications. Alta. Frequ.: Vol. 49; 1980. 154-158.
- [6] Corona, P.; Latmiral, G; and Paolini, E. Performance and analysis of a reverberating enclosure with variable geometry. IEEE. Trans. on EMC; EMC-22(1): 2-5; 1980 February.
- [7] Crawford, M.L. Evaluation of a reverberating chamber facility for performing EM radiated field susceptibility measurements. Nat. Bur. Stand. (U.S.) NBSIR 81-1638; 1981 February.
- [8] Liu, B.H.; Chang, D.C.; and Ma, M.T. Eigenmodes and the composite quality factor of a reverberating chamber. Nat. Bur. Stand. (U.S.) NBS Tech. Note 1066; 1983 August.
- [9] Ramo, S.; and Whinnery, J.R. Fields and Waves in Modern Radio, 2nd ed. New York: John Wiley & Son, Inc.; 1960. 418-428.
- [10] Liu, B.H.; Chang, D.C.; and Ma, M.T. Design considerations of reverberating chambers for electromagnetic interference measurements. Proc. IEEE. Int Symp. on EMC; 1983; Washington, DC. 508-512.
- [11] Ma, M.T.; Kanda, M.; Crawford, M.L.; and Larsen, E.B. A review of electromagnetic compatibility/interference measurement methodologies. Proc of IEEE. 388-411; 1985 March.
- [12] Tai, C.T. On the definition of the effective aperture of antennas. IEEE Trans. Antennas and Propag. AP-9: 224-225; 1961 March.
- [13] Greene, F.M. Development of Electric and Magnetic Near-Field Probes. Nat. Bur. Stand. (U.S.) NBS Tech. Note 658; 1975 January.
- [14] Roe, J.M. An improved technological basis for radiated susceptibility and emissions specifications. Proc. IEEE. Int. Symp. on EMC; 1978; Atlanta, GA.
- [15] Roe, J.M. Design of tuner for TEMEC, McDonnel Douglas Corp., St. Louis, MO., Private Communication.
- [16] Bean, J.L. Design of tuner for NSWC reverberating chamber, Naval Surface Weapons Center, Dahlgren, VA., Private communication.

- [17] MIL-STD-1377 (Navy). Effectiveness of Cables, Connectors, and Weapons Enclosures Shielding and Filters in Precluding Hazards of Electromagnetic Radiation to Ordinance, Measurement of. 1971 August.
- [18] Lentz, R.; and Anderson, H. Reverberating chambers for EMC measurements. Proc. IEEE. Symp. on EMC; 1979; San Diego, CA.
- [19] Crawford, M.L. and Koepke, G.H. Operational considerations of a reverberation chamber for EMC immunity measurements some experimental results. Proc. IEEE. Nat. Symp. on EMC; 1984; San Antonio, TX.
- [20] Wilson, P.F. Peak versus average response characteristics in a reverberation chamber. National Bureau of Standards, Boulder, CO, Private communication.
- [21] Bensema, W.D.; Reeve, G.R.; and Koepke, G.H. A multisensor automated EM field measurement system. Proc. IEEE IMTC/85 Conf; 1985; Tampa, FL.
- [22] Bowman, R.R. Calibration techniques for electromagnetic hazard meters: 500 MHz to 20 GHz. Nat. Bur. Stand. (U.S.) NBSIR 75-805; 1976 April.
- [23] Pressel, P.I. Mismatch: a major source of error in shielding effectiveness measurements. Proc. Seventeenth Annual Connector and Interconnection Technology Symp; 1984 September; Anaheim, CA.
- [24] Wilson, P.F. Apertured coaxial probe. Paper in progress.
- [25] Bean, J.L. Hero susceptibility of a 2.75 Inch FFAR: comparative results obtained from mode-stirred chambers, anechoic chamber, and ground plane test facilities, Proc. IEEE IMTC/85; 1985; Tampa, FL.

LIST OF FIGURES and TABLES


- Figure 2.1. Distinct frequencies of modes in NBS 3.05 m wide x 4.57 m long x 2.74 m high shielded chamber below 200 MHz.
- Figure 2.2 Total number of modes as a function of operating frequency for the NBS chamber.
- Figure 2.3 Total number of modes as a function of operating frequency for a square based chamber whose volume is the same as that of NBS chamber.
- Figure 2.4 Total number of modes as a function of operating frequency for a cubic chamber whose volume is the same as that of NBS chamber.
- Figure 2.5 An illustration of mode degeneracy (NBS chamber).
- Figure 2.6 An illustration of mode degeneracy (square-based chamber).
- Figure 2.7 An illustration of mode degeneracy (cubic chamber).
- Figure 2.8 Cumulative distribution curve of the normalized 1/Q values in the 180 MHz to 200 MHz frequency band for the NBS chamber.
- Figure 2.9 Cumulative distribution curve of the normalized 1/Q values in the 330 MHz to 350 MHz frequency band for the NBS chamber.
- Figure 2.10 Cumulative distribution curve of the normalized 1/Q values in the 480 MHz to 500 MHz frequency band for the NBS chamber.
- Figure 2.11 Photograph of interior of NBS reverberation chamber.
- Figure 2.12 Average and minimum losses between transmitted and received powers measured at antennas' terminals inside NBS reverberation chamber. Transmitting antennas are: log periodic (200 MHz 1000 MHz), ridged horn (1.0 GHz 4.0 GHz), double ridged circular horn (4.0 GHz 18 GHz). Receiving antennas are: long wire (200 MHz 1000 MHz), ridged horn (1.0 GHz 4.0 GHz), double ridged circular horn (4.0 GHz 18 GHz).
- Figure 2.13 Theoretical composite Q and experimental Q' determined for NBS reverberation chamber. a) Theoretical and experimental values of Q as a function of frequency.

 b) Ratio of the theoretical composite Q to experimental Q' as a function of frequency.
- Figure 2.14 Bulkhead panel used for accessing NBS reverberation chamber.
- Figure 2.15 Tuner designs for use in reverberation chambers. a) McDonnell Douglas Corp. TEMEC tuner, b) NSWC chamber tuner, c) NBS chamber tuner.
- Figure 2.16 Photograph of tuner, log-periodic transmitting antenna and NBS isotropic probes inside NBS reverberation chamber.
- Figure 2.17 Details of tuner and stepping motor mounting for the NBS reverberation chamber.
- Figure 2.18 Ratio of maximum to minimum received power obtained by rotating tuner in the frequency range 200 MHz to 18 GHz. a) Empty chamber, b) Four pieces of 66 cm rf absorber placed upright in center of chamber, 0.5 m above floor.
- Figure 2.19 Cross sectional views of NBS reverberation chamber showing placement of tuner, transmitting and receiving antennas, and NBS probes.
- Figure 2.20 Design of taper section of long wire antenna for use in Reverberation chamber.
- Figure 2.21 Photograph showing long wire antenna and NBS probes placement inside NBS reverberation chamber.

- Figure 2.22 VSWR of transmitting antennas placed inside NBS reverberation chamber. a) Long wire antenna, chamber empty, b) Composite of three antennas, (log-periodic, 0.2-1.0 GHz), (ridged horn, 1.0 4.0 GHz), and (double ridged circular horn, 4.0-18 GHz), chamber empty, and c) Composite of three antennas with chamber loaded with 4 pieces of 66 cm rf absorber placed upright in center of chamber, 0.5 m above floor.
- Figure 2.23 Average and minimum losses between transmitted and received powers measured at antennas's terminals inside NBS reverberation chamber. Long wire antenna transmitting (200 MHz 18 GHz), composite of three antennas receiving (log periodic 200 MHz 1000 MHz, ridged horn, 1.0 GHz 4.0 GHz, double ridged circular horn, 4.0 GHz 18 GHz).
- Figure 2.24 Average and minimum losses between transmitted and received powers measured at antennas' terminals inside NBS chamber with four pieces of 66 cm rf absorber upright in center of chamber, 0.5 m above floor. Composite of three antennas used for transmitting and receiving.
- Figure 2.25 Magnitude of wave impedance inside NBS reverberation chamber.
- Figure 2.26 Average and maximum E-field strengths inside empty NBS reverberation chamber for 1 W net input power determined from: a) composite of 3 antennas received power measurements, and b) calibrated 1 cm dipole probe measurements.
- Figure 2.27 E-field strength measured inside NBS reverberation chamber using array of 7 NBS isotropic probes: (a) maximum, and (b) average. Net power normalized to 1 Watt. Transmitting antennas are: log periodic (100 MHz 1 GHz), ridged horn (1 GHz 2 GHz).
- Figure 2.28 Mean values of the E-field strength measured inside NBS reverberation chamber using array of 7 NBS isotropic probes with 1 W net input power: (a) average, and (b) maximum. Data determined from maximum and average values of the 7 probes (7 locations) for the three orthogonal components and their sum (total) using 200 tuner positions (1.8 degree increments).
- Figure 3.1 Placement of metallic objects inside NBS reverberation chamber to evaluate scattering effects upon E-field spatial distribution. a) Photograph showing 30 cm x 50 cm x 60 cm welded aluminum box inside NBS reverberation chamber. b) Photograph showing rolling equipment rack inside NBS reverberation chamber.
- Figure 3.2 Comparison of the mean value of the average and maximum E-field strength measured using array of probes placed inside NBS reverberation chamber with chamber empty or with scattering object placed at center of test zone. a) 30 cm x 50 cm x 60 cm aluminum box, b) Rolling equipment rack.
- Figure 3.3 Maximum E-field strength inside empty chamber and chamber loaded with 4 pieces of 66 cm rf absorber for 1 W net input power determined from composite of 3 antennas received power measurements. Data obtained using mode stirring approach.
- Figure 4.1 Block diagram of NBS reverberation chamber evaluation and EMC measurement system.
- Figure 4.2 Major software tasks for performing and evaluation susceptibility tests using a reverberation chamber.
- Figure 4.3 Flow diagram for mode-tuned measurements.
- Figure 4.4 Flow diagram for mode-stirred measurements.
- Figure 5.1 Block diagram of NBS anechoic chamber EMC/EMI measurement system. Side view of chamber. The outside width is 6.7 m.
- Figure 5.2 Comparison of 1 cm dipole probe's peak responses to EM field established inside NBS reverberation and anechoic chambers. Output normalized to E-field exposure of 37 dB V/m.

- Figure 5.3 Comparison of ridged horn's peak responses to EM field established inside NBS reverberation and anechoic chambers. Output from horn normalized to exposure Efield of 37 dB V/m. a) Antenna output versus frequency, b) Difference in output responses of ridged horn measured in NBS reverberation and anechoic chambers compared to calibrated gain of horn.
- Figure 5.4 Photograph of 12 cm \times 18 cm \times 36 cm rectangular TEM cell with 5.1 cm \times 5.1 cm aperture.
- Figure 5.5 Comparison of power coupled to one port of 12 cm \times 18 cm \times 36 cm TEM cell with 5.1 cm \times 5.1 cm aperture placed inside NBS reverberation and anechoic chambers.
- Figure 5.6 Photograph of 12 cm x 12 cm x 24 cm rectangular TEM cell with 3.1 cm diameter aperture.
- Figure 5.7 Comparison of power coupled to one port of 12 cm x 12 cm x 24 cm TEM cell with 3.1 cm diameter aperture placed inside NBS reverberation and anechoic chambers.
- Figure 5.8 Photograph of 3.0 cm x 6.0 cm x 11.4 cm rectangular TEM cell with 1.4 cm diameter aperture.
- Figure 5.9 Comparison of power coupled to one port of 3.0 cm \times 6.0 cm \times 11.4 cm TEM cell with 1.4 cm diameter aperture placed inside NBS reverberation and anechoic chambers.
- Figure 5.10 Photograph of modified 7.0 cm Folding Fin Aircraft Rocket inside NBS reverberation chamber.
- Figure 5.11 Photograph of modified 7.0 cm Folding Fin Aircraft Rocket inside NBS anechoic chamber.
- Figure 5.12 Comparison of 7.0 cm modified FFAR thermocouple responses to EM field established inside NBS reverberation and anechoic chambers. Data normalized to exposure power density of 10 mW/cm². a) Thermocouple output vs frequency. b) Difference in thermocouple output measured in NBS reverberation and anechoic chambers.
- Figure 5.13 Examples of azimuth patterns of 7.0 cm modified FFAR thermocouple response taken in NBS anechoic chamber.
- Figure 5.14 Comparison of the average and maximum E-field strengths inside the NBS and NSWC reverberation chambers determined for 1 W net input power using 1) reference antenna received power measurements, and 2) calibrated 1 cm dipole probe measurements. (a) NBS chamber, (b) NSWC half chamber, and (c) NSWC full chamber.
- Figure 5.15 Comparison of 1 cm dipole probe's peak responses to normalized E-field of 37 dB V/m using NBS and NSWC reverberation chambers.
- Figure 5.16 Comparison of ridged horn's peak responses to normalized exposure E-field of 37 dB V/m using NBS and NSWC reverberation chambers.
- Figure 5.17 Comparison of 7.0 cm modified FFAR thermocouple responses to EM field established inside NBS and NSWC half reverberation chambers. Data normalized to exposure power density of 10 mW/cm². a) Thermocouple output vs frequency. b) Difference in thermocouple output measured in NBS and NSWC reverberation chambers.
- Figure 6.1 E-field strength measured inside NBS reverberation chamber using array of 7 NBS isotropic probes: (a) average, and (b) maximum. Comparison shown between results obtained before and after normalization of measurements to correct for changes in net input power. Normalized data corrected for net input power of 1.0 watt. chamber excitation antenna is log periodic. E_p is average field strength determined from 7 probes.

- Table 6.1 Summary and estimates of measurement uncertainties for determining field strength inside NBS reverberation chamber Mode Tuned (200 MHz 2.0 GHz).
- Table 6.2 Summary and estimates of measurement uncertainties for determining field strength inside NBS reverberation chamber Mode Stirred (2.0 GHz 18.0 GHz).
- Table 6.3 Estimates of impedance mismatch uncertainties for received power measurements.
- Table 6.4 Estimates of uncertainties due to limiting number of tuner positions (sample size).



Frequency (MHz)

Distinct modes	Mode #	Frequency MHz	Distinct modes	Mode # fmnp	Frequency MHz
1	110	59.13	33	222	161.16
2	011	63.83	34	320	161.49
2 3	101	73.59	35	240	164.05
4	111	80.58	36	013	167.48
5	120	82.02	37	321	170.51
6	021	85.48	38	042	170.95
7	121	98.62	39	150	171.32
8	210	103.69	40	103	171.32
9	130	110.07	41	241	172.94
10	201	112.57	42	051	172.94
11	031	112.66	43	113	174.55
12	012	114.30	44	023	
13	211	117.26	45	232	176.87 177.08
14	220	118.25	46	330	
15	102	120.03	47	142	177.38 177.89
16	131	122.93	48	151	
17	112	124.43	49	123	179.86 183.58
18	022	127.66	50	302	183.73
19	221	130.31	51	331	185.64
20	122	136.81	52	312	186.64
21	230	139.18	53	250	191.33
22	140	140.20	54	203	191.33
23	041	142.25	55	033	191.44
24	202	147.18	56	213	
25	032	147.25	57	322	194.23 195.10
26	231	149.56	58	242	195.10
27	141	150.51	59	052	197.28
28	212	150.80	60	340	
29	310	151.15	61	133	197.50
30	132	155.25	62	251	197.71
31	301	157.37	63	410	199.01
32	311	160.76	64	223	199.44
		100,0	04	443	202.38

Figure 2.1 Distinct frequencies of modes in NBS 3.05 m wide by 4.57 m long x 2.72 m high shielded chamber below 200 MHz.






Figure 2.2 Total number of modes as a function of operating frequency for the NBS chamber.



Total number of modes as a function of operating frequency for a square based chamber whose volume is the same as that of NBS chamber. Figure 2.3



Total number of modes as a function of operating frequency for a cubic chamber whose volume is the same as that of NBS chamber. Figure 2.4






Figure 2.5 An illustration of mode degeneracy (NBS chamber).



An illustration of mode degeneracy (square-base chamber). Figure 2.6





An illustration of mode degeneracy (cubic chamber). Figure 2.7




Figure 2.8 Cumulative distribution curve of the normalized 1/Q values in the 180 MHz to 200 MHz frequency band for the NBS chamber.




Figure 2.9 Cumulative distribution curve of the normalized 1/Q values in the 330 MHz to 350 MHz frequency band for the NBS chamber.




Figure 2.10 Cumulative distribution curve of the normalized 1/Q values in the 480 MHz to 500 MHz frequency band for the NBS chamber.



Figure 2.11 Photograph of interior of NBS reverberation chamber.




Figure 2.12 Average and minimum losses between transmitted and received powers measured at antennas' terminals inside NBS reverberation chamber. Transmitting antennas are: log periodic (200 MHz - 1000 MHz), ridged horn (1.0 GHz - 4.0 GHz), double ridged circular horn (4.0 GHz - 18 GHz). Receiving antennas are: long wire (200 MHz - 1000 MHz), ridged horn (1.0 GHz - 4.0 GHz), double ridged circular horn (4.0 GHz - 18 GHz).




Figure 2.13 Theoretical composite Q and experimental Q' determined for NBS reverberation chamber. a) Theoretical and experimental values of Q as a function of frequency. b) Ratio of the theoretical composite $\tilde{\text{Q}}$ to experimental Q' as a function of frequency.




Figure 2.14 Bulkhead panel used for accessing NBS reverberation chamber.



Figure 2.15a Photograph of field tuner/stirrer installed in McDonnell Douglas Corporation 2.4 m x 3.0 m x 7.6 m TEMEC (reverberation chamber) facility.



Figure 2.15b Photograph of field tuner/stirrer installed in NSWC 3.5 m x 5.2 m x 5.9 m reverberation chamber.



Figure 2.15c. Photograph of field tuner/stirrer installed in NBS 2.7 m x 3.1 m x 4.6 m reverberation chamber.

Figure 2.15. Tuner designs for use in reverberation chambers.

a) McDonnell Douglas Corp. TEMEC tuner, b) NSWC chamber tuner, c) NBS chamber tuner.



Figure 2.16 Photograph of tuner, log-periodic transmitting antenna and NBS isotropic probes inside NBS reverberation chamber.





Figure 2.17a. Details of collet for mounting tuner shaft to motor through wall of reverberation chamber.



Figure 2.17b. Photograph of tuner shaft mounted through collet on ceiling of NBS reverberation chamber.

Figure 2.17 Details of tuner and stepping motor mounting for the NBS reverberation chamber.






Figure 2.18 Ratio of maximum to minimum received power obtained by rotating tuner in the frequency range 200 MHz to 18 GHz. a) Empty chamber, b) Four pieces of 66 cm rf absorber placed upright in center of chamber, 0.5 m above floor.




Figure 2.19a. Cross sectional views of NBS reverberation chamber for use at frequencies above 1.0 GHz showing location of antenna and NBS probes.




Figure 2.19b. Cross sectional views of NBS reverberation chamber for use at frequencies below 1.0 GHz showing location of antenna and array of NBS probes.

Figure 2.19 Cross sectional views of NBS reverberation chamber showing placement of tuner, transmitting and receiving antennas, and NBS probes.




Figure 2.20 Design of taper section of long wire antenna for use in Reverberation chamber.





Figure 2.21 Photograph showing long wire antenna and NBS probes placement inside NBS reverberation chamber.



FREQUENCY (GHz) <u>်</u> 5.5 N. 5 1.5 . S ARMSA

antenna, chamber empty; b) composite of three antennas, (log-periodic, 0.2-1.0 GHz), ridged horn, 1.0-4.0 GHz), and (double with chamber loaded with 4 pieces of 66 cm rf absorber placed upright in center of chamber, 0.5 m above floor. ridged horn, 1.0-4.0 GHz), and (double ridged circular horn, 4.0-18 GHz), chamber empty; and c) composite of three antennas

Figure 2.22 VSWR of transmitting antennas placed inside NBS reverberation chamber. a) Long wire




Figure 2.23 Average and minimum losses between transmitted and received powers measured at antennas's terminals inside NBS reverberation chamber. Long wire antenna transmitting (200 MHz - 18 GHz), composite of three antenna receiving (log periodic 200 MHz - 1000 MHz, ridged horn, 1.0 GHz - 4.0 GHz, double ridged circular horn, 4.0 GHz - 18 GHz).




Figure 2.24 Average and minimum losses between transmitted and received powers measured at antennas' terminals inside NBS chamber with four pieces of 66 cm rf absorber upright in center of chamber, 0.5 m above floor. Composite of three antennas used for transmitting and receiving.




Figure 2.25 Magnitude of wave impedance inside NBS reverberation chamber.






Figure 2.26 Average and maximum E-field strengths inside empty NBS reverberation chamber for 1 W net input power determined from: a) composite of 3 antennas received power measurements, and b) calibrated 1 cm dipole probe measurements.





E-field strength measured inside NBS reverberation chamber using array of 7 NBS isotropic Net power normalized to 1 Watt. Transmitting probes: (a) maximum, and (b) average. Net power normalized to 1 Watt. Transcensas are: log periodic (100 MHz - 1 GHz), ridged horn (1 GHz - 2 GHz). Figure 2.27




Figure 2.28 Mean values of the E-field strength measured inside NBS reverberation chamber using array of 7 NBS isotropic probes with 1 W net input power: (a) average, and (b) maximum. Data determined from maximum and average values of the 7 probes (7 locations) for the three orthogonal components and their sum (total) using 200 tuner positions (1.8 degree increments).




Figure 3.1a Photograph showing 30 cm x 50 cm x 60 cm welded aluminum box inside NBS reverberation chamber.



Figure 3.1b Photograph showing rolling equipment rack inside NBS reverberation chamber.

Figure 3.1 Placement of metallic objects inside NBS reverberation chamber to evaluate scattering effects upon E-field spatial distribution. a) Photograph showing 30 cm x 50 cm x 60 cm welded aluminum box inside NBS reverberation chamber. b) Photograph showing rolling equipment rack inside NBS reverberation chamber.






Figure 3.2 Comparison of the mean value of the average and maximum E-field strength measured using array of probes placed inside NBS reverberation chamber with chamber empty or with scattering object placed at center of test zone. a) 30 cm x 50 cm x 60 cm aluminum box, b) Rolling equipment rack.




Figure 3.3 Maximum E-field strength inside empty chamber and chamber loaded with 4 pieces of 66 cm rf absorber for 1 W net input power determined from composite of 3 antennas received power measurements. Data obtained using mode stirring approach.




Figure 4.1 Block diagram of NBS reverberation chamber evaluation and EMC measurement system.




Figure 4.2 Major software tasks for performing and evaluation susceptibility tests using a reverberation chamber.




Figure 4.3 Flow diagram for mode-tuned measurements.




Figure 4.4 Flow diagram for mode-stirred measurements.




Figure 5.1 Block diagram of NBS anechoic chamber EMC/EMI measurement system. Side view of chamber. The outside width is 6.7 m.





Figure 5.2 Comparison of 1 cm dipole probe's peak responses to EM field established inside NBS reverberation and anechoic chambers. Output normalized to E-field exposure of 37 dB V/m.






Figure 5.3 Comparison of ridged horn's peak responses to EM field established inside NBS reverberation and anechoic chambers.

Output from horn normalized to exposure E-field of 37 dB V/m.

a) Antenna output versus frequency, b) Difference in output responses of ridged horn measured in NBS reverberation and anechoic chambers compared to calibrated gain of horn.



Figure 5.4 Photograph of 12 cm x 18 cm x 36 cm rectangular TEM cell with 5.1 cm x 5.1 cm aperture.




Figure 5.5 Comparison of power coupled to one port of 12 cm x 18 cm x 36 cm TEM cell with 5.1 cm x 5.1 cm aperture placed inside NBS reverberation and anechoic chambers.




Figure 5.6 Photograph of 12 cm x 12 cm x 24 cm rectangular TEM cell with 3.1 cm diameter aperture.




Figure 5.7 Comparison of power coupled to one port of 12 cm x 12 cm x 24 cm TEM cell with 3.1 cm diameter aperture placed inside NBS reverberation and anechoic chambers.



Photograph of 3.0 cm x 6.0 cm x 11.4 cm rectangular TEM cell with 1.4 cm diameter aperture. Figure 5.8





Figure 5.9 Comparison of power coupled to one port of 3.0 cm x 6.0 cm x 11.4 cm TEM cell with 1.4 cm diameter aperture placed inside NBS reverberation and anechoic chambers.



Figure 5.10 Photograph of modified 7.0 cm Folding Fin Aircraft Rocket inside NBS reverberation chamber.



Figure 5.11 Photograph of modified $7.0\ \mathrm{cm}$ Folding Fin Aircraft Rocket inside NBS anechoic chamber.








Figure 5.12 Comparison of 7.0 cm modified FFAR thermocouple responses to EM field established inside NBS reverberation and anechoic chambers. Data normalized to exposure power density of 10 mW/cm. a) Thermocouple output vs frequency. b) Difference in thermocouple output measured in NBS reverberation and anechoic chambers.



Examples of azimuth patterns of $7.0\ \mathrm{cm}$ modified FFAR thermocouple response taken in NBS anechoic chamber. Figure 5.13



brated 1 cm dipole probe measurements. (a) NBS chamber, (b) NSWC half chamber, and (c) NSWC full chamber. determined for 1 W net input power using 1) reference antenna received power measurements, and 2) cali-Comparison of the average and maximum E-field strengths inside the NBS and NSWC reverberation chambers Figure 5.14




Figure 5.15 Comparison of 1 cm dipole probe's peak response to normalized E-field of 37 dB V/m using NBS and NSWC reverberation chambers.





Figure 5.16 Comparison of ridged horn's peak responses to normalized exposure E-field of 37 dB V/m using NBS and NSWC reverberation chambers.








Figure 5.17 Comparison of 7.0 cm modified FFAR thermocouple responses to EM field established inside NBS and NSWC half reverberation chambers. Data normalized to exposure power density of 10 mW/cm . a) Thermocouple output vs frequency. b) Difference in thermocouple output measured in NBS and NSWC reverberation chambers.





(a) average, and (b) maximum. Comparison shown between results obtained before and after normalization of measurements to correct for changes in net input power. Normalized data corrected for net input $\boldsymbol{E}_{\ \ p}$ is average field strength $_{\ p}$ power of 1.0 Watt. Chamber excitation antenna is log periodic. determined from 7 probes.

Table 6.1 Summary and estimates of measurement uncertainties for determining field strength inside NBS reverberation chamber - Mode Tuned (200 MHz - 2.0 GHz)

1)	Source of Error Measuring Received Power	200 MHz Ave. Max.	Error (500 MHz Ave. Max.	1.0 GHz	2.0 GHz Ave. Max.
1)	Cable Loss Attenuator Calibration Antenna Efficiency Power Meter Calibration Total	± 0.05 ± 0.10 ± 0.05 ± 0.20 ± 0.40	± 0.05 ± 0.10 ± 0.05 ± 0.20 ± 0.40	± 0.05 ± 0.10 ± 0.05 ± 0.20 ± 0.40	± 0.10 ± 0.10 ± 0.10 ± 0.20 ± 0.50
2)	Receiving Power Mismatch (See Figure 6.1)	-2.8 -5.1	-1.5 -3.4	-0.7 -1.5	-0.3 -0.7
3)	Mixing/Sampling Efficiency Spatial Field Uniformity (see figure 2.27) Limited Sample Size	± 8.0	± 5.0	± 3.0	± 2.0
	(see Table 6.4)	±0.2 ±0.5	±0.2 ±0.5	±0.2 ±1.5	±0.3 ±1.0
	Total	±8.2 ±8.5	±5.2 ±5.5	±3.2 ±4.5	±2.3 ±3.0
4)	Wave Impedance ≠ 120π (see Figure 2.25)		-2.0 -2.0 +2.0 +6.0	-2.0 -2.0 +2.0 +4.5	
	Total Worst Case Error	-1 4.2 -16.8 +10.6 +14.9			-5.1 -6.2 +4.8 +6.5
	RSS Error	-9.1 -10.3 +8.5 +10.4	-5.8 -6.8 +5.6 +8.1		
	Failure to Correct for Input Power Variations (Transmit Mismatch Error)	-4.0	-3.0	-2.0	-1.0

Table 6.2 Summary and estimates of measurement uncertainties for determining field strength inside NBS reverberation chamber - Mode Stirred (2.0 GHz - 18.0 GHz)

Source of Error		Error 4.0 GHz Ave. Max.	8.0 GHz		
1) Measuring Received Power Cable Loss Attenuator Calibration Antenna Efficiency	± 0.10	± 0.10 ± 0.15	± 0.15 ± 0.15 ± 0.15		
Spectrum Analyzer Cal. Sub Total	± 1.50 ± 1.80	± 1.50 ± 1.90	± 1.50 ± 1.95	± 1.50 ± 2.05	± 1.50 ± 2.10
2)Receiving Power Mismatch (see Figure 6.1)	-0.8	-0.8	-0.8	-1.0	-1.8
3) Mixing/Sampling Efficiency Spatial Field Var. Limited Sample Size		± 1.0		_	_
(see Table 6.4) Sub Total	$\pm 0.1 \pm 0.3$ $\pm 2.1 \pm 2.3$	±0.2 ±0.5 ±1.2 ±1.5	$\pm 0.3 \pm 0.7$ $\pm 0.8 \pm 1.5$	$\pm 0.3 \pm 1.0$ $\pm 0.5 \pm 1.2$	$\pm 0.3 \pm 1.5$ $\pm 0.5 \pm 1.7$
4) Wave Imped ≠ 120π	Average	≦ ±2.0, -	2.0 ≩ Maxim	um ≤ +3.0	
5) Failure to Correct for Input Power Var.	-0.8	-0.8	-0.8	-1.0	-1.8
Total(Worst Case)Error		-6.7 -7.0 +5.1 +6.4		-6.6 -7.3 +4.6 +6.3	
RSS Error		-3.1 -3.3 +3.0 +3.9			

Table 6.3 Estimates of impedance mismatch uncertainties for received power measurements

		VSWR			Mismatch Error		
Frequency	Sot	Source		•	(dB)		
GHz	Ave	Max	Max	Ave	Max		
0.2	5.0	10.0	1.10	-2.83	-5.15		
0.5	3.0	6.0	1.10	-1.46	-3.40		
1.0	2.0	3.0	1.10	-0.66	-1.46		
2.0	1.5	2.0	1.10	-0.27	-0.66		
2.0	2.0	2.0	1.20	-0.81	-0.81		
4.0	2.0	2.0	1.20	-0.81	-0.81		
8.0	2.0	2.0	1.20	-0.81	-0.81		
12.0	2.0	2.0	1.30	-0.95	-0.95		
18.0	2.5	2.5	1.50	-1.77	-1.77		

Table 6.4 Estimates of uncertainties due to limiting number of tuner positions (sample size).

Frequency	Error due to limiting Sample Size Ave/Max (dB) Number of Tuner Positions					
GHz	50	100	200	400	800	
0.2	0.2/0.8	0.2/0.5				
0.5	0.6/3.6	0.5/2.0	0.2/0.5			
1.0		1.0/4.0	0.2/1.5	0.2/0.5	0.1/0.2	
2.0			0.5/3.0	0.3/1.0	0.1/0.5	
4.0				0.5/3.0	0.2/1.0	
8.0					0.5/3.0	

APPENDIX

Computer Programs for Reverberation Chamber Immunity Measurements

100! RE-STORE "ModeTune01" ! Original: 5 May 1984 G. Koepke (303) 497-5766 102 104 ! Revision: 21 Feb 1986, 09:20 106 ! This measurement routine will operate the REVERBERATION CHAMBER 108 110 ! using MODE TUNED techniques. The tuner is stepped in discrete steps 112 ! and measurements are performed at each step. In this version ALL 114 ! frequencies are measured at each tuner step before proceeding 116 ! to the next step. Both the case of susceptability (power supplied ! by a signal generator) and emissions (power supplied by EUT) can be 118 120 ! handled. This program will handle EUT emissions by not measuring 122 ! the net input power and recording the received power as detected 124 ! by the reference antenna. Duplicate measurements are required to ! inject an 'equivalent' (will be normalized later) power to set 125 128 ! up the same response using the transmit antenna as was measured 130 with the EUT only. This method will determine the total power 132 radiated by the EUT. 134 136 ! The program will also handle the case where the tuner is not stepped, 138 as in a TEM cell or ANECHOIC chamber where a single measurement 140 is needed. The data is condensed for this case. 142 144 Coupler, cable loss, and Fower meter head corrections are applied 146 immediately to the measured data. These computations must be verified 148 by examining program lines that begin with the line label 150 Apply_cal_data, merely execute the EDIT command as shown. 152 154 EDIT Apply_cal_data 156 158 The measurement data are saved on disk for processing. It may also 160 be tabulated as the measurement proceeds by toggling a print flag 162 that is shown at the start of each tuner step. 164 166 1-68 Features: 1) NBS multiprobe system 170 2) HP 436 and/or HP 438 power meters 3) HP 3456 or 3478 DVMs 172 174 4) HP 8566 Spectrum Analyzer (Fower only) 176 5) HP relay actuator for RF switching 178 6) Superior Electric Stepping motor control 180 7) Either of HF8660A or HF8672A signal source. 182 184 Current Configuration 186 188 Perform preliminary emissions experiments in the chamber. 190 192 Standard items: 1) Incident Power to transmit antenna 194 Reflected power from transmit antenna 196 3) Received power from reference antenna 198 200 Measure output of: 4) Any number of NBS probes via system. 202 [not used for emission tests] 204 206 208 210 212 214

216

```
218
220
         ***************** MAIN PROGRAM ******************
222
224
226
       OPTION BASE 1
228
       OUTPUT 2 USING "K,#"; "SCRAICH KEYX"
230
232
       CALL Wipe_clean
       GOSUB Dim_variables
234
                                ! Dimension all variables, set selected values.
236
       GOSUB Load_cal_data
                                ! Load all calibration data for pads & cables.
238 New measurement:!
       PRINTER IS CRT
240
242
       DISF CHR#(129)
       GOSUB Initial_values
244
                                ! Preset all parameters and access menu.
246
       GOSUB Sig_gen_subs
                                ! Load selected Signal Generator subs
248
                                  and selected coupler calibraton data.
250
       GOSUB Fillcalibration
                                  Fill lookup table for calibration values.
252
       GOSUB Do_measurements
                                ! <-- read it again
254
       GOSUB Die gracefully
                                ! Delete signal generator subs from memory
256
       PRINTER IS CRT
258
       DISP " ";TIME # (TIMEDATE);" ";DATE # (TIMEDATE);" .... FROGRAM FINISHED,";
       DISF "
260
               'CONTINUE' to repeat."
262
       FAUSE
264
       GOTO New_measurement
266
       STOP
268
270
         ****************** END of MAIN PROGRAM **************
272
274
         ////////////*** DIMENSION VARIABLES ***///////////////
276
278 Dim_variables:!
280
       COM /Parameters/ REAL Fstart, Fstop, Fstep
282
284
       COM /Parameters/ REAL Min_eut, Max_eut, Min_pwr, Max_pwr, Time_eut
286
       COM /Farameters/ INTEGER Low_dbm, High_dbm, Step_dbm
288
       COM /Farameters/ INTEGER Search_eut, Search_pwr, Re_run
290
       COM /Farameters/ 1NTEGER Begin_step, Total_steps, Total_meters
292
       COM /Farameters/ Run_id$[10],Measmt_id$[160],Time_date$[30]
       COM /Parameters/ Meter_defns#(40)[40],Operator_name#[28],Test_type#[20]
294
296
       COM /Parameters/ Coupler_id $[10], Generator_id $[10]
298
300
       COM /Frobe_system/ INTEGER Sys_size, Total_chans, Frobe_addr(30,3)
302
       CDM /Frobe_system/ INTEGER Top_probe,Fcal_pts,Fr_avgs
304
       COM /Probe_system/ INTEGER Probe_volts(30), Overrange(30)
306
       COM /Probe_system/ INTEGER Probe_zero(30).REAL Probe_v_m(30)
       COM /Probe_system/ REAL Amplitude_cal(11,3,5),Freq_cal(11,3,13,2)
308
310
       COM /Frobe_system/ REAL Readtime(30), Freq_crib(13,2)
312
314
       COM /Interrupts/ INTEGER Intr_prty
       COM /Motor_menu/ Motion_type $6101, Rev_rate, INTEGER Tuner_steps
316
       COM /Bugs/ INTEGER Bug1, Bug2, Bug3, Printer
318
       COM /Files/ Sourcedisk#[20],Outdisk#[20],Filename#[80]
320
322
       !..... Cable and etc. calibration files.....
324
326
328
       DIM Baddata_id $ (15)[40]
330
       INTEGER Calib items
332
334
       DIM Coup inc(205,2),Coup refl(205,2)
336
       INTEGER Inc_pts,Refl_pts
```

```
338
       REAL Couping, Couprefl
340
       DIM Cable6 1(180,2), Cable6_6(180,2), Cable4_2(180,2), Cable4_4(180,2)
342
       INTEGER Ca_ipts.Ca_apts.C4_2pts.C4_4pts
344
346
       REAL 06_110ss,06_610ss,04_210ss,04_410ss
349
350
       DlM Cableio 3(180,2), Cableio 5(180,2), Cable5 7(180,2)
       INTEGER 010 3pts,010 5pts,05 7pts
352
354
       REAL C10_31css,C10_51css,C5_71css
356
       DIM Cable_r4(80,2),Cable_r12(80,2)
358
360
       INTEGER Cr4pts, Cr12pts
362
       REAL Cr4loss, Cr12loss
364
       DIM Fad as6a(180,2), Fad_s6770(180,2), Fad_f5530(180,2)
366
348
       INTEGER Fada_pts,Fads_pts,Fadf_pts
370
       REAL Pada_loss, Pads_loss, Padf_loss
372
374
       DIM H_ict (77,2)
                         !Anzac Hybrid Junction
376
       INTEGER Jct_pts
       REAL Jct loss
378
380
382
       !.....Other useful variables.....
384
386
       DIM Cal_id $ [40], Pwr_id $ [2], Test $ [160]
388
       INTEGER Baddata, Dbm, Rf_on_off, Filesize, I, J, K, P
390
       INTEGER Valid, Ftotal, File20steps, Beginstep, Endstep
392
       INTEGER Frintflag, Fcount, Too hot, Frintflag2, Steps
394
       INTEGER Local_prty, Probe
396
398
       INTEGER Fp436a1,Fp436a2,Fp438a1,Fp438a2,Fsa8566b
400
       INTEGER Fv3456a1, Fv3456a2, Fv3478a1, Fr59306a
402
       REAL Z3456a1,Z3456a2,Z3478a1
404
       REAL V3456a1, V3456a2, V3478a1
406
408
       ! ..... we need these initial values .......
410
412
       Printer=701
       Sourcedisk*=":INTERNAL,4,0"
414
                                   ! or ":HP9133,700,0"
416
       Outdisk = ": INTERNAL, 4, 1"
418
       Intr_prty=6
420
       Local_prty=Intr_prty
422 Bugs: !
424
       Printflag=1
                           ! Frint all setup parameters and calibration values.
426
       Frintflag2=1
                           ! Print raw data if both Printflag and Printflag2
428
       Bug1=0
430
       Bug2=0
432
       Bug3=0
434
436
       RETURN
438
440
       ! /////////////****IN1TIALIZE VARIABLES & I/O****////////////
442
444 Initial_values:!
446
448
       ASSIGN @Motor TO 706
                                        Stepping motor
450
       ASSIGN @Fwr1 TD 709
                                     ! Fower meters HF436a
452
       ASSIGN @Fwr2 TO 710
454
       ASSIGN @Dual pwr1 TO 711
                                     ! Power meters HP438a
456
       ASSIGN @Dual_pwr2 TO 712
```

```
! Signal generator HP8660a or HP8672a
458
      ASSIGN @Sig gen TO 719
                               HP3456A Dvm.
      ASSIGN @Dvm1 TO 722
460
                               ! HP3456A Dvm.
     ASSIGN @Dym2 TO 723
462
                               ! HP3478A Dvm.
464
     ASSIGN @Dvm3 TO 724
                               ! NBS Multiprobe system
     ASSIGN @Gpib TO 12
466
      ASSIGN @Rly1 TO 717
                               ! HF relay actuator
468
      470
472
474
      Calib_items=15
                            ! 15 files for cables, coupler, and pad cals.
476
                            ! Read Multiprobe 3 times and average.
478
      Fr_avgs=3
      Motion_type*="STEP"
                            ! or "CONTINUOUS" for MODE STIRRING.
480
      Rev_rate=1.0
                            ! used only if MODE STIRRING operation.
482
484
      Rf_on_off=1
485
488
      CALL Measure menu
                                 ! Go and set up measurement parameters.
490
                                ! Turn on/off instruments as per menu
      GOSUB Configure_instr
      CALL Multiprobe_menu
492
                                ! Set up the 30 probe system.
494
     DISP CHR#(129)
496
      GOSUB Data_definition
                                ! Use above info to define data.
      GOSUB Die_gracefully
498
                                 ! To assure clean start.
                                 ! Initialize the Generator Level
500
      Dbm=Low dbm
                                 ! Initialize the motor control
502
      Tuner_steps=Total_steps
504
      !-----ALLOCATE THE RAW DATA MATRIX------
506
508
      Ftotal=INT((Fstop-Fstart)/Fstep)+1
      IF Test type#="OTHER (NO STEPS)" THEN
510
512
         File20steps=Ftotal
514
      FLSE
516
         File20steps=20*Ftotal
518
520
      ALLOCATE Rawdata(Total meters+Total chans+1,File20steps)
522
      524
     DISP "INSERT OUTPUT DATA DISK IN ";
526
528
      SELECT Outdisk*
      CASE ": INTERNAL, 4,0"
530
         DISF "RIGHT DRIVE, ";
532
      CASE ": INTERNAL, 4, 1"
534
         DISP "LEFT DRIVE, ";
536
538
      END SELECT
5.40
      DISP "and hit 'Continue-k5'."
542
      BEEF
544
      ON KEY 5 LABEL "Continue", Local_prty GOTO Datasaver
546 Zippity:GOTO Zippity
548 Datasaver: OFF KEY
550
    GOSUB Save configure
552
      IF Printer()CRT THEM
554
         FRINTER IS Frinter
556
         PRINT RPT#("_",80)
558
         FRINT
560
         PRINTER IS CRT
562
      END IF
      GOSUB Print_vitals
564
565
      DISP CHR#(12)
568
      RETURN
570
      572
574
576 Configure_instr:!
```

```
578
       ! ... Instrument read flags, if set the meter will be read ...
         Stepping motor controlled by Test_type$
580
          Signal generator HP8650a or HP8672a controlled by Test type*
582
584
         NBS Multiprobe system controlled by Total chans
       SELECT Test_type#
586
       CASE "MODE TUNE REGULAR"
588
590
          Fp436a1=0
                                      Power meter HP436a at addr 09
592
          Fp436a2=0
                                      Power meter HP436a at addr 10
                                      Power meter HP438a at addr 11
594
          Fp438a1=1
596
          Fp438a2=0
                                      Power meter HP438a at addr 12
                                      HP3456A Dym at addr 22
598
          Fv3456a1=0
600
                                      HP3456A Dvm at addr 23
          Fy3456a2=0
                                      HP3478A Dym at addr 24
602
          Fv3478a1=0
          En59306a=0
                                      HP relay actuator at addr 17
604
606
          Fsa8566b=1
                                      HP 8566 Spectrum Analyzer at addr 18
608
      CASE "MODE TUNE EMISSIONS"
610
          Fp436a1=0
                                      Power meter HP436a at addr 09
                                      Power meter HP436a at addr 10
612
          Fp436a2=0
614
          Fp438a1=0
                                      Power meter HP438a at addr 11
616
          Fp438a2=0
                                      Power meter HP438a at addr 12
618
          Fv3456a1=0
                                      HP3456A Dvm at addr 22
620
          Fv3456a2=0
                                      HP3456A Dym at addr 23
                                      HP3478A Dym at addr 24
622
          Fv3478a1=0
624
                                      HP relay actuator at addr 17
          Fr59306a=0
626
                                      HP 8566 Spectrum Analyzer at addr 18
          Fsa8566b=1
628
      CASE "OTHER (NO STEPS)"
630
          Fp436a1=0
                                    ! Power meter HP436a at addr 09
632
          Fp436a2=0
                                      Power meter HP435a at addr 10
634
          Fp438a1=1
                                      Power meter HP438a at addr 11
636
          Fp438a2=0
                                      Power meter HP438a at addr 12
638
          Fv3456a1=1
                                      HP3456A Dvm at addr 22
640
          Fy3456a2=0
                                      HP3456A Dvm at addr 23
642
                                      HP3478A Dvm at addr 24
                                   !
          Fv3478a1=0
644
          Er59306a=0
                                   ! HP relay actuator at addr 17
646
          Fsa8566b=0
                                   ! HP 8566 Spectrum Analyzer at addr 18
648
      END SELECT
650
652
      RETURN
654
656
        658
660 Data_definition:
                        ! Set up the definitions of each meter reading,
662
                        ! these are used later when processing
664
                        ! SO be sure these are correct.
666
                        ! The index corresponds to the Rawdata matrix row+1
668
                        ! Frequency is always in row 1
670
                        ! Meter 1 is in row 2, etc.
672
674
      SELECT Test_type#
676
      CASE "MODE TUNE REGULAR"
678
           Total_meters=3
680
          Meter defns≢(1)="Incident Power (Watts)"
682
          Meter_defns*(2)="Reflected Power(Watts)"
          Meter_defns$(3)="Recieved Power (Watts)"
684
686
       CASE "MODE TUNE EMISSIONS"
688
          Total_meters=1
          Meter_defns*(1)="Recieved Fower (Watts)"
690
692
       CASE "OTHER (NO STEPS)"
694
           Total_meters=3
696
           Meter_defns*(1)="Incident Power (Watts)"
```

```
Meter defns#(2)="Reflected Power(Watts)"
698
700
           Moter dofns*(3)="Probe Output (Volts)"
702
       END SELECT
704
       FOR F=1 TO Total_chans
706
708
           Test#="Amp # "%VAL$(Probe_addr(P,1))&", 5cm Probe # "
           Test#=Test#%VAL#(Frobe_addr(F,2))&"-"
710
712
           SELECT Probe addr (P.3)
714
           CASE 1
716
               Test#=Test#&"X"
           CASE 2
718
720
               Test=Test=&"Y"
722
           CASE 3
724
               Test#=Test#&"Z"
           CASE 4
726
728
               Test$=Test$&"Single"
730
           CASE ELSE
732
               Test #= Test #& "Error!"
734
           END SELECT
736
           IF LEN(Test#)>40 THEN
738
               REFE
               DISP "ERROR in probe definitions"
740
742
               PAUSE
744
               Test*=Test*[1,40]
746
           FLSE
748
               Meter_defns*(P+Total_meters)=Test*
750
           END IF
752
       NEXT P
754
       RETURN
756
758
       !//////////////////////////////****DIE GRACEFULLY****////////////////////////////
760
762 Die_gracefully: !
764
       IF Bug1 THEN
766
           PRINT TIME * (TIMEDATE);
768
           PRINT RPT$("<",15);" DIE GRACEFULLY ";RPT$(">",15)
770
       END IF
772
       ON ERROR GOTO Delet done1
774
       SELECT Generator_id$
776
       CASE "HP_8660A"
778
           DELSUB Set_freq,Set_dbm,FNDigit10$,FNDigit3$,FNRev$
780
       CASE "HF_8672A"
           DELSUB Set_freq,Set_dbm
782
784
       END SELECT
786 Delet_done1:
       OFF ERROR
788
       ON ERROR GOTO Delet_done2
790
792
       DEALLOCATE Rawdata(*), Adjust(*)
794 Delet_done2: !
796
       OFF ERROR
798
       RETURN
800
         802
804
806 Sig_gen_subs: !
808
       PRINTER IS CRT
       PRINT TABXY(1,18); RPT*("*",15);
810
812
       PRINT " LOAD SUB PROGRAMS & Coupler Calibrations ";RPT*("*",15)
814
       Filename#=Generator_id#%Sourcedisk#
815
       DISP " Put 'CALIBRATION DATA & SUB Program' disk in ";
```

```
SELEUT Sourcedisk*
818
      CASE ": INTERNAL, 4,0"
820
           DISP "RIGHT DRIVE, ";
822
824
       CASE ": INTERNAL, 4, 1"
826
           DISP "LEFT DRIVE, ";
828
       END SELECT
       DISP "hit 'Continue-k5'."
830
832
       BEEP
834
       ON KEY 5 LABEL "Continue", Local_prty GOTO Subloads
835
       LOOF
838
       END LOOP
840 Subloads: OFF KEY
       DISP CHR#(12)
842
       DISP " Signal Generator SUB PROGRAMS NOW LOADING "
844
846
       ON ERROR CALL Errortrap
848
       LOADSUB ALL FROM Filename#
       OFF ERROR
850
852
       DISP " Signal Generator SUB PROGRAMS LOADED "
854
       WAIT 1
856
858
860
862
       1F Printflag THEN PRINTER 1S Printer
864
       IF Printflag THEN PRINT "CALIBRATION DATA FOR THE FOLLOWING IS LOADED:"
       SELECT Coupler_id$
866
       CASE "HP_778D" ! 30 to 2000 MHz.
868
           Filename#="HP_778D_f"&Sourcedisk#
870
872
           CALL Enter_caldata(Filename*,Coup_inc(*),Cal_id*,Inc_pts)
874
           Baddata id#(1)=Cal_id#
876
           IF Printflag THEN PRINT Cal_id$
           Filename#="HP_778D_r"&Sourcedisk#
878
           CALL Enter_caldata(Filename*,Coup_refl(*),Cal_id*,Refl_pts)
880
882
           Baddata_id$(2)=Cal_id$
884
           IF Printflag THEN PRINT Cal_id$
886
       CASE "HP_11692D" ! 2 to 18 GHz
888
           Filename#="HF11692D_f"&Sourcedisk#
890
           CALL Enter_caldata(Filename*,Coup_inc(*),Cal_id*,Inc_pts)
892
           Baddata_id*(1)=Cal_id*
894
           IF Printflag THEN PRINT Cal_id$
896
           Filename#="HP11692D r"&Sourcedisk#
898
           CALL Enter_caldata(Filename*,Coup_refl(*),Cal_id*,Refl_pts)
900
           Baddata_id*(2)=Cal_id*
       IF Printflag THEN PRINT Cal_id  
CASE "CH_130_4" ! 1 to 30 MHz Anzac bi +directional
902
904
906
           Filename*="CH130_4_f1"&Sourcedisk*
908
           CALL Enter_caldata(Filename*,Coup_inc(*),Cal_id*,Inc_pts)
910
           Baddata_id*(1)=Cal_id*
           IF Printflag THEN PRINT Cal_id≢
912
914
           Filename#="CH130_4_r1"&Sourcedisk#
916
           CALL Enter caldata(Filename*, Coup_refl(*), Cal_id*, Refl_pts)
918
           Baddata_id≉(2)=Cal id≉
920
           IF Printflag THEN PRINT Cal_id$
922
       CASE ELSE
924
           PRINT "COUPLER CALIBRATION DATA ERROR....NOT DEFINED."
926
           BEER
928
           PAUSE
930
       END SELECT
932
934
936
```

```
938
       FRINT TABXY(1,18); FFT#(" ",80);
       RETURN
940
942
944
       945
948 Load cal_data: !
950
      PRINT TABXY(1,18);RPT#("*",20);" LOAD CALIBRATION DATA ";RPT#("*",20)
952
       DISP " Put 'CALIBRATION DATA & SUB Program' disk in ";
954
       SELECT Sourcedisks
956
       CASE ": INTERNAL, 4.0"
958
          DISP "RIGHT DRIVE, ";
960
       CASE ": INTERNAL, 4, 1"
962
          DISF "LEFT DRIVE, ";
964
       END SELECT
       DISP "hit 'Continue-k5'."
966
968
       BEEP
       ON KEY 5 LABEL "Continue", Local_prty GOTO Calloads
970
972
       LODE
974
       END LOOP
976 Calloads: OFF KEY
978
       DISP " Calibration DATA for Cables, Couplers, Fads, etc. now LOADING "
980
982
       !Install new calibration files here!
984
       986
       IF Printflag THEN PRINTER IS Printer
988
         Printflag THEN PRINT "CALIBRATION DATA FOR THE FOLLOWING IS LOADED:"
990
992
994
996
       Filename#="Cable6FT 1"&Sourcedisk#
978
       CALL Enter_caldata(Filename*,Cable6_1(*),Cal_id*,C6_1pts)
1000
      Baddata id*(3)=Cal id*
1002
      IF Frintflag THEN PRINT Cal_id$
1004
1006
      Filename#="Cable6FT_6"%Sourcedisk#
1008
       CALL Enter caldata(Filename*, Cable6 6(*), Cal id*, C6 6pts)
1010
      Baddata id$(4)=Cal id$
1012
      IF Frintflag THEN PRINT Cal_id$
1014
1016
      Filename*="Cable4FT 2"&Sourcedisk*
1018
      CALL Enter_caldata(Filename*,Cable4 2(*),Cal_id*,C4_2pts)
1020
      Baddata_id$(5)=Cal_id$
1022
       IF Printflag THEN PRINT Cal_id$
1024
1026
       Filename*="Cable4FT_4"&Sourcedisk*
       CALL Enter_caldata(Filename*,Cable4_4(*),Cal_id*,C4_4pts)
1028
1030
       Baddata_id*(6)=Cal_id*
1032
       IF Printflag THEN PRINT Cal_id#
1034
1036
       Filenames="Cable10F 3"&Sourcedisks
1038
      CALL Enter_caldata(Filename*,Cable10_3(*),Cal_id*,C10_3pts)
1040
       Baddata_id*(7)=Cal_id*
1042
       IF Printflag THEN PRINT Cal_id$
1044
1046
       Filename*="Cable10F 5"%Sourcedisk*
       CALL Enter_caldata(Filename*,Cable10_5(*),Cal_id*,C10_5pts)
1048
1050
       Baddata_id$(8)=Cal_id$
1052
       IF Printflag THEN PRINT Cal_id‡
1054
1056
       Filename#="Cable5FT_7"&Sourcedisk#
```

```
1058
       CALL Enter_caldsta(Filename*,CableS_7(*),Cal_id*,CS_7pts)
1060
       Baddata id$(9)=Cal_id$
       IF Printflag THEN PRINT Cal ids
1062
1064
      Filename#="FAD_S6770"&Sourcedisk#
1065
       CALL Enter_caldata(Filename*,Pad_s6770(*),Cal_id*,Pads_pts)
1048
       Baddata_id$(10)=Cal id$
1070
1072
      IF Printflag THEN PRINT Cal ids
1074
      Filename#="PAD_5530"&Sourcedisk#
1076
1078
       CALL Enter_caldata(Filename*, Pad_f5530(*), Cal_id*, Padf_pts)
1080
       Baddata id$(11)=Cal id$
1082
       IF Printflag THEN FRINT Cal id#
1084
1086
      Filename#="PdAS6A1466"&Sourcedisk#
      CALL Enter_caldata(Filename$,Fad_as6a(*),Cal_id$,Fada_pts)
1088
1090
      Baddata id$(12)=Cal_id$
1092
      IF Frintflag THEN PRINT Cal_id$
1094
      Filename#="ANZAC_JCT"&Sourcedisk#
1096
1098
      CALL Enter_caldata(Filename*,H_jct(*),Cal_id*,Jct_pts)
1100
      Baddata_id$(13)=Cal_id$
1102
       IF Frintflag THEN FRINT Cal ids
1104
1106
      Filename*="Roable4ft"&Sourcedisk*
1108
      CALL Enter_caldata(Filename*,Cable_r4(*),Cal_id*,Cr4pts)
1110
      Baddata id$(14)=Cal id$
1112
      IF Printflag THEN PRINT Cal ids
1114
      Filenames="Roable12ft"&Sourcedisks
1116
      CALL Enter_caldata(Filename*,Cable_r12(*),Cal_id*,Cr12pts)
1118
      Baddata id$(15)=Cal_id$
1120
1122
       IF Frintflag THEN FRINT Cal id$
1124
1126
       IF Printflag THEN
1128
          PRINT RPT#(" ".80)
          PRINT USING "4/"
1130
1132
      END IF
      DISF " Calibration DATA LOADED "
1134
1135
      WAIT 1
1138
      PRINTER IS CRT
1140
      CALL Wipe clean
1142
      RETURN
1144
1146
       1148
1150 Fillcalibration:
                        ! Determine the cable, coup? r and pad calibration
1152
                        ! values for each frequer.
1154
                        ! Save these in the adjust(*) file for use by the
1156
                        ! measurement routine.
1158
1160
       IF Bug1 THEN
1162
          PRINT TIME#(TIMEDATE);
1164
          PRINT RPT#("<",15);" FILL CALIBRATION MATRIX ";RPT#(">",15)
1166
       DISF "NOW Filling Calibration matrix."
1158
1170
       ALLOCATE Adjust(Ftotal, Calib_items)
1172
       Fcount=1
1174
      FOR Frequency=Fstart TO Fstop STEP Fstep
1176
          CALL Get_cal_value(Frequency,Coupinc,Coup_inc(*),Baddata,Inc_pts)
```

```
1178
           1F Baddata THEN
1180
                Cal id*=Baddata id*(1)
1187
                GOSUB Flagbaddata
1184
           END IF
1186
           Adjust (Fcount.1) = Coupinc
1188
1190
           CALL Get_cal_value(Frequency,Couprefl,Coup_refl(*),Baddata,Refl_pts)
1192
           IF Baddata THEN
               Cal_id#=Baddata_id#(2)
1194
1193
                GOSUB Flagbaddata
1198
           END 18
1200
           Adjust (Fcount, 2) = Coupref1
1202
1204
           CALL Get_cal_value(Frequency,C6_1loss,Cable6_1(*),Eaddata,C6_1pts)
1206
           IF Baddata THEN
1208
                Cal id#=Baddata id#(3)
1210
                GOSUB Flagbaddata
1212
           END IF
1214
           Adjust(Fcount,3)=C6_1loss
1216
1218
           CALL Get_cal_value(Frequency,C6_6loss,Cable6_6(*),Baddata,C6_6pts)
1220
           IF Baddata THEN
1222
                Cal id*=Baddata id*(4)
1224
                GOSUB Flagbaddata
1226
           END IF
1228
           Adjust (Fcount, 4) = C6_61 oss
1230
1232
           CALL Get cal value(Frequency,C4 2loss,Cable4 2(*),Baddata,C4_2pts)
1234
           IF Baddata THEN
1236
               Cal_id#=Baddata_id*(5)
1238
                GOSUB Flagbaddata
1240
           END IF
1242
           Adjust(Fcount,5)=C4 2loss
1244
1246
           CALL Get_cal_value(Frequency,C4_4loss,Cable4_4(*),Baddata,C4_4pts)
1248
           IF Baddata THEN
1250
                Cal_id = Baddata_id = (6)
1252
                GOSUB Flagbaddata
1254
           END IF
1256
           Adjust (Fcount, 6) = C4_41oss
1258
1260
           CALL Get_cal_value(Frequency,C10_3loss,Cable10_3(*),Baddata,C10_3pts)
1262
           IF Baddata THEN
1264
                Cal id#=Baddata id#(7)
1266
                GOSUB Flagbaddata
1268
           END IF
1270
           Adjust (Fcount, 7) = C10_31oss
1272
           CALL Get_cal_value(Frequency,C10_5loss,Cable10_5(*),Baddata,C10_5pts)
1274
1276
           IF Baddata THEN
1278
               Cal_id$=Baddata_id$(8)
                GOSUB Flagbaddata
1280
1282
           END 1F
1284
           Adjust(Fcount,8)=C10_5loss
1286
           CALL Get_cal_value(Frequency,C5_7loss,Cable5_7(*),Baddata,C5_7pts)
1288
1290
           IF Baddata THEN
1292
                Cal_id = Baddata_id + (9)
1294
                GOSUB Flagbaddata
1296
           END 1F
```

```
Adjust(Fcount,9)=C5 7loss
1298
1300
1302
           CALL Get cal value(Frequency, Pads loss, Pad s6770(*), Baddata, Pads pts)
1304
           IF Baddata THEN
1306
               Cal id$=Baddata id$(10)
1308
               GOSUB Flagbaddata
           END IF
1310
1312
           Adjust(Fcount, 10) = Pads_loss
1314
1316
           CALL Get_cal_value(Frequency,Padf_loss,Pad_f5530(*),Baddata,Padf_pts)
           IF Baddata THEN
1318
1320
               Cal_id*=Baddata_id*(11)
1322
               GOSUB Flagbaddata
1324
           END TE
1326
           Adjust(Fcount, 11) = Padf loss
1328
1330
           CALL Get cal value(Frequency, Pada loss, Pad as6a(*), Baddata, Pada pts)
1332
           IF Baddata THEN
               Cal_id = Baddata_id = (12)
1334
1336
               GOSUB Flagbaddata
1338
           END IF
1340
           Adjust (Fcount, 12) = Pada_loss
1342
1344
           CALL Get_cal_value(Frequency,Jct_loss,H_jct(*),Baddata,Jct_pts)
1346
           IF Baddata THEN
1348
               Cal_id#=Baddata_id#(13)
1350
               GOSUB Flagbaddata
1352
           END IF
1354
           Adjust(Fcount, 13) = Jct_loss
1356
1358
           CALL Get_cal_value(Frequency,Cr4loss,Cable_r4(*),Baddata,Cr4pts)
1360
           IF Baddata THEN
1362
               Cal_id*=Baddata_id*(14)
1364
               GOSUB Flagbaddata
1366
           END IF
1368
           Adjust (Fcount, 14) = Cr41 oss
1370
1372
           CALL Get_cal_value(Frequency, Cr12loss, Cable_r12(*), Baddata, Cr12pts)
1374
           IF Baddata THEN
1376
               Cal_id = Baddata_id = (15)
1378
               GOSUB Flagbaddata
1380
           END IF
1382
           Adjust (Fcount, 15) = Cr12loss
1384
1386
           Fcount=Fcount+1
1388
       NEXT Frequency
       DISP "NOW labulating calibration values."
1390
1392
       GOSUB Printcalvalues
1394
       DISP CHR#(12)
1396
       RETURN
1398
1400
         1402
1404 Flagbaddata:
                      !Inform the operator that there is wrong data
1406
                       !being brought back from Enter_cal_data
1408
1410
       PRINTER IS Printer
1412
       PRINT RPT#("*",5); " NO CAL DATA at ": Frequency:
       PRINT " MHz: ";Cal_id*
1414
1416
       BEEF!
```

```
1418
       PRINTER IS CRT
1420
       RETURN
1422
1424
        1425
1428 Printcalvalues:
                        !MAKE LIST OF CALIBRATION VALUES USED.
1430
1432
       PRINTER IS Printer
1434
       PRINT
1436
       PRINT RPT#("*",24); " CALIBRATION / LOSS VALUES (dB) "; RPT#("*",24)
1438
       PRINT
1440
1442
       !.....first half of the values.....
1444
1446
       PRINT "Frequency
                         Coupler
                                       ----- BLUE CABLES ----":
       PRINT "-
1448
       PRINT "
                        Fward
1450
                MHz
                               Refl
                                      6ft#1 6ft#6 4ft#2 4ft#4 10ft#3 ";
       PRINT "10ft#5
                     5ft#7"
1452
1454 Lossfmt1: IMAGE M5D.D, X, 2(MDD.DD, X), X, 2(MDD.DD, X), #
1456 Lossfmt2: IMAGE 5 (MDD.DD,X)
1458
       Fcount=1
1460
       FOR Frequency=Fstart TO Fstop STEP Fstep
1462
           Coupinc=10*LGT(Adjust(Fcount,1))
                                                      !Coupler incident
1464
           Couprefl=10*LGT(Adjust(Fcount,2))
                                                      !Coupler reflected
1466
           C6_1loss=10*LGT(Adjust(Fcount,3))
                                                      !6 foot BLUE cable #1
1468
           C6_6loss=10*LGT(Adjust(Fcount,4))
                                                      !6 foot BLUE cable #6
1470
           C4_2loss=10*LGT(Adjust(Fcount,5))
                                                      !4 foot BLUE cable #2
1472
           C4_4loss=10*LGT(Adjust(Fcount,6))
                                                      !4 foot BLUE cable #4
1474
           C10_3loss=10*LGT(Adjust(Fcount,7))
                                                      !10 foot BLUE cable #3
1476
           C10_5less=10*LGT(Adjust(Fcount,8))
                                                      !10 foot BLUE cable #5
1478
           C5_7loss=10*LGT(Adjust(Fcount,9))
                                                      !4 foot BLUE cable #4
1480
           FRINT USING Lossfmt1; Frequency, Coupinc, Couprefl, C6_1loss, C6_6loss
1482
           PRINT USING Lossfmt2;C4_2loss,C4_4loss,C10_3loss,C10_5loss,C5_7loss
1484
           Fcount=Fcount+1
1486
       NEXT Frequency
       PRINT RPT#("-",80)
1488
1490
       PRINT
1492
1494
       !.....last half of the values..........
1476
1498
       PRINT "Frequency $6770 F5530
                                       ASA6A
                                               HJct
                                                       Semi-Rigid"
       PRINT "
1500
                                                       4ft
                         pad
                                pad
                                         pad
                                               loss
1502 Lossfmt3: IMAGE M5D.D, X, 2(MDD.DD, X), X, MDD.DD, X, #
1504 Lossfmt4: IMAGE 3(MDD.DD,X)
1506
       Fcount=1
1508
       FOR Frequency=Fstart TO Fstop STEP Fstep
1510
           Pads_Ioss=10*LGT(Adjust(Fcount,10))
                                                     !Weinschel S6770 10dB pad
                                                     !Weinschel F5530 10dB pad
1512
           Padf_loss=10*LGT(Adjust(Fcount,11))
                                                     !Weinschel AS6A-1466 10dB
1514
           Pada_loss=10*LGT(Adjust(Fcount,12))
1516
           Jct_loss=10*LGT(Adjust(Fcount,13))
                                                     !Anzac Hybrid Junction
1518
                                                    ! 4ft Rigid coax
           Cr4loss=10*LGT(Adjust(Fcount,14))
1520
           Cr12loss=10*LGT(Adjust(Fcount,15))
                                                    ! 12ft Rigid coax
           PRINT USING Lossfmt3; Frequency, Pads_loss, Padf_loss, Pada_loss
1522
1524
           PRINT USING Lossfmt4; Jct_loss, Cr41oss, Cr12loss
           Fcount=Fcount+1
1526
       NEXT Frequency
1528
1530
       PRINT RPT#("*",80)
1532
       PRINT
1534
       PRINTER IS CRT
1536
       RETURN
```

```
1538
      1540
1542
                     !Get all calibration data for this
1544 Extract_caldata:
                     !frequency.
1544
1548
1550
      ! Calibration data for all cables, probes. & power heads.
1552
1554
      Pwrmtrcali=FNPwrmtrcali((Frequency))
                                              !18 GHz HEAD.
1556
     Pwrmtrcal2=FNPwrmtrcal2((Frequency))
                                             126 GHz HEAD.
1558
1560
     Coupinc=Adjust(Fcount.1)
                                         !Coupler incident
1562
     Couprefl=Adjust(Fcount,2)
                                         !Coupler reflected
1564
     C6 1loss=Adjust(Fcount,3)
                                         !6 foot BLUE cable #1
1566
      C6_6loss=Adjust(Fcount,4)
                                         !6 foot BLUE cable #6 rcvr.
                                         !4 foot BLUE cable #2
1568
      C4_2loss=Adjust(Fcount,5)
1570
      C4_41oss=Adjust(Fcount,6)
                                         !4 foot BLUE cable #4
                                         !10 foot BLUE cable #3
1572
      C10_3loss=Adjust(Fcount,7)
     C10_5loss=Adjust(Fcount,8)
                                         !10 foot BLUE cable #5
1574
1576
     C5 7loss=Adjust(Fcount.9)
                                         !5 foot ELUE cable #7
1578
     Fads_loss=Adjust(Fcount,10)
                                         !Weinschel S6770 10dB pad
1580
      Fadf loss=Adjust(Fcount,11)
                                         !Weinschel F5530 10dB pad
1582
      Fada loss=Adjust(Fcount,12)
                                         !Weinschel ASSA-1466 10dB
1584
      Jct_loss=Adjust(Fcount,13)
                                         !Anzac Hybrid Junction
1584
      Cr4loss=Adjust(Fcount,14)
                                        !4ft Semi-rigid coax lines
1588
      Cr12loss=Adjust(Fcount,15)
                                        !12ft Semi-rigid coax lines
1590
      RETURN
1592
1594
      1596
1598 Flip printflao: !
     DISP " Toggle PRINTING of measurement data. "
1600
1.502
      Waittime=TIMEDATE
1604
      LOOP
1606
         IF Frintflao2 THEN
1608
             ON KEY O LABEL "Print is ON", Local prty GOSUB Toggleprint
1610
         ELSE
1612
             ON KEY O LABEL "Print is OFF", Local prty GOSUB Toggleprint
1514
         END IF
1615
     EXIT IF TIMEDATE-Waittime>4
1618 END LOOP
1620
      DISP CHR$(12)
1622
      OFF KEY
1624
      RETURN
1626
      ! ........
1628 Toggleprint:!
1630
     IF Frintflag2 THEN
1632
         Printflag2=0
      ELSE
1634
1636
         Frintflag2=1
      END IF
1638
1540
      RETURN
1642
1644
      1444
1648 Do_measurements:!
1650
     IF Bug1 THEN
1652
1654
        PRINT TIME#(TIMEDATE);RPT#("<",20);" DD MEASUREMENTS ";RPT#(">",20)
1655
      END IF
```

```
1658
      REMOTE @Sig_gen
1660
      IF Fp436a1 DR Fp436a2 THEN CALL Menu_pwr436a ! Set up 436A pwr mtrs
1662
1654
      IF Fv3456a1 THEN CALL Setdvm_3456a(@Dvm1)
      IF Fv3456a2 THEN CALL Setdvm 3456a(@Dvm2)
1666
      IF Fv3478a1 THEN CALL Setdvm_3478a(@Dvm3)
1668
      1F Fsa8566b THEN CALL Spec_alzr_setup(@Spec_alzr)
1670
      IF Test_type$<>"OTHER (NO STERS)" THEN
1672
1674
          CALL Initializemotor(@Motor)
          CALL Zeromotor (@Motor)
1676
1678
      END IF
1680
      IF Test_type$="MODE TUNE EMISSIONS" THEN
          CALL Set_dbm(-140,0,@Sig_gen)
                                        !EUT is the source
1682
1684
      END IF
1686
      !
1488
1690
      Column=1
1692
      Beginstep=Begin_step
1694
      Steps=Begin_step-1
1696
      REFEAT
              ! measurements for all steps or once for non-stepping type.
1698
          Steps=Steps+1
1700
1702
          IF (Steps-1)/40.=INT((Steps-1)/40.) OR Steps=Begin_step THEN
1704
              IF Test_type = "MODE TUNE EMISSIONS" THEN
1706
                  GOSUB Flip_printflag ! includes WAIT action.
1708
1710
                 GOSUB Read_zero_field ! for all enabled instruments.
1712
              END IF
1714
          ELSE
1716
             GOSUB Flip printflag
1718
          END IF
1720
1722
            ..... ZERD Readings or WAIT complete ......
1724
1726
          IF Total_chans<1 THEN ! Print single header for all frequencies
£728
              IF Printflag AND Printflag2 THEN GOSUB Print_headinfo
1730
          END IF
1732
          IF Test_type$<>"MODE TUNE EMISSIONS" THEN ! Restore power
1734
              CALL Set_freq((Frequency),@Sig_gen)
1736
              CALL Set_dbm(Dbm,1,@Sig_gen)
1738
          END IF
1740
1742
            1744
1746
          Fcount=1
1748
          FOR Frequency=Fstart TD Fstop STEP Fstep
1750
              DISP CHR $ (129)
1752
              DISP " TIME: "; TIME $ (TIMEDATE);
              IF Test_type #= "OTHER (NO STEPS)" THEN
1754
1756
                 DISF " Now Testing: FREQUENCY =";Frequency; " MHz. "
1758
                 DISP " TUNER STEP "; Steps; ", FREQUENCY ="; Frequency; " MHz. "
1760
1762
              END IF
              GOSUB Extract_caldata
1764
                                     ! Get all calibration data for this
1766
                                     ! frequency.
1768
              Rawdata(1,Column)=Frequency
              IF Test_type $<> "MODE TUNE EMISSIONS" THEN
1770
1772
                  CALL Set freq((Frequency),@Sig_gen)
1774
              END IF
1776
              IF Search_eut THEN GOSUB Level_eut_out
```

```
IF Search pwr THEN GOSUB Level_net_input
1778
1780
              GOSUB Read meters
                                     ! Read all enabled instruments.
                                     ! See Configure_instr for changes.
1782
                                      Calibration data is applied there
1784
1796
                                     ! via Apply_cal_data.
1788
1790
               1792
1794 Fill_data_file: ! **** Make sure this assignment matches defns.
              SELECT Test_type #
1796
1798
              CASE "MODE TUNE REGULAR"
1800
                 Rawdata(2,Column)=P1
1802
                 Rawdata(3,Column)=P2
1804
                 Rawdata(4,Column)=Sa_pwr
1806
              CASE "MODE TUNE EMISSIONS"
                 Rawdata(1,Column)=Sa_pwr
1808
1810
              CASE "OTHER (NO STEPS)"
1812
                 Rawdata(2,Column)=P1
1814
                 Rawdata (3, Column) =P2
1815
                 Rawdata(4,Column)=V1
1818
              END SELECT
1820
1822
              IF Total_chans>0 THEN
                 FOR P=Total_meters+2 TO Total_chans+Total_meters+1
1824
1826
                     Rawdata(P,Column)=Frobe_v_m(F-Total_meters-1)
                 NEXT P
1828
1830
              END IF
1832
              !
1834
              IF Printflag AND Printflag2 THEN
                  IF Total_chans>0 THEN GOSUB Print_headinfo
1836
1838
                  GOSUB Printrawdata
1840
              END IF
1842
              Column=Column+1
1844
              Fcount=Fcount+1
1846
          NEXT Frequency
1848
1850
            ..... ALL frequencies measured .......
1852
1854
          IF Test_type$="OTHER (NO STEPS)" THEN
              GOSUB Save_data
1856
1858
          ELSE
1860
              FRINT TIME*(TIMEDATE);" ...Step number";Steps;" completed...."
              IF (Column+Ftotal-1>File20steps) OR (Steps=Tuner_steps) THEN
1842
1864
                 Endstep=Steps
1855
                  GOSUB Save data
1868
                  Beginstep=Endstep+1
1870
                  Column=1
1872
                 MAT Rawdata= Rawdata*(0.)
1874
              END IF
1876
              CALL Movemotor (@Motor)
1878
          END IF
1880
      UNTIL Steps>=Tuner_steps OR Test_type$="OTHER (NO STEPS)"
1882
      IF Test_type≢<>"MODE TUNE EMISSIONS" THEN
1884
1886
          CALL Set dbm(-140,0,@Sig_gen)
1888
      END IF
1890
      LOCAL 7
1892
      RETURN ! ALL Measurements complete.
1894
1896
```

```
1898
1900 Read zero_field:
       FRINT TIME $ (TIMEDATE); " Step number"; Steps; ", zero meters."
1902
1904
1906
          ..... Measure all zero field values .......
1908
1910
       CALL Set_dbm(-140,0,@Sig_gen)
1912
       IF Fp436a1 AND Fp436a2 THEN
1914
            CALL Zero_pwr_mtrs(@Sig_gen,@Pwr1,@Pwr2)
1915
       FLSE
1918
            IF Fp436a1 THEN CALL Zero_pwr_mtrs(@Sig_gen,@Fwr1)
1920
            IF Fp436a2 THEN CALL Zero_pwr_mtrs(@Sig_gen,@Pwr2)
1922
       END IF
       IF Fp438a1 THEN
1924
1926
            Ab#="AB"
1928
            CALL Zero_438a(@Dual_pwr1,Ab*)
1930
       END IF
1932
       IF Fp438a2 THEN
1934
            Ab*="A"
1936
           CALL Zero_438a(@Dual_pwr2,Ab*)
       END IF
1938
       IF Fv3456a1 THEN CALL Readdvm(Z3456a1,@Dvm1)
IF Fv3456a2 THEN CALL Readdvm(Z3456a2,@Dvm2)
IF Fv3478a1 THEN CALL Readdvm(Z3478a1,@Dvm3)
1940
1942
1944
1946
       IF Bug1 THEN
1948
           PRINTER IS Printer
1950
           PRINT "Zeros DVM1="; Z3456a1;", DVM2="; Z3456a2;" DVM3="; Z3478a1
1952
            PRINTER IS CRT
1954
       END IF
1956
1958
       ! Fill Frobe_volts(30) using Probe_addr(*) and Total_chans
1960
1962
       IF Total_chans>0 THEN
1964
           MAT Probe_zero= (0)
1966
           CALL Read_probes(@Gpio)
1968
           MAT Probe_zero= Probe_volts
1970
            IF MAX(Frobe_zero(*))>10 OR MIN(Probe_zero(*))<-10 THEN
                FRINT TIME $ (TIMEDATE); " ... ";
1972
1974
                PRINT " WARNING ... Check Multiprobe zero ******* "
1976
            END IF
1978
       END IF
1980
       RETURN
1982
1984
         //////// APPLY CALIBRATION TO MEASUREMENT DATA ///////
1985
1988 Apply_cal_data:! For listing of valid variable names
1990
                      see Extract_caldata. Values are in ratio form.
1992 Cal power 1 2:!
1994
       P1=Power1*Coupinc*Pwrmtrcal1*Padf loss/(C10_3loss*Fads_loss)
1995
       F2=Power2*Coupref1*Pwrmtrcal1*C10_3loss*Pads_loss
1998
       RETURN
2000
2002 Cal_power_3_4:!
2004
       P3=Power3
2005
       F4=Fower4
2008
       RETURN
2010
        !----
2012 Cal_power_5:!
2014
      P5=Power5
2016
       RETURN
```

```
2018
2020 Cal_power_6:!
2022
     F6=Fower6
2024
2026
2028 Cal_sa_power:!
2030
      Sa_pwr=Sa_power*C10_5loss*C4_2loss*C4_4loss
2032
2034
2036
2038
      2040
2042 Read meters:! Control module for all instrument reads.
      Too hot=0
2046
      F1=0
2048
     F2=0
2050
      Checktime=TIMEDATE
2052
2054 Hp438a_1:!
2056
     IF Fp438a1 THEN
2058
          GOSUB Power_1_2
                            ! HP438A both channels
2060
                            ! returns Power1, Fower2 (watts)
          IF Too hot THEN GOTO Read_meters
2062
          GOSUB Cal_power_1_2! correct for losses and return F1,F2
2066 Min_power: IF (F1-F2) < Min_pwr THEN
2068
              BEEF
2070
              FRINTER IS Frinter
              FRINT TIME $ (TIMEDATE); " "
2072
2074
              PRINT RFT$("-",40);" INFUT IS TOO LOW! "
2076
              FRINT "Raw P1="; Fower1; " ** Cal P1="; P1
              PRINT "Raw P2="; Power2; " ** Cal P2="; P2
2078
2080
              PRINT "Net input power (P1-P2) =";P1-P2
              PRINT RPT$("-",40)
2082
2084
              PRINTER IS CRT
2086
              GOSUB Adjust power
2088
              GOTO Read_meters
2090
          END IF
     END IF
2092
2094
2096 Hp438a_2:!
2098 IF Fp438a2 THEN
2100
          60SUB Fower_3_4
                          ! Set for channel A (Fower3) only, Power4=0
                           ! returns Fower3, Fower4 (watts)
2102
2104
          IF Too hot THEN GOTO Read meters
2106
          GOSUB Cal_power_3_4 ! correct for losses and return F3,F4
      END IF
2108
2110
2112 Hp436a_1:!
2114
      1F Fp436a1 THEN
          GOSUB Power_5 ! HP 436A
2116
2118
                         ! returns Fower5
          IF Too hot THEN GOTO Read_meters
2120
2122
          GOSUB Cal_power_5 ! correct for losses and return P5
2124
     END IF
2126
      1-----
2128 Hp436a_2:!
2130 IF Fp436a2 THEN
         GOSUB Fower_6 ! HF 436A
2132
2134
                         ! returns Power6
2136
          IF Too_hot THEN GOTO Read_meters
```

```
GOSUB Cal_power_6 ! correct for losses and return P6
2138
2140 END IF
2142 !-----
2144 Nbs_probes:!
2150
2152 Wait_loop:!
2154
     LOOP
2156
      EXIT IF (TIMEDATE-Checktime)>Time_eut
      END LOOP
2158
2160
2162 Hp3456a_1:! ====== EUT connected to this dvm. =======
2164 IF Fv3456a1 THEN
2166
         CALL Readdvm(Volt1,@Dvm1) ! HP digital voltmeter
         V1=Volt1+Z3456a1
2168
                                   ! returns Volts (DC volts)
2170
                                    ! correct for zero, yields V1
         IF V1>Max_eut THEN
2172
              PRINTER IS Printer
2174
              PRINT TIME * (TIMEDATE); "...DVM1 error / EUT overload. "
2176
              PRINT "Set max="; Max_eut;", Reading="; Volt1;", Zero="; Z3456a1;
2178
              PRINT ", Adjusted reading=";V1
2180
              PRINTER IS CRT
2182
2184
              GOSUB Reduce_power
2186
              GOTO Read_meters
2188
          END IF
2190 END IF
2192
      1-----
2194 Hp3456a 2:!
2196 IF Fv3456a2 THEN
2198
         CALL Readdvm(Volt2,@Dvm2) ! HP digital voltmeter
2200
                                     ! returns Volts (DC volts)
2202
          V2=Volt2-Z3456a2
                                    ! correct for zero, yields V2
2204 END IF
2206
     1-----
2208 Hp3478a 1:!
2210 IF Fv3478a1 THEN
2212
         CALL Readdvm(Volt3,@Dvm3) ! HP digital voltmeter
                              ! returns Volts (DC volts)
2214
                                   ! correct for zero, yields V3
2216
          V3=Volt3-Z3478a1
2218
      END IF
2220
      1-----
2222 Hp59306a_relay:! An example of using the relay to measure multiple
2224
                  ! quantities. This requires additional instrument to
2226
                   ! actually do the measurements, as the relay only controls
                   ! a system of rf switches.
2228
2230
                   ! In this example, turn off the Spectrum Analyzer flag.
2232
     IF Fr59306a THEN
2234
          OUTFUT @Rly1; "A123" ! Toggle to SUM port
2236
          CALL Spec_alzr_start(Frequency,@Spec_alzr)
          CALL Spec_alzr_read(Sa_power,Frequency,@Spec_alzr)
2238
2240
          Sa_power=10.0^((Sa_power/10.0)-3.0) ! dBm -> watts
2242
          GOSUB Cal sa power! correct for losses and return Sa_pwn
2244
          Sum_power=Sa_pwr
2246
2248
          QUIPUT @Rly1; "B123" ! Toggle to DIFFERENCE port
2250
          CALL Spec_alzr_start(Frequency,@Spec_alzr)
          CALL Spec_alzr_read(Sa_power,Frequency,@Spec_alzr)
Sa_power=10.0^((Sa_power/10.0)-3.0) ! dBm -> watts
2252
2254
2256
          GOSUB Cal_sa_power! correct for losses and return Sa_pwr
```

```
2258
         Diff_power=Sa_pwr
2260
      END 1F
                 ______
2262
      1 -----
2264 Spec_alzr:!
      IF Fsa8566b AND NOT Fr59306a THEN ! HF8566B Spectrum analyzer
2266
2268
          CALL Spec_alzr_start(Frequency,@Spec_alzr)
          CALL Spec_alzr_read(Sa_power,Frequency,@Spec_alzr)
2270
          Sa_power=10.0^((Sa_power/10.0)-3.0) ! dBm -> watts
2272
2274
          GOSUB Cal_sa_power! correct for losses and return Sa_pwr
      END IF
2276
      RETURN
2278
2280
2282
       ! //////// Read instrument subroutines ///////////////////
2284
2286
       ! ..... HP 438A Dual power meter - @Dual_pwr1 ......
2288
2290 Power_1_2:Ab*="AB"
2292
      CALL Read_dual_pwr(Ab*,Apower,Epower,Too_hot,Valid,@Dual_pwr1)
2294
      IF Too hot THEN
2296
          GOSUB Reduce power
2298
          RETURN
2300
     END IF
2302
      IF NOT Valid AND NOT Too hot THEN
2304
          GOSUB Dual_pwr_error
2306
          GOTO Power_1_2
                             ! Repeat measurements
2308
     END IF
      IF Ab$="AB" OR Ab$="A" THEN
2310
          IF Apower<0. THEN Apower=0.
2312
                                         ! Fower detectors are not sources
2314
          Power1=Apower
2316
      END IF
      IF Ab#="AB" OR Ab#="B" THEN
2318
2320
          IF Bpower<0. THEN Bpower=0.
2322
          Fower2=Bpower
2324
      END IF
2326
      RETURN
2328
2330
       ! ..... HP 438A Dual power meter - @Dual pwr2 ......
2332
2334 Fower_3_4:Ab*="A" ! or Ab*="AB" if you want both channels.
2336
      CALL Read_dual_pwr(Ab*,Apower,Bpower,Too_hot,Valid,@Dual_pwr2)
2338
      IF Too hot THEN
          GOSUB Reduce_power
2340
2342
          RETURN
2344
      END IF
2346
      IF NOT Valid AND NOT Too hot THEN
2348
          GOSUB Dual_pwr_error
          GDTO Power_3_4 ! Repeat measurements
2350
2352
      END IF
2354
      IF Ab=="AB" OR Ab=="A" THEN
2356
          IF Apower(0. THEN Apower=0. ! Power detectors are not sources
2358
          Fower3=Apower
2360
      END IF
2362
      IF Ab#="AB" OR Ab#="B" THEN
2364
          IF Bpower<0. THEN Bpower=0.
2366
          Power4=Bpower
      END IF
2368
2370
      RETURN
2372
2374
       ! ..... HF 436A Power meter - @Fwr1 ......
2376
```

```
2378 Power_5: ! Pwr_id#="P1"
      CALL Read_pwr_meter(Power, Pwr_id$, Valid, @Pwr1, @Sig_gen)
2380
      IF NOT Valid THEN
2382
2384
          DISP "ERROR IN 436a POWER METER 1"
2386
          BEEP
          PAUSE
2388
2390
          Power=0.
2392
          Too_hot=1
2394
      END IF
2396
      IF Power(0. THEN Power=0.
2398
      Power5=Power
2400
      RETURN
2402
2404
        ..... HP 436A Power meter - @Pwr2 ........
2406
2408 Fower_6: ! Fwr_id*="P6"
2410
      CALL Read_pwr_meter(Power, Pwr_id*, Valid, @Pwr2, @Sig_gen)
      IF NOT Valid THEN
2412
2414
          DISP "ERROR IN 436a POWER METER 2"
2416
          BEEF
          PAUSE
2418
2420
          Fower=0.
2422
          Too_hot=1
      END IF
2424
2426
      IF Power<0. THEN Power=0.
2428
      Fower 6=Fower
2430
      RETURN
2432
2434
        ..... NBS Multiprobe system ........
2436
2438 Probe_rd:!
2440
      IF Total_chans>0 THEN
2442
          CALL Read probes (@Gpio)
2444
          Too_hot=0
          FOR F=1 TO Total_chans
2446
2448
              Too_hot=Too_hot OR Overrange(F)
2450
          NEXT P
2452
          IF Too hot THEN
2454
              GOSUB Reduce_power
2456
          ELSE
2458
                                              ! Amplitude correction.
              CALL Apply_probe_cal(Frequency)
2460
                                              ! Frequency correction.
2462
          END IF
2464
      END IF
2466
      RETURN
2468
2470
      2472
2474 Level_eut_out:! This routine will adjust the signal generator
2476
                   output to cause the EUT output (tied to @Dvm1)
2478
                  ! to fall within the limits of Min_eut and Max_eut.
2480
                  ! All the while within the bounds of Low_dbm to High_dbm.
2482
2484
2486
2488
2490
2492
      RETURN
2494
2496
```

```
2498
2500 Level_net_input:! This routine will adjust the signal generator
2502
                   ! output to cause the corrected net input power
                   ! to fall within the limits of Min_pwr and Max_pwr
2504
2506
                   ! All the while within the bounds of Low dbm to High dbm.
2508
2510
2512
2514
2516
2518
     RETURN
2520
      2522
2524
2526 Adjust_power:
      DISP " INPUT power is too low. Check system (Continue-k5) "
2528
2530
      ON KEY 5 LABEL "Continue", Local_prty GOTO Tryitagain
      ON KEY O LABEL "Reduce Power", Local_prty GOSUB Reduce_power ON KEY 2 LABEL "Increase Pwr", Local_prty GOSUB Increase_pwr
2532
2534
2536
2538 Myself:ON KEY 6 LABEL " dBm="&VAL$(Dbm),Local prty GOTO Myself
2540
     END LOOP
2542 Tryitagain: OFF KEY
      DISF CHR$(12)
2544
2546
     RETURN
2548
      !
2550 Reduce_power:!
2552
      Dbm=Dbm-1
      CALL Set_dbm(Dbm,1,@Sig_gen)
2554
2556
     IF Printflag THEN
          FRINTER IS Printer
2558
2560
          PRINT TIME # (TIMEDATE); ": Step#"; Steps; "Freq="; Frequency;
2562
          PRINT RPT#("*",10);" NEW GENERATOR LEVEL =";Dbm
2564
         FRINTER IS CRT
2566
      END IF
2568
      RETURN
2570
     .....
2572 Increase_pwr:!
2574
     Dbm=Dbm+1
     CALL Set_dbm(Dbm,1,@Sig_gen)
2576
2578
      IF Printflag THEN
2580
          PRINTER IS Printer
2582
          PRINT TIME $ (TIMEDATE); ": Step#"; Steps; "Freq="; Frequency;
2584
          FRINT RFT$("*",10);" NEW GENERATOR LEVEL =";Dbm
2584
          PRINTER IS CRT
2588
      END IF
2590
     RETURN
2592
25.94
      2596
2598 Dual_pwr_error:!
2600
     CALL Set_dbm(-140,0,@Sig_gen) ! Kill power
2602
      IF Frintflag THEN
2604
          PRINTER IS Frinter
2606
          PRINT TIME # (TIMEDATE);": Step#": Steps;" Freq="; Frequency;
          PRINT RPT≇("*",10);" ERROR IN DUAL FOWER METER !!!"
2608
2610
         PRINTER IS CRT
2612
      END IF
      DISP " ERROR in DUAL POWER METER, correct and 'CONTINUE' "
2614
2616
      BEEP
```

```
PAUSE
2618
      CALL Set dbm(Dbm,1,@Sig gen)
2620
                                     ! Restore power.
2622
      RETURN
2624
       ! ////////*****PRINT HEADING FOR RAW DATA****/////////////
2626
2628
2630 Print headinfo: ! Values in order of insertion into matrix.
      PRINTER IS Printer
2632
2634
      PRINT
      SELECT Test_type$
2636
2638
      CASE "MODE TUNE REGULAR"
          PRINT RPT#("-",15); "Identifier: "; Run id#;
2640
          PRINT " STEP NUMBER ";Steps;RPT#("-",15)
2642
          PRINT "FREQUENCY
                                       REFL-PWR ":
2644
                             INC-PWR
          PRINT "
2646
                    REC-PWR"
          PRINT "
2648
                    MHz
                              Watts
                                         Watts ":
2650
          PRINT "
                     Watts"
      CASE "MODE TUNE EMISSIONS"
2652
2654
          PRINT RPT#("-",15);"Identifier: ";Run_id#;
          PRINT " STEF NUMBER "; Steps; RFT # ("-", 15)
2656
          PRINT "FREQUENCY
2658
                             REC-PWR "
          PRINT "
2660
                    MHz
                              Watts
      CASE "OTHER (NO STEPS)"
2662
          FRINT RPT#("=",80)
2664
2666
          PRINT "Measurement Identifier: ";Run_id$
          PRINT Measmt_id#
2668
2670
          PRINT RPT$(".",80)
2672
          FRINT
          PRINT "FREQUENCY
                                       REFL-FWR ";
2674
                             INC-FWR
          FRINT "
2676
                    Frobe OUTPUT"
          PRINT "
2678
                                         Watts ";
                    MHz
                              Watts
          PRINT "
2680
                     Volts"
2682
      END SELECT
2684
      PRINTER IS CRT
2686
      RETURN
2688
2690
        2692
2694 Printrawdata:!
2676 Rawimage1: IMAGE 6D.2D, X, #
2698 Rawimage2: IMAGE #, MD. DDDE, X
2700
      PRINTER IS Printer
2702
      PRINT USING Rawimage1; Rawdata(1, Column)
2704
      FOR I=2 TO Total meters+1
2706
          PRINT USING Rawimage2; Rawdata(I, Column)
      NEXT I
2708
2710
      PRINT
2712
      IF Total_chans>1 THEN GOSUB Print_probes
      PRINTER IS CRT
2714
2716
      RETURN
2718
2720
       2722
2724 Print_probes:!
      PRINT RPT#(" ",80)
2726
2728
      PRINT "Amp# Probe# Axis Zero Output Orng?";
      PRINT "
2730
                  VoIts/mtr"
2732 Pimage1:IMAGE M3D,2X,M3D,3X,A,3X,2(M4D,2X),MDD,2X,M4D.2D
      FOR I=1 TO Total_chans
2734
2736
          Amp=Probe_addr(I,1)
```

```
2738
          Probe=Probe_addr(I,2)
          SELECT Probe_addr(I,3)
2740
2742
          CASE 1
2744
              A \times \Phi = {}^{n} X^{n}
2745
          CASE 2
              Ax *= "Y"
2748
          CASE 3
2750
              Ax#="Z"
2752
2754
          CASE 4
              Ax$="S"
2756
2758
          CASE ELSE
              Ax 事= "E"
2760
2762
          END SELECT
2764
          Org=Overrange(I)
2766
          Zer=Probe_zero(I)
2768
          A_d=Probe_volts(1)
2770
          V_m=Rawdata(Total_meters+I+1,Column)
2772
          PRINT USING Pimage1; Amp, Probe, Ax#, Zer, A_d, Org, V_m
2774
      NEXT I
2776
      PRINT RPT#("_",80)
2778
      FRINT
2780
      PRINT
2782
      RETURN
2784
2786
       2788
2790 Save_data:!
2792
      ON ERROR CALL Errortrap
2794
      IF Test_type$="OTHER (NO STEPS)" THEN
2795
          Filename#=Run_id#
2798
      FLSE
2800
          Filename#="S"&VAL#(Beginstep)&" "&VAL#(Endstep)
      END IF
2802
2804
      Filename#=Filename#&Outdisk#
      Filesize=INT((((Total_chans+Total_meters+1)*File20steps*8)/255)+2
2806
2808
      CREATE BDAT Filename$,Filesize,256
2810
      ASSIGN @Datapath TO Filenames
2812
      OUTPUT @Datapath:Rawdata(*)
2814
      ASSIGN @Datapath TO *
2816
      PRINTER IS Printer
2818
      IF Test_type = "OTHER (NO STEPS)" THEN
2820
          PRINT TIME*(TIMEDATE);" .... DATA STORED ON FILE ";Filename*
2822
      ELSE
2824
          Filename$="S"&VAL*(Beginstep)&"_"&VAL*(Endstep)
2825
          PRINT TIME # (TIMEDATE); "......DATA FOR STEPS ";
2828
          PRINT Beginstep; "TO "; Endstep; "STORED ON FILE "; Filename*
2830
      END IF
2832
      OFF ERROR
2834
      PRINTER IS CRT
2836
      RETURN
2838
2840
      2842
2844 Save_configure:!
      ON ERROR CALL Errortrap
2844
2848
      Filename*="CONFIGURE"
2850
      Filename#=Filename#&Dutdisk#
2852
      CREATE BDAT Filenames, 16,256
2854
      ASSIGN @Datapath TO Filename$
2856
      OUTPUT @Datapath;Run_id#
```

```
OUTPUT @Datapath; Measmt_id≇
2858
2860
       OUTPUT @Datapath: Time dates
2862
       GUTPUT @Datapath; Fstart, Fstop, Fstep
       IF Test_type≇="OTHER (NO STEPS)" THEN
2864
           OUTPUT @Datapath; 1
2855
2868
       ELSE
2870
           OUTFUT @Datapath; Total_steps
       END IF
2872
2874
       OUTPUT @Datapath; Total _meters
2876
       OUTPUT @Datapath; Total_chans
       OUTPUT @Datapath; Probe_addr(*)
2878
2880
       OUTPUT @Datapath; Meter_defns $ (*)
2882
       OUTPUT @Datapath; File20steps
2884
       ASSIGN @Datapath TC *
2886
      OFF ERROR
2888
      PRINTER IS CRT
2890
      PRINT TIME # (TIMEDATE); " CONFIGURE file for "; Run_id #; " SAVED."
2892
2894
2896
       2898
2900 Print_vitals: !
2902
      FRINTER IS Frinter
       PRINT RPT#("_",80)
2904
      PRINT "THIS DATA SET IS IDENTIFIED AS:
2906
                                               ";Run_id$
      PRINT "MEASUREMENT date: "; Time_date$
2908
2910
      PRINT RPT# ("-".80)
2912
       PRINT Measmt_id$
2914
      PRINT RPT#("-",80)
       PRINT "FREQUENCIES "; Fstart; " TO ";
2916
      PRINT Fstop; " STEP "; Fstep; " MHz."
2918
2920
       PRINT "THE TUNER STEPFED "; Total_steps; " increments."
2922
      PRINT Total_meters;" PWR METERS and DVMs, along with "; Total_chans;
       FRINT " channels of the NBS multiprobe system."
2924
2926
       PRINT
2928
       PRINT "The measured DATA are defined as follows:"
2930
      PRINT RPT#("-",80)
2932
       PRINT "Data slot #
                             Description";
2934
       FRINT TAB(40); "Data slot #
                                    Description"
2936
       J=INT(((Total_chans+Total_meters)/2)+1)
2938
      IF J<>((Total_chans+Total_meters)/2)+1 THEN J=J+1
2940
      I = 1
2942
       K=J
                  ! J is starting point of second column.
2944
       REPEAT
          PRINT I;": ";Meter_defns$(I);
IF K<=Total_chans+Total_meters THEN
2945
2948
2950
              PRINT TAB(40); K; ": "; Meter_defns $ (K)
2952
           ELSE
2954
               PRINT
           END IF
2956
2958
           I = I + 1
2960
           k(=k(+1
2952
       UNTIL I>=J
       PRINT RPT#("-",80)
2964
      FRINT USING "2/"
2966
2968
      PRINTER IS CRT
2970
      RETURN
2972
        2974
2976
```

```
2978
       EMD
2980
2982
            *************************
2984
2986
       SUB Measure_menu
2988 Measure_menu:
                       Original: 5 May 1984
2990
                       Revision: 24 Jan 1986
2992
2994
2996
                       This routine will facilitate setting up the
2998
                      ! measurement by providing MENU access to the
3000
                       parameters.
3002
3004
           COM /Parameters/ REAL Fstart, Fstop, Fstep
3006
           COM /Parameters/ REAL Min_eut, Max_eut, Min_pwr, Max_pwr, Time_eut
3008
           COM /Farameters/ INTEGER Low_dbm, High_dbm, Step_dbm
           COM /Farameters/ INTEGER Search_eut, Search_pwr, Re_run
COM /Farameters/ INTEGER Begin_step, Total_steps, Total_meters
3010
3012
           COM /Farameters/ Run_id*, Measmt_id*, Time_date*
3014
           COM /Parameters/ Meter_defns*(*),Operator_name*.Test_type$
3016
3018
           COM /Parameters/ Coupler_id*, Generator_id*
3020
3022
           COM /Files/ Sourcedisk*, Outdisk*, Filename*
3024
           COM /Bugs/ INTEGER Bug1, Bug2, Bug3, Printer
3026
           COM /Interrupts/ INTEGER Intr prty
3028
           DIM Test#[160]
3030
            INTEGER Local_prty,I,Ascii_num,Interrupted
3032
           Local_prty=Intr_prty
3034
           DISP CHR#(129)
3036
           IF Frinter=701 THEN
3038
                ON TIMEOUT 7,.5 GOSUB Printerdead
3040
3042
                PRINT
3044
                OFF TIMEOUT
3046
           END IF
3048
3050
           IF Bug1 THEN
3052
                PRINT TIME * (TIMEDATE); RPT * ("*", 10); " ENTER Measure menu"
3054
3056
           CALL Wipe_clean
                                         ! Clear the CRT.
3058
           PRINTER IS CRT
3060
           GOSUB Write backqnd
                                         ! Format menu area.
3062
           IF NOT Re run THEN
3064
                GOSUB Start_up_values
                                         ! Initial values
3066
                                         ! Put initial values in menu
3068
           ELSE
3070
                GOSUB Fill_in_values
                                         ! Put current values in menu
3072
           END IF
3074
3076
            !Make any changes or corrections.
3078
3080
           GOSUB Define keys
3082
           PRINT (ABXY(56,3); DATE $ (TIMEDATE)
3084
           LOOP
3086
                IF Interrupted THEN GOSUB Define_keys
3088
                ON KEY 5 LABEL "EXIT ARESET", Local_prty GOTO Exit_sub ON KEY 15, Local_prty GOSUB Start_up_values
3090
3092
                PRINT TABXY(69,3); TIME*(TIMEDATE)
3094
           END LOOP
3096 Exit sub:!
```

```
2978
       END
2980
         2982
2984
2986
       SUB Measure menu
2988 Measure_menu:
                      Original: 5 May 1984
2990
2992
                      Revision: 24 Jan 1986
2994
2996
                      This routine will facilitate setting up the
2998
                      measurement by providing MENU access to the
3000
                      parameters.
3002
           COM /Parameters/ REAL Fstart, Fstop, Fstep
3004
3006
           COM /Parameters/ REAL Min_eut, Max_eut, Min_pwr, Max_pwr, Time_eut
3008
           COM /Farameters/ INTEGER Low_dbm, High_dbm, Step_dbm
3010
           COM /Farameters/ INTEGER Search_eut, Search_pwr, Re_run
3012
           COM /Parameters/ INTEGER Begin_step, Total_steps, Total_meters
           COM /Farameters/ Run_id*, Measmt_id*, Time_date*
3014
3016
           COM /Parameters/ Meter_defns#(*), Operator_name#. Test_type#
3018
           COM /Farameters/ Coupler_id*, Generator_id*
3020
           COM /Files/ Sourcedisk*, Outdisk*, Filename*
3022
           COM /Bugs/ INTEGER Bug1, Bug2, Bug3, Printer
3024
3026
           COM /Interrupts/ INTEGER Intr_prty
3028
           DIM Test#[160]
3030
           INTEGER Local_prty,I,Ascii_num,Interrupted
3032
           Local_prty=Intr_prty
3034
           DISP CHR#(129)
3036
3038
           IF Frinter=701 THEN
3040
               ON TIMEOUT 7,.5 GOSUB Printerdead
3042
               PRINT
3044
               OFF TIMEOUT
3046
           END IF
3048
3050
           IF Bug1 THEN
3052
               PRINT TIME#(TIMEDATE); RPT#("*",10); " ENTER Measure_menu"
3054
           END IF
3056
           CALL Wipe_clean
                                       ! Clear the CRT.
3058
           PRINTER IS CRT
3060
           GOSUB Write backgnd
                                       ! Format menu area.
3062
           IF NOT Re run THEN
3064
               GOSUB Start_up_values
                                       ! Initial values
3066
                                       ! Put initial values in menu
3068
           FLSE
3070
                                       ! Put current values in menu
               GOSUB Fill in values
3072
           END IF
3074
3076
           !Make any changes or corrections.
3078
3080
           GOSUB Define keys
3082
           PRINT TABXY(56,3); DATE*(TIMEDATE)
3084
           LOOP
3086
               IF Interrupted THEN GOSUB Define_keys
3088
               ON KEY 5 LABEL "EXIT
                                       ARESET", Local prty GOTO Exit sub
               ON KEY 15, Local_prty GOSUB Start_up_values
3090
3092
               PRINT TABXY(69,3); TIME $ (TIMEDATE)
3094
           END LOOP
3096 Exit sub:!
```

```
3098
           OFF KEY
3100
           DISP CHR#(12)
           Time dates=TIMEs(TIMEDATE)&", "&DATEs(TIMEDATE)
3102
3104
           PRINTER IS Printer
           IF Printer=701 THEN DUMP ALPHA
3106
3108
           IF Bual THEN
              PRINT TIME $ (TIMEDATE); RPT$ ("*",10); " EXIT Measure menu"
3110
3112
           END IF
          CALL Wipe_clean
3114
          PRINTER IS CRT
3116
3118
           SUBEXIT
3120
            3122
3124
3126 Define_keys:!
3128
          OFF KEY
3130
           Interrupted=0
3132
           DISP RPT#("<",15);"
                                 SELECT PARAMETER TO CHANGE ":
           DISP " (^shift key)
                                 ";RPT*(">",15)
3134
          ON KEY O LABEL "TEST ID ATYPE", Local_prty GOSUB Change_eutid
3136
3138
           ON KEY 10.Local prty GOSUB Change type
3140
          ON KEY 1 LABEL "FREQs ^SIG GEN", Local prty GOSUB Change freqs
3142
           ON KEY 11, Local prty GOSUB Change levels
3144
          ON KEY 2 LABEL "INPUT MIN ^MAX", Local_prty GOSUB Change_pwr_min
3146
          ON KEY 12, Local_prty GOSUB Change_pwr_max
3148
          ON KEY 3 LABEL "LEVEL "SEARCH", Local_prty GOSUB Change_search_p
          ON KEY 13, Local_prty GOSUB Change_search_e
3150
          ON KEY 4 LABEL "EUT MIN
3152
                                   ^MAX",Local_prty GOSUB Change_eut_min
3154
          ON KEY 14, Local_prty GOSUB Change_eut_max
          ON KEY 6 LABEL "DATE
                                   ^NAME",Local_prty GOSUB Call_time_date
3156
3158
          ON KEY 16, Local prty GOSUB Enter name
3160
          ON KEY 7 LABEL "Response Time", Local prty GOSUB Change response
3162
           IF Test_type $<> "OTHER (NO STEPS)" THEN
3164
              ON KEY 8 LABEL "TUNER
                                      ^BEGIN",Local_prty GOSUB Change_tuner
3166
               ON KEY 18, Local_prty GOSUB Change_beginstp
3168
3170
           ON KEY 9 LABEL "DISK DRIVE", Local prty GOSUB Change diskdriv
3172
          RETURN
3174
3176
            3178
3180 Start_up_values: ! Define the initial values for all parameters.
3182
           Re_run=1
3184
          Fstart=100
                             ! Frequency range in MHz.
3186
          Fstop=1000
3188
          Fstep=50
3190
          Low_dbm=-40
                             ! Signal generator level in dBm.
3192
          High_dbm=-10
3194
          Step dbm=1
3196
          Search eut=0
                             ! O= DO NOT auto search for EUT response
3198
                              ! 1 = DO
3200
                             ! 0= DO NOT auto level the Net Input power.
          Search_pwr=0
3202
                               1= DO
3204
          Min_eut=1.0E-6
                               Minimum output of EUT in volts.
3206
           Max_eut=10.0
                              Maximum output of EUT in volts.
3208
          Min pwr=1.0E-6
                             ! Minimum net input power in watts.
          Max_pwr=10.0
                              ! Maximum net input power in watts.
3210
3212
                              ! Time for EUT to respond after field is set.
           Time eut≔0.
3214
           Begin_step=1
3216
          Total_steps=200
                             !An integer division of 3200
```

```
3218
           Test type$="MODE TUNE REGULAR"
                                          !or "MODE TUNE EMISSIONS"
                                           !or "OTHER (NO STEPS)"
3220
3222
           Run id*="Run 1"
3224
           Operator_name#="Galen Koepke"
3226
           Measmt_id*="Evaluate the susceptability of a device"
           Measmt_id≉=Measmt_id≢&" in the NBS Reverberating Chamber."
3228
           Coupler_id#="HP_778D"
3230
           Generator_id$="HP_8660A"
3232
3234
3236
           GOSUB Fill_in_values ! Put initial values in menu
          RETURN
3238
3240
3242
           3244
3246 Fill_in_values:!
3248
3250
          GOSUB Change_eutid ! Fill in the values
3252
           GOSUB Frint_type
          GOSUB Frint_freqs
3254
3254
           GOSUB Frint_gen_level
3258
          GOSUB Print_beginstp
3240
          GOSUB Frint_tuner
3262
          GOSUB Frint name
3264
          GOSUB Frint_search_p
3266
          GOSUB Frint_search_e
3248
          GOSUB Print_eut_min
3270
          GOSUB Print_eut_max
          GOSUB Print_pwr_min
3272
3274
           GOSUB Print_pwr_max
3276
           GOSUB Frint_wait
3278
          GOSUB Print_diskdrive
3280
          RETURN
3282
3284
           3286
3288 Write_backgnd: ! Format menu area.
3290
           PRINT CHR#(129)
3292
           PRINT TABXY(16,1); " ***MEASUREMENT PARAMETERS -
                                                                           *** "
3294
           PRINT TABXY(1,3);" TEST ID:
           PRINT TABXY(23,3);" TYPE: "
3296
           FRINT TABXY(41,3); " DATE / TIME: "
3298
3300
3302
          PRINT CHR#(132);
3304
           PRINT TABXY(1,5); RFT#(" ",160)
3306
           FRINT CHR#(129);
3308
           PRINT TARXY(1,8); " FREQUENCY (MHz) "
3310
3312
           PRINT TABXY(1,9);" LOW: "
           PRINT TABXY(1,10);" HIGH: "
3314
           PRINT TABXY(1,11);" STEP: "
3316
3318
           PRINT TABXY(21,8); " GENERATOR (dDm) "
3320
3322
           PRINT TABXY(41,8);" NET INPUT POWER (W) "
           PRINT TABXY(41,5);"
3324
                                MIN: "
                                 MAX: "
3326
           PRINT TABXY(41,10);"
          PRIN: TABXY(41,11); "LEVEL INPUT? "PRINT TABXY(65.8); "EUT RESPONSE PRINT TABXY(65.11); "SEARCH? "
3328
3330
3332
3334
          PRINT CHR$(128);
3336
          PRINT TABXY(62,9);"..."
```

```
3338
         PRINT TABXY (62,10); "..."
          FRINT CHR#(129);
3340
          PRINT TABXY(1,13); " ESTIMATE BUT RESPONSE TIME "
3342
         PRINT TABXY(41,13); " seconds. "; RPT*(" ",30)
3344
         PRINT TABXY(41,15); " COUPLER/SIG GEN: ";
3346
          PRINT TABXY(1,15); " BEGIN TUNER POSITION "
3348
         PRINT TABXY(29,15); " END "
3350
          PRIN! TABXY(1,17); " OFERATOR: ";
3352
          PRINT TABXY(41,17); " OUTPUT DISK DRIVE: "
3354
          PRINT CHR# (128)
3356
3358
          RETURN
3360
3362
           3364
3366 Printerdead: DISP "NO PRINTER at HPIB address 701 !!":
3348
          DISP " Please correct situation and hit 'CONTINUE'"
3370
          BEEF
3372
         PAUSE
3374
         RETURN
3376
3378
          3380
3382 Call_time_date:Interrupted=1
3384
         CALL Time_date
3386
          RETURN
3388
3390
           3392
3394 Change_eut_max:Interrupted=1
          IF Test_type#="MODE TUNE EMISSIONS" THEN RETURN
3398
          DISP " ENTER the UPPER LIMIT for the EUT RESPONSE (your units) ";
          INFUT Max_eut
3400
          IF Max_eut<Min_eut THEN
3402
3404
             Min eut=Max eut
3406
             GOSUB Print eut min
3408
         END IF
3410 Frint_eut_max:!
3412
          PRINT TABXY(66,10);
          IF Test_type$="MODE TUNE EMISSIONS" THEN
3414
             FRINT USING "9A"; " Not used"
3416
3418
         EL SE
3420
             FRINT USING "MD.2DE"; Max_eut
3422
         END IF
3424
         RETURN
3426
           3428
3430
3432 Change_eut min:Interrupted=1
3434
          IF NOT Search_eut OR Test_type≢="MODE TUNE EMISSIONS" THEN RETURN
          DISP " ENTER the LOWER LIMIT for the EUT RESPONSE (your units) ";
3436
         INPUT Min_eut
3438
3440
         IF Min_eut>Max_eut THEN Min_eut=Max_eut
3442 Print_eut_min:!
3444
         FRINT TABXY (66,9);
3446
          IF NOT Search_eut OR Test_type$="MODE TUNE EMISSIONS" THEN
3448
             FRINT USING "9A"; " Not used"
3450
             PRINT USING "MD. 2DE"; Min eut
3452
3454
         END IF
3456
         RETURN
```

```
3458
           3460
3452
3464 Change_pwr_max:Interrupted=1
3466
         IF NOT Search pwr OR Test_type≇="MODE TUNE EMISSIONS" THEN RETURN
          DISP " ENTER the Maximum NET Input Power ";
3468
3470
          INPUT Max_pwr
          IF Max_pwr<0. THEN Max_pwr=0.
3472
3474
          IF Max_pwr<Min_pwr THEN
3476
             Min_pwr=Max_pwr
             GOSUB Print_pwr_min
3478
3480
         END IF
3482 Print_pwr_max:!
         PRINT TABXY(50,10);
3484
3486
          IF NOT Search_pwr OR Test_type = "MODE TUNE EMISSIONS" THEN
             PRINT USING "9A": " Not used"
3488
3490
3492
             PRINT USING "MD. 2DE"; Max_pwr
3494
         END IF
3496
          RETURN
3498
          3500
3502
3504 Change_pwr_min:Interrupted=1
3506
          IF Test type#="MODE TUNE EMISSIONS" THEN RETURN
3508
          DISP " ENTER the Minimum NET Input Power ";
          INPUT Min_pwr
3510
          IF Min_pwr<0. THEN Min_pwr=0.
3512
3514
          IF Min_pwr>Max_pwr THEN Min_pwr=Max_pwr
3516 Print_pwr_min:!
3518
          PRINT TABXY(50,9);
          IF Test_type$="MODE TUNE EMISSIONS" THEN
3520
3522
             PRINT USING "9A"; " Not used"
3524
3526
             PRINT USING "MD. 2DE"; Min pwr
3528
          END IF
3530
          RETURN
3532
          3534
3534
3538 Change_search_p:!
3540
          IF Search_pwr=0 AND Search_eut=0 THEN
3542
             Search_pwr=1
3544
          ELSE
3546
             Search_pwr=0
3548
          END IF
3550
          GOSUB Print_gen_level
          GOSUB Print_pwr_max
3552
3554 Print_search_p:!
3556
          PRINT TABXY (56,11);
          IF Test_type$="MODE TUNE EMISSIONS" THEN
3558
3560
             PRINT "OFF"
3562
          ELSE
3564
             IF Search pwr THEN
3566
                 PRINT "ON "
3548
             ELSE
                 PRINT "DEF"
3570
3572
             END IF
3574
         END IF
          RETURN
3576
```

```
3578
3580
            3582
3564 Change search e:!
          IF Search_eut=0 AND Search_pwr=0 THEN
3586
3588
              Search_eut=1
3570
          ELSE
3592
              Search_eut=0
          END IF
3594
3596
          605UB Print_gen_level
          GOSUB Print_eut_min
3598
3600 Print_search_e:!
3602
          PRINT TABXY (75,11);
          IF Test_type = "MODE TUNE EMISSIONS" THEN
3604
              PRINT "OFF"
3606
3608
          ELSE
3610
              IF Search eut THEN
                  PRINT "DN "
3612
3614
              ELSE
                 FRINT "OFF"
3616
3618
              END IF
3620
          FND IF
3622
          RETURN
3624
3626
           3628
3630 Change_type:!
3632
          Interrupted=1
3634
          OFF KEY
3636
          DISP " SELECT MEASUREMENT TYPE. "
3638
          ON KEY O LABEL "Source = ANT", Local_prty+1 GOTO Source_ant
          ON KEY 2 LABEL "Source = EUT", Local_prty+1 GOTO Source_eut
3640
          ON KEY 4 LABEL "NO TUNER STF", Local prty+1 GOTO Notunerstep
3642
3644
          LOOP
          END LOOP
3645
3648 Source ant:! Regular MODE TUNED TESTS with transmitting antenna
3650
          Test types="MODE TUNE REGULAR"
3652
          Measmt_id$="Evaluate the susceptability of a device"
3654
          Measmt_id#=Measmt_id#&" in the NBS Reverberating Chamber."
3656
          GOSUB Print_eutid
3658
          GOTO New type
3660 Source_eut:! Emissions using MODE TUNED sequence, EUT is source
          Test_type#="MODE TUNE EMISSIONS"
3662
3664
          Measmt_id$="Measure the radiated emissions of a device"
3666
          Measmt_id#=Measmt_id#&" in the NBS Reverberating Chamber."
3669
          GOSUB Print eutid
3670
          GOTO New_type
3672 Notunerstep: ! Other measurements that require no TUNER stepping
3674
          Test type#="OTHER (NO STEPS)"
3676
          Measmt_id="Measure the response of a device to a field"
3678
          Measmt_id#=Measmt_id#&" in the NBS 1.2 meter TEM CELL."
3680
          GOSUB Print_eutid
3682 New_type:OFF KEY
3684
          ! Update all the menu items affected by TYFE change.
3686
          GOSUB Frint_gen_leveI
3688
          GOSUB Print_beginstp
3690
          GOSUB Print_tuner
3692
          GOSUB Print_search_e
3694
          GOSUB Frint_search_p
3696
          GOSUB Print_gen_id
```

```
3698
          GOSUB Frint_pwr_min
          GOSUB Print_pwr_max
3700
3702
          GOSUB Frint_eut_min
          GOSUB Print_eut_max
3704
3706 Print_type:!
          PRINT CHR# (129);
3708
3710
          FRINT TABXY(45,1);
3712
          SELECT Test_type$
          CASE "MODE TUNE REGULAR", "MODE TUNE EMISSIONS"
3714
3716
              FRINT "MODE TUNED TESTS";
          CASE "OTHER (NO STEPS)"
3718
3720
              PRINT "TEM CELL TESTS
3722
          CASE ELSE
3724
              PRINT "??????????????;
3726
          END SELECT
3728
          PRINT CHR# (128);
3730
          PRINT TABXY(31,3);
3732
          SELECT Test_type *
3734
          CASE "MODE TUNE REGULAR"
3736
              PRINT "REGULAR
          CASE "MODE TUNE EMISSIONS"
3738
              FRINT "EMISSIONS"
3740
3742
          CASE "OTHER (NO STEPS)"
3744
             PRINT "OTHER
3746
          CASE ELSE
              PRINT "?????????"
3748
3750
          END SELECT
3752
          RETURN
3754
3756
            3758
3760 Change_beginstp:Interrupted=1
          IF Test_type$="OTHER (NO STEPS)" THEN GOTO Frint_beginstp
3762
          DISP " ENTER THE BEGINNING TUNER STEP NUMBER ";
3764
3766
          INFUT Begin step
3768
          IF Begin_step>Total_steps THEN Begin_step=Total_steps
3770 Print beginstp:!
3772
          FRINT TABXY(24,15);
3774
          IF Test_type$<>"OTHER (NO STEPS)" THEN
3776
              FRINT USING "4D"; Begin_step
3778
          ELSE
3780
              FRINT USING "4A"; "N/A "
3782
          END IF
3784
          RETURN
3786
          3788
3790
3792 Change_tuner:!
3794
          IF Test type≉="OTHER (NO STEPS)" THEN GOTO Print_tuner
3796
          SELECT Total_steps
3798
          CASE 3200
              Total_steps=100
2800
3802
          DASE 1600
3804
              Total_steps=3200
3806
          CASE 800
3808
              Total_steps=1600
3810
          CASE 400
3812
              Total_steps=800
          CASE 200
3814
3816
              Total_steps=400
```

```
3818
          CASE 100
3820
              Total steps=200
3822
          CASE ELSE
3824
              Total_steps=400
          END SELECT
3826
3828 Print tuner:!
          PRINT TABXY(35,15):
3830
          IF Test_type $<>"OTHER (NO STEPS)" THEN
3832
              FRINT USING "4D"; Total_steps
3834
          ELSE
3836
3838
              PRINT USING "4A": "N/A "
          END IF
3840
3842
          IF Begin_step>Total_steps THEN
3844
              Begin_step=Total_steps
              GOSUB Print_beginstp
3844
3848
          END IF
          RETURN
3850
3852
            3854
3854
3858 Change_eutid:Interrupted=1
          DISP " ENTER the TEST ID# (LEGAL FILE NAME) ":
3840
3862
          OUTPUT 2 USING "K,#";Run_id$
3854
          LINPUT Test#
          IF LEN(Test*)=0 THEN Change eutid
3866
3868
          IF LEN(Test*)>10 THEN
3870
              BEEF'
3872
              DISP " ERROR in NAME ENTRY--700 MANY CHARACTERS, TRY AGAIN. "
              WAIT 1.8
3874
3876
              OUTPUT 2 USING "K,#";Filename≉
3878
              GOTO Change_eutid
3880
          END IF
3882
          FOR I=1 TO LEN(Test*)
              Ascii_num=NUM(Test≇[I])
3884
3886
              SELECT Ascii_num
3888
              CASE 65 TO 90,95,97 TO 122,48 TO 57
3890
                  !Allowed characters
              CASE ELSE
3892
3894
                  REFE
3894
                  DISP "ERROR in NAME ENTRY--ILLEGAL CHARACTERS, TRY AGAIN."
3898
                  WAIT 1.8
3900
                  GOTO Change eutid
3902
              END SELECT
3904
          NEXT I
3906
          Run_id#=Test#
3908
3910
          DISP " DESCRIPTION of the EUT and PURPOSE for test?? (<2 lines) ";
          OUTPUT 2 USING "K,#"; Measmt_id*
3912
3914
          LINPUT Measmt_id$
3916 Print_eutid:!
          PRINT TABXY(12,3); RFT#(" ",10)
3918
3920
          PRINT TABXY(12,3); Run_ids
3922
          PRINT CHR*(132);
          PRINT TABXY(1,5); RPT#(" ",160)
3924
3926
          PRINT TABXY(1,5); Measmt_id*
3928
          PRINT CHR$(128);
3930
          RETURN
3932
3934
            3936
```

```
3938 Enter_freq_er: !
3940
           DISF " ERROR in numeric entry or ILLEGAL value. "
3942
           REFE
3944
           WAIT 1.8
3946 Change fregs: Interrupted=1
           DISP " ENTER Start, Stop, Step frequencies (MHz). ";
3948
           DISP "[Ranges: 1-30, 30-2000, 2000-18000]";
3950
3952
           LINFUT Test$
3954
           ON ERROR GOTO Enter_freq_er
3956
           Fstart=VAL (Test*)
           Fstop=VAL(Test*[POS(Test*,",")+1])
3958
           Test*=Test*[POS(Test*,",")+1,LEN(Test*)]
3960
           Fstep=VAL(Test $[POS(Test *, ", ") +1])
3962
3964
           OFF ERROR
           IF Fstop<Fstart THEN GOTO Enter_freq_er
3966
           Fstart=MAX(MIN(Fstart, 18000), 1)
3968
3970
           Fstop=MAX(MIN(Fstop, 18000), 1)
3972
           Fstep=MAX(MIN(Fstep,18000),.01)
3974
           SELECT Fstart+(Fstop-Fstart)/2
                                             !Mid point in the range of freq.
3976
                         ! Set limits to 1-30 range
           CASE <=30
3978
               IF Fstop>30 THEN Fstop=30
3980
               Generator_id = "HP_8660A"
3982
               Coupler_ids="CH_130_4"
3984
                        ! Set limits to 30-2000 range
           CASE <=2000
               IF Fstart<30 THEN Fstart=30
3986
3988
               IF Fstop>2000 THEN Fstop=2000
3990
               Coupler id≉="HP 778D"
3992
               Generator_id$="HF_8560A"
3994
           CASE >=2000
                        ! Set limits to 2000-18000 range
3996
               IF Fstart<2000 THEN Fstart=2000
3998
               Coupler_id = "HP_11692D"
4000
               Generator_id$="HF_8672A"
4002
           END SELECT
4004 Print_freqs: !
           PRINT TABXY(9,9);
4006
4008
           PRINT USING "5D.2D"; Fstart
           PRINT TABXY(9,10);
4010
4012
           FRINT USING "5D.2D"; Fstop
4014
           FRINT TABXY(9,11);
           FRINT USING "5D.2D"; Fstep
4016
4018 Frint_gen_id:!
4020
           PRINT TABXY(59,15); RPT*(" ",21);
           IF Test_type#="MODE TUNE EMISSIONS" THEN
4022
4024
               PRINT TABXY(59,15); "Not used"
4026
           ELSE
4028
               PRINT TABXY(59,15);Coupler_id*;"/";Generator_id*
4030
           END IF
4032
           RETURN
4034
           4036
4038
4040 Change_levels:Interrupted=1
           IF Test_type‡="MODE TUNE EMISSIONS" THEN RETURN
4042
4044
           IF Search_eut OR Search_pwr THEN
4046
               DISP "ENTER the LOW, HIGH, STEP Signal generator LEVEL (dBm) ";
               DISF " ...integers only! ";
4048
4050
               INFUT Low_dbm, High_dbm, Step_dbm
               IF Low_dbm>High_dbm THEN Low_dbm=High_dbm ! capped by high_dbm
4052
4054
               IF Step_dbm<1 THEN Step_dbm=1
4056
           ELSE
```

```
DISP " ENTER Signal generator LEVEL (dBm) ";
4058
               DISP " ...integers only! ";
4040
4062
               INPUT Low_dbm
               IF High_dbm<Low_dbm THEN High_dbm=Low_dbm ! capped by low_dbm
4064
4055
           END IF
4068 Print_gen_level:!
           PRINT CHR#(129);
4070
           SELECT Test_type*
4072
           CASE "MODE TUNE REGULAR", "OTHER (NO STEPS)"
4074
4076
               IF Search_eut OR Search_pwr THEN
                   FRINT TABXY(21,9);"
                                         LOW: "
4078
                   PRINT TABXY(21,10);"
                                        HIGH: "
4080
                   PRINT TABXY(21,11); " STEP: "
4082
4084
               ELSE
4086
                   PRINT TABXY(21,9); " FIXED: "
                   PRINT TABXY(21,10);"
4088
                   PRINT TABXY(21,11);"
4090
4092
               END IF
4094
           CASE "MODE TUNE EMISSIONS"
                                     NOT "
4096
               PRINT TABXY(21,9);"
               PRINT TABXY(21,10);"
                                      USED "
4098
               FRINT TABXY(21,11);"
4100
4102
           CASE ELSE
4104
               PRINT TABXY(21,9); " ERROR "
               PRINT TABXY(21,10); "DETECTED"
4106
4108
               PRINT TABXY(21,11); "IN TYPE!"
4110
           END SELECT
           PRINT CHR$(128);
4112
4114
           PRINT TABXY(30,9);
           PRINT USING "4A";"
4116
4118
           PRINT TABXY(30,10);
4120
           PRINT USING "4A";"
4122
           PRINT TABXY(30,11);
4124
           FRINT USING "4A";"
           IF Test_type$<>"MODE TUNE EMISSIONS" THEN
4126
4128
               PRINT TABXY(30,9);
4130
               FRINT USING "4D"; Low_dbm
4132
               IF Search_eut OR Search_pwr THEN
4134
                   PRINT TABXY (30,10);
                   FRINT USING "4D"; High_dbm
4136
4138
                   PRINT TABXY(30,11);
4140
                   FRINT USING "4D"; Step dbm
4142
               END IF
4144
           END IF
4146
           RETURN
4148
             4150
4152
4154 Change_response:Interrupted=1
           DISP " ENTER time for EUT to respond after field is set. (seconds) ";
4156
           INPUT Time eut
4158
4160 Frint_wait:!
           PRINT TABXY (30,13);
4162
           IF Time_eut<9999 THEN
4164
               FRINT USING "X,5D.3D"; Time_eut
4165
4168
               PRINT USING "MD. 3DE"; Time_eut
4170
4172
           END IF
4174
           RETURN
4176
```

```
4178
4180
4182 Enter_name: Interrupted=1
         DISP " PLEASE TYPE IN YOUR NAME ";
4184
4186
         LINFUT Test$
         Operator_name = Test $[1,28]
4188
4190 Frint_name:!
         PRINT TABXY(13,17); RPT#(" ",28);
4192
         FRINT TABXY(13,17);Operator_name*
4194
4196
         RETURN
4198
          4200
4202
4204 Change diskdriv:!
4205
         OFF KEY
4208
         Interrupted=1
         DISP " SELECT DISK DRIVE for DATA OUTPUT. "
4210
         ON KEY O LABEL "LEFT Internal", Local_prty+1 GOTO Left_internal
4212
         ON KEY 2 LABEL "9133 HARD DISK", Local_prty+1 GOTO Hard9133
ON KEY 4 LABEL "RIGHT Internal", Local_prty+1 GOTO Right_internal
4214
4216
4218
         ON KEY 7 LABEL "9133 floppy",Local_prty+1 GOTO Floppy9133
4220
         LOOF
4222
         END LOOP
4224 Left_internal:Outdisk#=":INTERNAL,4,1"
4226
         GOTO Disk_selected
4228 Right_internal:Outdisks=":INTERNAL,4,0"
4230
         GOTO Disk_selected
4232 Hand9133: Outdisk#=":HP9133,700.0"
4234
         GOTO Disk_selected
4236 Floppy9133:Outdisk#=":HP9133,702,0"
4238 Disk_selected:OFF KEY
4240 Print_diskdrive:!
         PRINT TABXY(62,17); Outdisk*
4242
4244
4246
4248
          4250
4252
      SUBEND
4254
4256
       **********************
4258
```

```
100!
      RE-STORE "MODE STIR"
      ! Original: 22 May 1984, G. Koepke, NBS (303) 497-5766
102
      ! Revision: 02 Oct 1985
104
106
        108
       The program is currently configured as follows:
           1) Read diode detector on DVM i [722] (Horn antenna)
110
112
              Calibrate this reading via diode calibration
              and normalize to 10 mW/cm^2 referenced to the
114
116
              energy calculated via reference antenna as read
118
              on the spectrum analyzer.
120
122
           2) Read 1cm dipole output on DVM 2 [723] and DVM 3 [724]
124
              This is the EUT for the measurement.
126
              Calibrate via calibration curve and
128
              normalize to 37 dB V/m as calculated from
130
              reference received power.
132
134
           3) In the event of failure to complete revolution
136
              the program will modify sample count to compensate.
138
140
           4) Parameters set for NBS chamber.
142
144
           5) Save data is disabled, needs to be updated for GRAPH DATA
146
148
       150
152
      ! ==== CHECK ALL CABLES AND PAD PLACEMENTS ==========
154
156
      !This measurement routine will operate the REVERBERATION CHAMBER
158
      !using MODE STIRED techniques. The tuner is stepped continuously
      !and measurements are performed asyncronusly. In this version each
160
162
      !frequency is measured completely before proceeding
164
      !to the next frequency.
166
      !Coupler, cable loss, and Power meter head corrections are applied
168
      !immediately to the measured data.
170
      !The statistical results are saved for graphing.
172
174
176
      OFTION BASE 1
178
      DEG
180
      PRINTER IS 1
182
      OUTPUT 2 USING "K,#"; "SCRATCH KEYX"
184
      DISP CHR# (129)
186
188
      GOSUB Die gracefully
                              !For a clean slate.
      GOSUB Dim_variables
190
192
      GOSUB Initial_values
194
      GOSUB Fillcalibration
196
      GOSUB Do measurements
193
      GOSUB Die_gracefully
      DISP "PROGRAM FINISHED"
200
202
      STOP
204
206
      208
210 Dim_variables:
212
      COM /Parameters/ Startf, Stopf, Stepf, Slow_down, Coupler_id #[10]
      COM /Parameters/ Generator_id [10], Dvm_integrat [3]
214
216
      COM /Farameters/ INTEGER Low_dbm,High_dbm,Step_dbm,Dvm_samples
      COM /Parameters/ Upperlimit, Threshold, Rev_time
218
```

```
220
       CDM /Motor_menu/ Motion_type #[10], INTEGER Jog_wait
222
       COM /Bugs/ INTEGER Bug1, Bug2, Bug3, Printer
       COM /Interrupts/ INTEGER Intr_prty
224
225
       COM. /Files/ Sourcedisk#[20],Outdisk#[20],Filename#[80]
228
230
       DIM Coup_inc(100,2),Coup_refl(100,2),Daddata_id*(10)[80]
232
       DlM Cable6a(180,2), Cable6b(180,2), Cable4(180,2), Cable10ft(180,2)
       DIM Pad_as6a(180,2),Pad_s6770(180,2),Pad_f5530(180,2)
234
       DIM NEWC (180,2) !NSWC CABLE DATA
236
238
       DIM Cal_id*L80], Ab*[2], Pwr_id*L2], Test*[40]
240
242
244
       INTEGER Baddata, Dbm, Rf_on_off
245
       INTEGER Failflag
248
       INTEGER Valid, Total freqs, Total curves, Ser_poll
250
       INTEGER Frintflag, Read1flag, Read2flag, Movingflag, Pad10db
252
254
       INTEGER Newc_pts
256
       INTEGER Inc_pts,Refl_pts,C6a_pts
258
       INTEGER C6b_pts,C4_pts,C10_pts,Fada_pts,Fad_pts,Fadf_pts
260
       INTEGER Fcount, Too_hot, Frintflag2
262
       INTEGER Local_prty,P_sams,P,Dvm1_sams,Dvm2_sams
264
266
       RETURN
268
270
      !/////////////****INIT1ALIZE VARIABLES % I/O****////////////
272
274 Initial_values:
276
278
       ASSIGN @Motor TD 706
280
       ASSIGN @Fwr1 TO 709
282
       ASSIGN @Pwr2 TO 710
       ASSIGN @Dual_pwr1 TO 711
284
       ASSIGN @Spectrum TO 718
286
288
       ASSIGN @Dvm1 TO 722
290
       ASSIGN @Dvm2 TD 723
292
       ASSIGN @Dvm3 TO 724
294
       ASSIGN @Sig_gen TD 719
296
298
       Intr_prty=6
300
       Local_prty=Intr_prty
302
       Printer=701
304
       Sourcedisk#=":INTERNAL,4,0"
306
       Outdisks=":INTERNAL,4,1"
308
310
       Printflag=0
312
       Bug 1=0
314
       Bug2=0
316
       Bug3≈0
318
320
       Motion type:="CONTINUOUS"
                                       !or "STEP" for MODE TUNED.
322
324
       Rf_on_off=1
                                       ! 1=on, 0=off
326
328
       CALL Measure menu
                                      !Go and set up the measurement parameters.
330
       Dvm1_sams=Dvm_samples
332
       Dvm2_sams=Dvm_samples
       CALL Menu_pwr436a
334
                                      !Set up all power meters
336
       GOSUB Die gracefully
                                      !For a clean slate.
338
```

```
!-----ALLOCATE THE RAW DATA MATRIX------
340
342
       Totalfregs=INT((Stopf-Startf)/Stepf)+1
344
       Totalcurves=6
       ALLUCATE Savedata (Total freqs, Total curves+1)
346
348
       ALLOCATE Adjust(Totalfreqs, 10)
350
352
354
       PRINTER IS CRT
356
       PRINT TABXY(1,18); RPT#("*",20); " LOAD SUB PROGRAMS "; RPT#("*",20)
358
       Filename#=Generator_id#&Sourcedisk#
       DISP "Insert 'SUB Program/Support DATA' disk in ";
360
362
       SELECT Sourcedisk≉
       CASE ": INTERNAL, 4, 0"
364
366
           DISP "RIGHT DRIVE, ";
368
       CASE ": INTERNAL, 4, 1"
           DISP "LEFT DRIVE, ";
370
       END SELECT
372
374
       DISP "and hit 'CONTINUE'."
376
378
       ON KEY 5 LABEL "CONTINUE", Local_prty GOTO Subloads
380 Zippy:GOTO Zippy
382 Subloads: OFF KEY
384
       DISP CHR#(12)
386
       DISP " Signal Generator SUB PROGRAMS NOW LOADING "
       ON ERROR CALL Errortrap
388
390
       LOADSUB ALL FROM Filenames
392
       OFF ERROR
394
       DISP " Signal Generator SUB PROGRAMS LOADED "
396
       WAIT 1
398
       PRINT TABXY(1,18); RPT#("*",20); " LOAD CALIBRATION DATA "; RPT#("*",20)
400
402
       DISP " Calibration DATA for Cables, Couplers, Fads, etc. now LOADING "
404
406 Install_cal_fl:!.... Install new calibration files here....!
408
       IF Printflag THEN PRINTER IS Printer
410
       IF Printflag THEN FRINT "CALIBRATION DATA FOR THE FOLLOWING IS LOADED:"
412
414
       SELECT Coupler_id$
415
       CASE "HP 778D"
418
           Filename*="HP 778D f"&Sourcedisk*
           Enter_caldata(Filename*,Coup_inc(*),Cal_id*,Inc_pts)
420
422
           Baddata id#(1)=Cal id#
424
           IF Printflag THEN FRINT Cal_id$
426
           Filename*="HP_778D_r"&Sourcedisk*
428
           Enter_caldata(Filename$,Coup_refl(*),Cal_id$,Refl_pts)
430
           Baddata id*(2)=Cal id*
432
           IF Frintflag THEN PRINT Cal_id$
       CASE "HF 11692D"
434
           Filename#="HP11692D_f"&Sourcedisk#
436
438
           Enter_caldata(Filename*.Coup_inc(*),Cal_id*,Inc_pts)
440
           Boddata id#(1)=Cal id#
442
           1F Printflag THEN PRINT Cal_id$
444
           Filename*="HP11692D_r"&Sourcedisk*
446
           Enter_caldata(Filename*,Coup_refl(*),Cal_id*,Refl_pts)
           Baddata_id # (2) = Cal_id #
448
450
           IF Printflag THEN PRINT Cal_id$
       CASE ELSE
452
454
           PRINT "COUPLER CALIBRATION DATA ERROR....NOT DEFINED."
456
           REFE
458
           PAUSE
```

```
460
       END SELECT
462
464
465
       Filename*="Cable6FT_1"&Sourcedisk*
468
       Enter_caldata(Filename*,Cable6a(*),Cal_id*,C6a_pts)
470
472
       Baddata id#(3)=Cal_id#
474
       IF Printflag THEN PRINT Cal_id$
476
478
       Filename#="Cable6FT_6"&Sourcedisk*
480
       Enter_caldata(Filename*,Cable5b(*),Cal_id*,C6b_pts)
482
       Baddata id#(4)=Cal id#
484
       IF Printflag THEN PRINT Cal id#
486
488
       Filename#="Cable4FT_2"&Sourcedisk#
490
       Enter_caldata(Filename*,Cable4(*),Cal_id*,C4_pts)
492
       Baddata_id$(5)=Cal_id$
       IF Printflag THEN PRINT Cal id$
494
496
498
       Filename#="Cable10F_5"&Sourcedisk#
500
       Enter_caldata(Filename*,Cable10ft(*),Cal_id*,C10_pts)
502
       Baddata_id$(6)=Cal_id$
504
       IF Frintflag THEN PRINT Cal_id$
506
508
       Filename#="PAD_S6770"&Sourcedisk#
510
       Enter_caldata(Filename*,Fad_s6770(*),Cal_id*,Fad_pts)
512
       Baddata_id*(7)=Cal_id*
514
       IF Frintflag THEN FRINT Cal_id$
516
518
       Filename#="PAD_5530"&Sourcedisk#
520
       Enter_caldata(Filename*,Pad_f5530(*),Cal_id*,Padf_pts)
522
       Baddata_id$(8)=Cal_id$
524
       IF Frintflag THEN FRINT Cal_id$
526
528
       Filename*="PdAS6A1466"&Sourcedisk*
530
       Enter_caldata(Filename*,Fad_as5a(*),Cal_id*,Fada_pts)
532
       Baddata_id$(9)=Cal_id$
534
       IF Printflag THEN PRINT Cal_id$
536
538
       Filename#="PdAS6A1466"
540
       Filename#=Filename#&Sourcedisk#
542
       Enter_caldata(Filename*, Nswc(*), Cal_id*, Nswc_pts)
544
       Baddata_id*(10)=Cal_id*
546
       IF Frintflag THEN FRINT Cal id*
548
       DISP " Calibration DATA LOADED "
550
       WAIT 1
552
       PRINTER IS CRT
554
       CALL Wipe_clean
555
558
560
562
       DISP "INSERT OUTPUT DATA DISK IN ";
564
       SELECT Outdisk*
       CASE ": INTERNAL, 4, 0"
566
568
           DISP "RIGHT DRIVE, ";
       CASE ": INTERNAL, 4, 1"
570
572
           DISP "LEFT DRIVE, ";
574
       END SELECT
576
       DISP "and hit 'CONTINUE'."
578
       BEEF
```

```
580
       ON KEY 5 LABEL "CONTINUE", Local_prty 60TO Datasaver
582 Zippity:GOTO Zippity
584 Datasaver:OFF KEY
586
       DISP CHR#(12)
588
590
       RETURN
592
       !//////////////////////////////****DIE GRASEFULLY****///////////////////////////
594
596
598 Die_gracefully:
       IF Bug1 THEN
600
           FRINT TIME # (TIMEDATE);
602
           PRINT RPT#("<",15);" DIE GRACEFULLY "; RPT#(">",15)
604
       END IF
606
608
       ON ERROR GOTO Delet_done1
       SELECT Generator_id*
610
       CASE "HF_8660A"
612
614
           DELSUB Set_freq,Set_dbm,FNDigit10$,FNDigit3$,FNRev$
616
       CASE "HP 8672A"
618
           DELSUB Set_freq,Set_dbm
620
       END SELECT
622 Delet_done1:
624
       OFF ERROR
626
       ON ERROR GOTO Delet done2
628
       DEALLOCATE Savedata(*), Adjust(*)
630 Delet done2:
632
       OFF ERROR
634
       RETURN
636
638
       640
642 Fillcalibration:
                       !Determine the cable, coupler and pad calibration
644
                        !values for each frequency.
646
                       !Save these in the adjust(*) file for use by the
648
                        !measurement routine.
650
652
       IF Bug1 THEN
654
           FRINT TIME # (TIMEDATE);
656
           PRINT RPT#("<",15);" FILL CALIBRATION MATRIX ";RPT#(">",15)
658
       END IF
660
       Fcount=1
662
       FOR Frequency=Startf TO Stopf STEP Stepf
654
           Get_cal_value(Frequency,Coupinc,Coup_inc(*),Baddata,Inc_pts)
           IF Baddata THEN
666
668
               Cal id#=Baddata id#(1)
670
               GOSUB Flagbaddata
672
           END IF
674
           Adjust (Fcount, 1) = Coupinc
676
678
           Get_cal_value(Frequency,Couprefl,Coup_refl(*),Baddata,Refl_pts)
680
           IF Baddata THEN
682
               Cal_id = Baddata_id = (2)
684
               GOSUB Flagbaddata
686
           END IF
688
           Adjust(Fcount,2)=Coupref1
690
692
           Get_cal_value(Frequency,C6a_loss,Cable6a(*),Baddata,C6a_pts)
694
           IF Baddata THEN
696
               Cal id#=Baddata id#(3)
698
               GOSUB Flagbaddata
```

```
700
           END IF
           Adjust (Fcount, 3) = C6a_loss
702
704
           Get_cal_value(Frequency,C6b_loss,Cable6b(*),Baddata,C6b_pts)
706
708
           IF Baddata THEN
               Cal id*=Baddata id*(4)
710
712
               GOSUB Flagbaddata
           END IF
714
           Adjust (Fcount, 4) = C6b_loss
716
718
           Get_cal_value(Frequency,C4_loss,Cable4(*),Baddata,C4_pts)
720
722
           IF Baddata THEN
724
               Cal id≉=Baddata_id≰(5)
               GOSUB Flagbaddata
725
728
           END IF
730
           Adjust (Fcount, 5) = C4_loss
732
           Get_cal_value(Frequency,C10_loss,Cable10ft(*),Baddata,C10_pts)
734
736
           IF Baddata THEN
738
               Cal_id = Baddata_id $ (6)
740
               GOSUB Flagbaddata
742
           END IF
744
           Adjust(Fcount, 4)=C10_loss
746
748
           Get_cal_value(Frequency, Pad_loss, Pad_s6770(*), Baddata, Pad_pts)
750
           IF Baddata THEN
752
               Cal id$=Baddata id$(7)
754
               GOSUB Flagbaddata
           END IF
756
758
           Adjust (Fcount, 7) = Fad loss
760
762
           Get_cal_value(Frequency,Fadf_loss,Fad_f5530(*),Baddata,Fadf_pts)
764
           IF Baddata THEN
766
               Cal_ids=Baddata_ids(8)
               GOSUB Flagbaddata
768
770
           END IF
772
           Adjust(Fcount,8)=Fadf_loss
774
           Get_cal_value(Frequency, Pada_loss, Pad_as6a(*), Baddata, Pada_pts)
776
778
           IF Baddata THEN
780
               Cal_id$=Paddata_id$(9)
782
               GOSUB Flagbaddata
784
           END IF
           Adjust(Fcount,9)=Pada_loss
785
788
           Get cal value (Frequency, Nawc loss, Nawc (*), Baddata, Nawc_pts)
790
792
           IF Baddata THEN
794
               Cal_id$=Baddata_id$(10)
796
               GOSUB Flagbaddata
798
           END IF
800
           Adjust (Fcount, 10) = Nswc_loss
802
804
           Fcount=Fcount+1
806
       NEXT Frequency
808
       GOSUB Printcalvalues
       RETURN
810
812
814
         816
                       !Inform the operator that there is wrong data
818 Flagbaddata:
```

```
!being brought back from Enter cal data
820
822
824
      PRINTER IS CRY
      PRINT TABXY(1,18);
826
      PRINT RF(*("*",10);" CALIBRATION DATA out of range for ";Frequency;
828
      PRINT " MHz "; RPT $ ("*", 10)
830
832
      DISP Cal id#
834
      BEEF
836
      PAUSE
      PRINT TABXY(1,18);
838
840
      PRINT RPT#("*",10);" CALIBRATION VALUE OF 0 dB WILL BE USED ";
842
      FRINT RET#("*",10)
844
      WAIT 3
      PRINT TABXY(1,18); RPT#(" ",80)
846
      DISP CHR#(12)
848
850
      RETURN
852
       854
856
858 Printcalvalues:
                       !MAKE LIST OF CALIBRATION VALUES USED.
860
862
      PRINTER IS Printer
864
      FRINT
      PRINT RPT$("*",24); " CALIBRATION / LOSS VALUES (dB) ";RPT$("*",24)
866
848
      PRINT
      PRINT "Frequency
870
                       Coupler
                                    ---- BLUE CABLES ----";
872
      PRINT " $6770 F5530 ASA6A TEST"
      PRINT "
                                    6ft#1 6ft#6
874
               MHz
                       Inc
                            Refl
                                                 4ft 10ft":
876
      FRINT "
              pad
                      pad
                             pad
                                   СЬ1"
878 Lossfmt1: IMAGE M5D.D,X,4(MDD.DD),#
880 Lossfmt2:IMAGE 3(MDD.DD),2(MDD.DD,X),#
882 Lossfmt3: IMAGE MDD.DD
      Fcount=1
834
886
      FOR Frequency=Startf TO Stopf STEF Stepf
888
          Coupinc=10*LGT(Adjust(Fcount,1))
                                                     !Coupler incident
890
          Couprefl=10*LGT(Adjust(Fcount,2))
                                                     !Coupler reflected
892
          C6a_loss=10*LGT(Adjust(Fcount,3))
                                                     !6 foot BLUE cable #1
894
          C6b_loss=10*LGT(Adjust(Fcount,4))
                                                     !6 foot BLUE cable #6
876
          C4 loss=10*LGT(Adjust(Fcount,5))
                                                     !4 foot BLUE cables
898
          C10_loss=10*LGT(Adjust(Fcount,6))
                                                     !10 foot BLUE cables
900
          Fad loss=10*LGT(Adjust(Fcount,7))
                                                     !Weinschel S6770 10dB pad
902
          Fadf_loss=10*LGT(Adjust(Fcount,8))
                                                     !Weinschel F5530 10dB pad
904
          Fada_loss=10*LGT(Adjust(Fcount,9))
                                                     !Weinschel AS6A-1466 10dB
906
          Nswc_loss=10*LGT(Adjust(Fcount,10))
                                                    !NSWC input cable
908
          PRINT USING Lossfmt1; Frequency, Coupinc, Coupref1, C6a_loss, C6b_loss
910
          PRINT USING Lossfmt2;C4_loss,C10_loss,Pad_loss,Padf_loss,Pada_loss
912
          FRINT USING Lossfmt3; Nswc_loss
914
          Fcount=Fcount+1
      MEXT Frequency
915
918
      PRINT
920
      PRINT RET#("*",80)
922
      PRINT USING "4/"
924
      PRINTER IS CRT
926
      RETURN
928
930
932
       934
936 Do_measurements:
938
```

```
940
       PRINTER IS 1
942
       Fcount=1
944
       Dbm=Low dbm
                                !Initialize the Generator Level
946
       Frequency=Startf
                                !Initialize first frequency.
       ! BEEF
948
950
       ! INPUT "ENTER THE RANGE SET ON THE 1 cm DIPOLE AMPLIFIER", Picm_scale
952
       ! DISP CHR#(12)
954
       Ficm scale=.1
955
       Initializemotor(@Motor)
958
       Zeromotor (@Motor)
960
       REPEAT
962
964
966
           !Initial values and zeroing
948
970
           !Calibration data for all cables, probes, & power heads.
972
974
           Pwrmtrcal1=FNPwrmtrcal1((Frequency))
                                                          !18 GHz HEAD.
976
           Pwrmtrcal2=FNPwrmtrcal2((Frequency))
                                                         !26 GHz HEAD.
978
980
           Coupinc=Adjust(Fcount,1)
                                                !Coupler incident
982
           Coupref1=Adjust (Fcount,2)
                                                !Coupler reflected
984
           C6a_loss=Adjust(Fcount,3)
                                                !6 foot BLUE cable #1
986
           C6b loss=Adjust(Fcount,4)
                                                !6 foot BLUE cable #6 rcvr.
988
                                                !4 foot BLUE cable
           C4_loss=Adjust(Fcount,5)
                                                !10 foot BLUE cable
           C10_loss=Adjust(Fcount,6)
990
992
           Pad_loss=Adjust(Fcount,7)
                                                !Weinschel S6770 10dB pad
994
           Fadf loss=Adjust (Fcount,8)
                                                !Weinschel F5530 10dB pad
996
                                                !Weinschel AS6A-1466 10dB
           Fada loss=Adjust (Fcount, 9)
998
                                                !NSWC input cable
           Nswc_loss=Adjust(Fcount,10)
1000
1002
           Dvm1 sams=Dvm samples
                                     !The measurement will be attempted at
1004
                                      !the predicted number of samples first.
           Dvm2_sams=Dvm_samples
1006
                                     !These will be adjusted if failure occurs.
1008
           Failflag=0
1010
1012 Restart:
              !Any failure on this measurement causes branch to here.
1014
           Set_dbm(-140,Rf_on_off,@Sig_gen)
1016
           Set_freq(Frequency,@Sig_gen)
           Initializemotor (@Motor)
1018
1020
1022
           DISF CHR#(12)
1024
1026
           Setdcv3456a(@Dvm1)
           Readdvm(Eut_zero,@Dvm1)
1028
1030
           Setdcv3456a(@Dvm2)
1032
           Readdvm(F1cm_zero,@Dvm2)
1034
1036
           Setdvm_3456a(@Dvm1,Dvm_integrat*,Dvm1_sams)
1038
           Setdvm_3456a(@Dvm2,Dvm_integrat≉,Dvm2_sams)
1040
           Setdym 3478a(@Dym3)
1042
           Spec_alzr_setup(@Spectrum)
1044
1046
           !Zero_pwr_mtrs(@Pwr1,@Pwr2)
1048
           Ab = "AB"
1050
1052
           CALL Zero_438a(@Dual_pwr1,Ab*)
1054
1056
           IF NOT Failflag THEN
1058
               Dbm=Low_dbm
```

```
1060
               Movemeter (@Motor)
1062
               PRINT CHR#(12)
1064
               PRINT TABXY(1,3); TIME#(TIMEDATE); "************;
               PRINT " FREQUENCY ": Frequency; " MHz. ***********
1055
               PRINT TABXY(1,5); "FINDING THRESHOLD VALUE dBm="
1068
               PRINT TABXY(36.5); " Average EUT RESPONSE= "
1070
1072
               LOOP
1074
                   Set dbm(Dbm,Rf on off,@Sig gen)
1076
                   Vave=0.
1078
                   FOR Sams=1 TO 30
1080
                       Readdvm_3478a(@Dvm3,V)
                       V=V-F1cm_zero
1082
1084
                       Vave=Vave+V
1086
                   NEXT Sams
                   Vave=Vave/40
1088
                   PRINT TABXY (30,5);
1090
                   PRINT USING "5D": Dbm
1092
1094
                   PRINT TABXY(60,5);
1096
                   PRINT USING "3D.8D"; Vave
1098
               EXIT IF Vave>=Threshold OR Dbm>=High dbm
                   Dbm=Dbm+Step_dbm
1100
1102
               END LOOP
1104
               Stop_motor(@Motor)
1106
           ELSE
1108
               Set_dbm(Dbm,Rf_on_off,@Sig_gen)
           END IF
1110
1112
           Failflag=1
1114
1116
           ! Trigger measurement ......
1113
1120
           DISP CHR#(12)
1122 Restart_point2:!
1124
           Ab*="AB"
1126
           CALL Read_dual_pwr(Ab$,Apower,Bpower,Too_hot,Valid,@Dual_pwr1)
1128
           IF Too_hot THEN
1130
               GOSUB Reduce power
1132
               GOTO Restart_point2
1134
           END IF
1136
           IF NOT Valid AND NOT Too hot THEN GOSUB Dual pwr error
1138
           IF Apower<0. THEN Apower=0.
1140
           IF Bpower<0. THEN Bpower=0.
1142
           Incpwr_raw=Apower
1144
           Refpwr_raw=Bpower
1145
1148
           !....Sequence for reading 436a Fower meters.......
                Pwr_id排="P1"
1150
1152
                Read_pwr_meter(Fower, Fwr_id*, Valid, @Fwr1, @Sig_gen)
1154
                IF NOT Valid THEN
                    DISP "ERROR IN 436a POWER METER 1"
1156
1158
                    BEEP
1160
                    PAUSE
1162
                END IF
1164
1166
           Incpwr=Incpwr_raw
1168
           Incpwr=Incpwr*Coupinc*Fwrmtrcal1/(C6b_loss) !Inc power at ANT
1170
           Refpwr=Refpwr raw*Coupref1*Fwrmtrcal1*C6b loss !Ref1 pwr at ANT
1172
           Netpower=(Incpwr-Refpwr)
1174
1176
           FRINT TIME * (TIMEDATE);
1178
           PRINT "**** START NEW MEASURMENT AT FREQUENCY = "; Frequency
```

```
ON INTR 7 GOSUB Check_dvm_done
1180
1182
           ENABLE INTR 7:2
1184
           Movemotor (@Motor)
           IF Buq1 THEN PRINT "DVM1 trigger ";TIME$(TIMEDATE);" ";
1186
1188
           Trig1 time=TIMEDATE
1190
           Trigger_3456a(@Dvm1)
           IF Bug1 THEN FRINT "DVM2 trigger ";TIME$(TIMEDATE);" ";
1192
1194
          Trio2 time=TIMEDATE
1196
          Trigger_3456a(@Dvm2)
1178
          Spec_alzr_start(Frequency,@Spectrum)
1200
           IF Bug1 THEN PRINT "TRIGGER ANALYZER ": TIME $ (TIMEDATE)
1202
          Read1flag=0
1204
          Read2flag=0
1206
          Vpeak=0
1208
          LOOP
1210
              Readdym 3478a(@Dym3,V)
1212
               V=V-P1cm zero
1214
               IF V>=Upperlimit THEN
1216
                   Stop motor (@Motor)
1218
                   REFEAT
1220
                       Dbm=Dbm-Step_dbm
1222
                       Set_dbm(Dbm,Rf_on_off,@Sig_gen)
1224
                       WAIT Slow down
1226
                       Readdym 3478a(@Dym3,V)
1228
                       V=V-F1cm_zero
1230
                      BEEF
1232
                      PRINT "EUT MAXIMUM EXCEEDED **** POWER DECREASED TO ";
1234
                      PRINT Dbm: " dBm. "
1236
                   UNTIL V<Upperlimit
1238
                   OFF INTR 7
1240
                  GOTO Restart
1242
              END IF
1244
              Checkmotor (@Motor, Movingflag)
1246
              IF NOT Movingflag THEN
1248
                  PRINT "MOTOR NOT MOVING******DATA BAD"
1250
                   GOTO Restart
1252
              END IF
1254
              IF V>Vpeak THEN Vpeak=V
1256
              Countdown=Rev_time-(TIMEDATE-Trig1_time)
              IMAGE M4D.D," Seconds left, EUT mV=",M6D.2D," / ",M6D.2D," "
1258 Spy:
1260
              DISP USING Spy; Countdown, V*1000, Vpeak*1000
          EXIT IF Readiflag AND Read2flag
1262
1264
          END LOOP
1266
           1268
           ! Make sure that the correct voltmeters are connected for this test!
1270
           ! IF (Vpeak+Eut zero)>High2 THEN High2=Vpeak+Eut zero
1272
           1274
          OFF INTR 7
1276
          Failflag=0
1278
1280
           ! Insure successful (syncronized tuner and dyms)
                                                            measurement.
1282
1284
          IF (Read1_time<.98*Rev_time) OR (Read1_time>1.02*Rev_time) THEN
1285
               Dvm1_sams=INT((Rev_time/Read1_time)*Dvm1_sams)
1288
              FRINT "Dym 1 NOT syncronized with TUNER REVOLUTION. ";
1290
              PRINT "Changing samples to "; Dvm1_sams
1292
               Failflag=1
1294
          END IF
          IF (Read2_time<.98*Rev_time) DR (Read2_time>1.02*Rev_time) THEN
1296
1278
               Dvm2 sams=INT((Rev time/Read2_time)*Dvm2_sams)
```

```
PRINT "Dvm 2 NOT syncronized with TUNER REVOLUTION. ";
1300
1302
              PRINT "Changing samples to "; Dvm2_sams
1304
             Failflag=1
1306
          END IF
1308
          IF Failflag THEN
              Stop_motor(@Motor)
1310
1312
              6010 Restart
1314
          END IF
1316
          Spec alzr read(Power, Frequency, @Spectrum)
          PRINT "SPECTRUM ANALYZER READS "; Power; " AT FREQUENCY "; Frequency
1318
1320
          Stop_motor(@Motor)
1322
          Set_dbm(-140,Rf_on_off,@Sig_gen)
1324
1326
          GOSUB Process data
1328
          GOSUB Print_alldata
1330
1332
          Frequency=Frequency+Stepf
1334
          Fcount=Fcount+1
1336
      UNTIL Frequency>Stopf
1338
1340
      Set dbm(-140,0,@Sig gen)
1342
      ! GOSUB Save_data
1344
      RETURN
1346
      1348
1350
1352 Reduce_power: !
      Dbm=Dbm-1
1354
1356
      Set_dbm(Dbm,1,@Sig_gen)
1358
      IF Frintflag THEN
1360
          PRINTER IS Printer
1362
          FRINT TIME * (TIMEDATE); ": Freq="; Frequency;
1364
          PRINT RFT$("*",10);" NEW GENERATOR LEVEL ="; Dbm
1366
      END IF
1368
      RETURN
1370
1372
        1374
1376 Dual_pwr_error:
1378
      Set dbm(-140,0,@Sig gen)
1380
      IF Printflag THEN
          PRINTER IS Frinter
1382
1384
          FRINT TIME $ (TIMEDATE); ": Freq="; Frequency;
1386
          PRINT RPT#("*",10);" ERROR IN DUAL POWER METER !!!"
1388
      END IF
1390
      STOP
                 Program dies here!
1392
      RETURN
1394
1396
      1398
1400 Check_dvm_done:
1402
                    !Respond to an INTERUPT on the HPIB generated by one of
1404
                    !two HP3456a DVMs. Meaning that the data is ready.
1406
1408
      Ser_poll=SFOLL(@Dvm1)
1410
      ENABLE INTR 7
1412
      IF Ser_poll=66 THEN
1414
          Read1_time=TIMEDATE-Trig1_time
          IF Bug1 THEN PRINT "DVM1 total sample time = ";Read1_time;" ";
1416
1418
          IF Bug1 THEN PRINT TIME $ (TIMEDATE)
```

```
1420
1422
1424
          !Since the output of the detector is negative, Low and High are
1426
          Readdvm_stat(@Dvm1, High1, Low1, Mean1, Var1, Sam1) !Low and High swapped!
1428
1430
1432
1434
          Low1=-1*Low1
                               !Crystal detector has negative output
1436
          High1=-1*High1
                               1 11
          Mean1=-1*Mean1
1438
          FRINT " DVM 1====",Low1,High1,Mean1,Var1,Sam1
1440
1442
          Read1flag=1
1444
      END IF
1446
      Ser_poll=SPOLL(@Dvm2)
1448
      ENABLE INTR 7
      IF Ser_poll=66 THEN
1450
          Read2_time=TIMEDATE-Trig2_time
1452
          IF Bug1 THEN PRINT "DVM2 total sample time = ";Read2_time;" ";
IF Bug1 THEN PRINT TIME*(TIMEDATE)
1454
1456
1458
          Readdvm_stat(@Dvm2,Low2,High2,Mean2,Var2,Sam2)
1460
          FRINT " DVM 2====",Low2,High2,Mean2,Var2,Sam2
1462
          Read2flag=1
1464
      END IF
1466
      RETURN
1468
      1470
1472
1474 Frocess_data:
1476
1478
      !Calculations for power read from spectrum analyzer.
1480
                                      !Convert dBm to watts.
1482
      Power=(.001)*10^(Power/10.)
1484
      Cor_power=Power*C10_loss*C6a_loss*Fada_loss
1486
1488
      !ALSO EDIT PRINT STATEMENT IN LINE 1620
1490
1492
      !Normalize to 10 mW/cm^2
1494
1496
      Ref_pwr_den=(.4*PI*Frequency*Frequency*Cor_power)/9.0E+4
1478
      Normal_pwr=SQR(10/Ref_pwr_den)
1500
      !.....
1502
      !Normalize to 37 dB V/m
1504
1506
      Ref_e_field=(4*FI*Frequency/300)*SQR(Cor_power*30)
1508
      Normal_fld=(((10.0^(37/20))/Ref_e_field))
1510
1512
      !Calculations for CRYSTAL detector with 6 ft cable.
1514
1516
      Cor_high1=(High1-Eut zero)
1518
      Cor_mean1=(Mean1-Eut_zero)
1520
      IF Cor_high1<1.0E-50 THEN Cor_high1=1.0E-50
1522
      IF Cor_mean1<1.0E-50 THEN Cor_mean1=1.0E-50
1524
1526
      1F Cor_high1<=.1 THEN</pre>
1528
          Cor_high1=.00304939*Cor_high1^(1.1195)!Convert to WATTS
1530
      ELSE
          Cor_high1=.0135056*Cor_high1^(1.7488)!Convert to WATTS
1532
1534
      END IF
1536
1538
      Cor_high1=Cor_high1*C10_loss
```

```
1540
       Cor high1=Cor_high1*Normal_pwr*Normal_pwr
1542
       Cor_high1=10*L6T(Cor_high1/1.0E-3)
                                                      !Convert to dBm
1544
1546
       1F Cor_mean1=.1 THEN
1548
           Cor_mean1=.00304939*Cor_mean1^(1.1195)!Convert to WATTS
1550
1552
          Cor_mean1=.0135056*Cor_mean1^(1.7488)!Convert to WATTS
1554
       END IF
1556
1558
       Cor_mean1=Cor_mean1*C10_loss
       Cor_mean1=Cor_mean1*Normal_pwr*Normal_pwr
1560
       Cor_mean1=10*LGT(Cor_mean1/1.0E-3)
1562
                                                      !Convert to dBm
1564
       !Calculations for 1 cm DIPOLE with super amp.
1566
1568
1570
      Cor_high2=(High2-P1cm_zero)
1572
       Return_field(Cor_high2,F1cm_fld_high)
1574
       P1cm_fld_high=F1cm_fld_high*Normal_fld
1576
       New_volts(P1cm_fld_high,Cor_high2)
1578
1580
       Cor mean2=(Mean2-P1cm zero)
       Return_field(Cor_mean2,P1cm_fld_mean)
1582
       P1cm_fld_mean=P1cm_fld_mean*Normal_fld
1584
1586
       New_volts(P1cm_fld_mean,Cor_mean2)
1588
1590
       1F Cor_high2<1.0E-50 THEN Cor_high2=1.0E-50</pre>
1592
       1F Cor_mean2<1.0E-50 THEN Cor_mean2=1.0E-50</pre>
1594
       Cor_high2=20*LGT(Cor_high2*1000)
                                              idB mV
1596
       Cor_mean2=20*LGT(Cor_mean2*1000)
                                              !dB mV
1598
1600
       Savedata(Fcount,1)=Frequency
                                          ! MHz
1602
       Savedata (Fcount, 2) = Netpower
                                          !Watts
       Savedata(Fcount,3)=Ref_e_field
1604
                                          !V/m
1606
       Savedata(Fcount, 4) = Cor_high1
                                          !dBm
1608
       Savedata(Fcount,5)=Cor_mean1
                                          !dBm
1610
      Savedata(Fcount,6)=Cor_high2
                                          !dB mV
1612
      Savedata(Fcount,7)=Cor_mean2
                                          !dB mV
1614
1616
      RETURN
1618
       1620
1622
1624 Print alldata:!
      PRINTER 1S Printer
1626
1628
      FRINT
      PRINT RPT#("-",80)
1630
      FRINT "************************
1632
1634
      PRINT USING "2X,6D.DD,6A,2X,#";Frequency; " MHz "
      FR1NT "***********************
1636
      PRINT RPT#("-",80)
1638
      PRINT RPT#(" ",80)
1640
1642
      PRINT "Measured RAW data:"
1644
      FRINT
      PRINT "
1646
                      FWR 1N
                                       MAX REC PWR
                                                      HORN ZERO
                                                                  HORN PEAK";
      PRINT "
                 HORN MEAN"
1648
      FRINT "
                                                                      mV
                                                                           " :
1650
                 1NC--Watts--REF
                                          Watts
                                                          mV
                     mV"
1652
      PRINT "
1654 Spyraw1:1MAGE MD.4DE,X,MD.4DE,XX,MD.4DE,XX,6D.2D,3X,#
1656 Spyraw2:1MAGE 7D.2D, X, 7D.2D
      PRINT USING Spyraw1; Incpwr_raw, Refpwr_raw, Power, Eut_zero*1000
1658
```

```
1.660
       FRINT USING Spyraw2; High1*1000, Mean1*1000
1662
1664
       PRINT
       PRINT "1cm FRB ZERO
                               1cm PRB PEAK
1666
                                               1cm PRB MEAN
                                                                Signal Gen Level"
       FRINT "
                  mΥ
                                    mΥ
1668
                                                    mΥ
                                                                       dBm"
1670 Spyraw3:1MAGE 6D.2D,6X,7D.2D,6X,7D.2D,10X,5D
       PRINT USING Spyraw3; Picm_zero*1000, High2*1000, Mean2*1000, Dbm
1672
1674
       PRINT
       PRINT RPT#("_",80)
1676
       PRINT "PROCESSED DATA: "
1678
       PRINT "HORN normalized to 10 mW/cm^2, 1cm DIFOLE normalized to 37";
1680
       PRINT " dB V/m."
1682
1684
       PRINT
       PRINT "REC PWR CORR.
1686
                              HORN FEAK
                                           HORN MEAN
                                                       " ;
       PRINT "1cm PRB PK
1683
                         1cm PRB MEAN"
1690
       FRINT "
                                                       ";
                Watts
                                              dBm
                                 dBm
       PRINT "
1692
                dB mV
                               dB mV"
1694 Spyraw6: IMAGE MD. 4DE, 5X, M4D. 2D, 3X, #
1696 Spyraw7: IMAGE M6D. 2D, 2X, M4D. 2D, 4X, M4D. 2D
1698
1700
       PRINT USING Spyraw6; Cor_power, Cor_high1
1702
       PRINT USING Spyraw7; Cor_mean1, Cor_high2, Cor_mean2
1704
       FRINT TAB(41); RFT$("_",25)
       PRINT TAB(41); "Field V/m
1706
                                    Field V/m"
1708
       FRINT USING "39X,M4D.2D,4X,M4D.2D";P1cm_fld_high,P1cm_fld_mean
1710
       FRINT
1712
       PRINT RPT#("-",65)
       PRINT "REC PWR CORR.
                               NET INPUT POWER
                                                  REF PWR DENSITY REF FIELD"
1714
       FRINT "
1716
                                                                       V/m"
                  dBm
                                     Watts
                                                       mW/cm^2
1718 Spyraw8: IMAGE X,M4D.2D,10X,MD.4DE,6X,M2D.4D,5X,M4D.4D
1720
       Fower_dbm=10*LGT(1000*Cor_power)
1722
       PRINT USING Spyraw8; Power_dbm, Netpower, Ref_pwr_den, Ref_e_field
       PRINT RPT#("_",80)
1724
       FRINT RPT#("*",80)
1726
       FRINT RFT#("_",80)
1728
1730
       FRINT
1732
       PRINTER IS CRT
1734
       RETURN
1736
1738
       1740
1742 Save data:
1744
       RETURN
1746
       DISP "ENTER FILE NAME FOR THIS DATA (<=10 CHRS/NUMS ONLY) ";
1748
       BEEP
1750
       LINFUT Filename#
1752
       IF LEN(Filename$)>10 THEN Save_data
1754
       Filename#=Filename#&Outdisk#
1756
       ON ERROR CALL Errortrap
1758
       CREATE BDAT Filename$, (7*Totalfreqs+128),8
1760
       ASSIGN @Datapath TO Filename$
1762
       OUTPUT @Datapath; Total curves
1764
       OUTPUT @Datapath: Totalfregs
1766
       OUTFUT @Datapath; Total freqs
       OUTPUT @Datapath; Savedata(*)
1768
1770
       ASSIGN @Datapath TO *
1772
1774
       PRINTER IS Frinter
       PRINT TIME * (TIMEDATE); "......DATA STORED ON FILE ";
1776
1778
       PRINT Filename $ [1, POS (Filename $, ":") - 1]; ".........
```

```
PRINTER IS 1
1780
       OFF ERROR
1782
1784
       RETURN
1786
       FND
1788
1790
        1792
1794
1796
       SUB Measure_menu
1798
1800
                                 !This routine will facilitate setting up the
1802
                                 !measurement.
1804
            COM /Parameters/ Startf, Stopf, Stepf, Slow_down, Coupler_id $[10]
1806
1808
            COM /Parameters/ Generator_id*[10],Dvm_integrat*[3]
            COM /Farameters/ INTEGER Low_dbm, High_dbm, Step_dbm, Dvm_samples COM /Farameters/ Upperlimit, Threshold, Rev_time
1810
1812
            COM /Motor_menu/ Motion_type $[10], INTEGER Jog_wait
1814
            COM /Bugs/ INTEGER Bug1, Bug2, Bug3, Printer
1816
1818
            DIM Eut identity $[160], Operator name $[60]
1820
1822
1824
            PRINTER IS 1
1826
                                !Clear the CRT.
            Wipe clean
1828
            !Define the choices at start-up.
1830
1832
1834
            Operator_name = "Mike Crawford"
1836
1838
            Startf=2000
                                !Frequency range in MHz.
1840
            Stopf=4000
1842
            Stepf=200
1844
1845
           Low dbm=-30
                                     !Signal generator level in dBm.
1848
            High dbm=-10
1850
            Step_dbm=1
1852
1854
            Eut identity = "Evaluate use of NSWC Reverberating Chamber "
1855
            Eut_identity = Eut_identity = & "for measuring response of EUT."
1858
1860
            Threshold=50.0
                                !EUT LOWER THRESHOLD VOLTAGE. mV.
1842
            Upperlimit=1200.0
                                !EUT FAILURE VOLTAGE. mV.
1864
                                !Time for EUT to respond after field is set.
1866
            Slow down=.02
1868
1870
            Jog wait=10
                                !Wait .10 seconds between each of 3200 jogs.
1872
            Coupler_id#="HP_11692D"
1874
1876
            Generator_id#="HP_8672A"
1878
1880
            !Display the above parameters.
1882
1884
            PRINT CHR# (129)
           PRINI TABXY(16,1); " MEASUREMENT PARAMETERS FOR MODE STIRRED TESTS. "
PRINT TABXY(1,3); " TEST DESCRIPTION: "
PRINT TABXY(1,7); " FREQUENCY RANGE "
1885
1838
1890
            PRINT TABXY(30,7); "TO"
1892
            FRINT TABXY(42,7); "STEP"
1894
1896
            PRINT TABXY (56,7); "MHz."
1898
            FRINT TABXY(1,9);" SIG-GEN RANGE "
```

```
PRINT TABXY(22,9); "TO"
1900
                       PRINT TABXY(29,9);" / "
1902
                       PRINT TABXY(37,9); "dBm."
1904
                       PRINT TABXY(44,9); " EUT RESPONSE TIME "
1906
                       PRINT TABXY(70,9); " Sec. "
1908
                       PRINT TABXY(45,11); " FAIL LIMIT mV "
1910
                       PRINT TABXY(1,11);"
                                                                   EUT LOWER THRESHOLD RESPONSE mV "
1912
                       FRINT TABXY(1,13); " EST. TIME/Tuner rev "
1914
1916
                       PRINT TABXY(33,13); " DVM SAMPLES "
                       PRINT TABXY (53,13); " LINE CYCLES/SAMPLE "
1918
                       FRINT TABXY(40,15); " COUPLER/SIG GEN "
1920
                       PRINT TABXY(1,15);" DATE/TIME "
1922
                       FRINT TABXY(1,17);"
1924
                                                                   OPERATOR'S NAME "
1926
                       PRINT CHR#(128)
1928
1930
                        !Fill in the default choices.
1932
                       GOSUB Frint_eutid
1934
1936
                       GOSUB Print_freqs
                       GOSUB Frint_gen_level
1938
1940
                       GOSUB Print_eutfail
                       GOSUB Print_slowdown
1942
1944
                       GOSUB Frint_thresh
1946
                       GOSUB Frint_tuner
1948
                       GOSUB Frint_name
1950
1952
                        !Make any changes or corrections.
1954
1956
                       OFF KEY
1958
                       ON KEY O LABEL "TEST ID",5 GOSUB Change_eutid
                       ON KEY 1 LABEL "Frequency",5 GOSUB Change_freqs
ON KEY 2 LABEL "GEN Levels ",5 GOSUB Change_levels
1960
1962
                       ON KEY 3 LABEL "THRESHOLD", 5 GOSUB Change_thresh
1964
                       ON KEY 4 LABEL "FAIL LIMIT",5 GOSUB Change_eutfail
1966
                       ON KEY 8 LABEL "TUNER REVs",5 GOSUB Change_tuner
1948
                       ON KEY 5 LABEL "CONTINUE",5 GOSUB Exit_sub
1970
                       ON KEY 6 LABEL "YOUR NAME",5 GOSUB Enter_name
1972
                       ON KEY 7 LABEL "RESPONSE tm",5 GOSUB Change_respond
1974
                       ON KEY 8 LABEL "TUNER REVs",5 GOSUB Change_tuner
ON KEY 5 LABEL "CONTINUE",5 GOSUB Exit_sub
1976
1978
                       ON KEY 9 LABEL " DATE ",5 CALL Time_date
1980
1982
                       BEEP
1984
                       PRINT TABXY(14,15); DATE$(TIMEDATE)
1986 Spin:
                       DISP "<<<<<<< $\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}{\circles}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\circles}{\circles}}\frac{\ci
1988
1990
                       PRINT TABXY(28,15); TIME#(TIMEDATE)
1992
                       GOTO Spin
1994 Exit_sub:
1996
                       Upperlimit=Upperlimit/1000!Convert to volts
1998
                        Threshold=Threshold/1000!Convert to volts
2000
                       OFF KEY
                       DISP CHR#(12)
2002
2004
                       FRINTER IS Printer
2005
                        IF Printer=701 THEN DUMP ALPHA
2008
                        CALL Wipe_clean
2010
                        SUBEXIT
2012
                        2014
2016
2018 Change_tuner: !
```

```
Jog_wait=Jog_wait+1
2020
2022 Print_tuner:
2024
          Rev_time=38.37068*Jog_wait+4.92406
2025
2028
          Dvm samples=INT(1.15*(38.9729+23.60383*(Rev_time))) ! .1 cycle
2030
          Dvm_integrat≉=".1"
2032
          IF Dvm_samples>9999 THEN
2034
              Dvm samples=INT(1.15*(3.970658+12.8621757*(Rev_time)))! 1 cycle
2036
2038
              Dvm_integrat*="1"
2040
          END IF
2042
          IF Dvm_samples>9999 THEN
2044
              Jog_wait=0
              GCTO Change_tuner
2046
2048
          END IF
2050
          Hh=Rev time DIV 3600
2052
          Mm=(Rev time-Hh*3600) DIV 60
2054
          Ss=INT(Rev_time-Hh*3600) MOD 60
2056
          PRINT TABXY (23,13);
2058
          FRINT USING "DD,A,ZZ,A,ZZ";Hh,":",Mm,":",Ss
          FRINT TABXY(47,13); Dvm_samples
2060
2062
          PRINT TABXY (74,13);"
          PRINT TABXY(74,13); Dvm_integrat#
2064
2066
          RETURN
2068
          2070
2072
2074 Change_eutid:
          DISP "DESCRIPTION of the EUT and PURPOSE for test?? (<2 lines)";
2076
2078
          OUTFUT 2 USING "K,#"; Eut_identity$
2080
          LINFUT Eut_identity$
2082 Print_eutid:
          FRINT TABXY(1,4); RFT#(" ",160)
2084
          PRINT TABXY(1,4); Eut_identity$
2086
2088
          RETURN
2090
2092
          2094
2096 Change_freqs:
2098
          DISF "ENTER the START, STOP, and STEP frequencies (MHz) ";
          INFUT Startf, Stopf, Stepf
2100
2102
          IF Startf<100 THEN Startf=100
2104
          IF Startf>18000 THEN Startf=18000
2106
          SELECT Startf
2108
          CASE <2000
2110
              IF Stopf>2000 THEN Stopf=2000
              Coupler_id = "HF_778D"
2112
              Generator_id#="HF_8660A"
2114
2116
          CASE >=2000
              IF Stopf>18000 THEN Stopf=18000
2118
2120
              Coupler_id*="HP_11692D"
2122
              Generator id#="HP 8672A"
2124
          END SELECT
2126 Print_freqs: !
          PRINT TABXY(21,7);
2128
          PRINT USING "5D.2D"; Startf
2130
2132
          FRINT TABXY(33,7);
2134
          PRINT USING "5D.2D"; Stoof
2136
          FRINT TABXY(47,7);
          FRINT USING "5D.2D"; Stepf
2138
```

```
PRINT TABXY(58,15); RPT#(" ",10)
2140
         FRINT TABXY(69,15); RFT#(" ",10)
2142
         PRINT TABXY(58,15);Coupler_id$
2144
         PRINT TABXY(69,15):Generator_id$
2146
2148
         RETURN
2150
         2152
2154
2156 Change_levels:
2158
       ! DISF "ENTER Signal generator LEVEL (dBm) ";
        INFUT Dbm
2160
2162
       ! Low_dbm=INT(Dbm)
2164
         DISP "LOW, HIGH, STEP Signal generator LEVEL (dBm) ";
         INFUT Low_dbm, High_dbm, Step_dbm
2166
2168 Frint_gen_level:
2170
         PRINT TABXY(17,9);
         FRINT USING "4D"; Low_dbm
2172
2174
         FRINT TABXY(24,9);
2176
         PRINT USING "4D"; High dbm
2178
         PRINT TABXY(32,9);
         FRINT USING "4D"; Step_dbm
2180
2182
         RETURN
2184
2186
         2188
2190 Change eutfail:
2192
         DISF "ENTER the UPPER LIMIT for the EUT RESPONSE (mV)";
2194
         INFUT Upperlimit
2196 Frint_eutfail:
2198
         FRINT TABXY(60,11); Upperlimit
2200
         RETURN
2202
2204
         2206
2208 Change_thresh:
2210
         DISP "LOWER LIMIT EUT RESPONSE for initially setting field. (mV) ";
2212
         INFUT Threshold
2214 Frint_thresh:
2216
         FRINT TABXY(35,11); Threshold
2218
         RETURN
2220
2222
         2224
2226 Change respond:
2228
         DISP "WAIT TIME FOR EUT TO RESPOND AFTER FIELD IS SET.";
2230
         INFUT Slow_down
2232 Print_slowdown:
2234
         PRINT TABXY(64,9); RPT#(" ",6)
2236
         FRINT TABXY(64,9);Slow_down
2238
         RETURN
2240
2242
         2244
2246 Enter_name:
2248
         DISF "FLEASE TYPE IN YOUR NAME ";
2250
         LINEUT Operator_name#
2252 Print_name:
         PRINT TABXY(20,17);Clear_opname*
2254
         PRINT TABXY(20,17); Operator_name$
2256
2258
         RETURN
2260
2262
         2264
2266
     SUBEND
2268
2270
       ************************
2272
```

NBS-114A (REV. 2-80)			
U.S. DEPT, OF COMM.	1. PUBLICATION OR	2. Performing Organ. Report N	o. 3. Publication Date
BIBLIOGRAPHIC DATA	REPORT NO.		
SHEET (See instructions)	NBS/TN-1092		April 1986
4. TITLE AND SUBTITLE	1 1000	1	11p111 1700
Design, Evaluation, and Use of a Reverberation Chamber for Performing			
Electromagnetic Susceptibility/Vulnerability Measurements			
5. AUTHOR(S)			
M. L. Crawford and G. H. Koepke			
			•
6. PERFORMING ORGANIZA	TION (If joint or other than NBS	, see instructions)	7. Contract/Grant No.
NATIONAL BUREAU OF STANDARDS			
			8. Type of Report & Period Covered
WASHINGTON, D.C. 20234			
9. SPONSORING ORGANIZAT	TION NAME AND COMPLETE A	DDRESS (Street, City, State, ZI	P)
Naval Surface Weapons Center (NSWC), Dahlgren, Virginia			
and			
Rome Air Development Center (RADC), Griffiss Air Force Base, Rome, New York			
10. SUPPLIENTARY NOTES			
10. SUPPLEMENTARY NOTES			
Document describes a computer program; SF-185, FIPS Software Summary, is attached.			
11. ABSTRACT (A 200-word or less factual summary of most significant information. If document includes a significant bibliography or literature survey, mention it here)			
This report pre	sents the results of v	work at the National E	Sureau of Standards.
Boulder, Colorado, to carefully evaluate, document, develop (when necessary),			
and describe the methodology for performing radiated susceptibility/vulnerability			
measurements using a reverberation chamber. The report describes the reverberation			
chamber theory of operation construction englished for the level of			
chamber theory of operation, construction, evaluation, functional operation, and			
use for performing immunity measurements. It includes an estimate of measurement			
uncertainties derived empirically from test results and from comparisons with			
anechoic chamber measurements. Finally, it discusses the limitations and			
advantages of t	he measurement technic	que to assist potentia	al users in determining
the applicability for this technique to their electromagnetic compatibility			
(EMC) measurement needs.			
(EMC) measurement needs.			
12. KEY WORDS (Six to twelve entries; alphabetical order; capitalize only proper names; and separate key words by semicolons)			
i i			
electromagnetic susceptibility/vulnerability; estimated uncertainty;			
evaluation; measurement procedures; reverberabtion chamber			
	•		
13. AVAILABILITY			14. NO. OF
			PRINTED PAGES
Car Official Distribution De Not Release to NTIS			1/6
Natural Natural			146
X Order From Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.			15. Price
Order From National Technical Information Service (NTIS), Springfield, VA. 22161			







Periodical

Journal of Research—The Journal of Research of the National Bureau of Standards reports NBS research and development in those disciplines of the physical and engineering sciences in which the Bureau is active. These include physics, chemistry, engineering, mathematics, and computer sciences. Papers cover a broad range of subjects, with major emphasis on measurement methodology and the basic technology underlying standardization. Also included from time to time are survey articles on topics closely related to the Bureau's technical and scientific programs. Issued six times a year.

Nonperiodicals

Monographs—Major contributions to the technical literature on various subjects related to the Bureau's scientific and technical activities.

Handbooks—Recommended codes of engineering and industrial practice (including safety codes) developed in cooperation with interested industries, professional organizations, and regulatory bodies.

Special Publications—Include proceedings of conferences sponsored by NBS, NBS annual reports, and other special publications appropriate to this grouping such as wall charts, pocket cards, and bibliographies.

Applied Mathematics Series—Mathematical tables, manuals, and studies of special interest to physicists, engineers, chemists, biologists, mathematicians, computer programmers, and others engaged in scientific and technical work.

National Standard Reference Data Series—Provides quantitative data on the physical and chemical properties of materials, compiled from the world's literature and critically evaluated. Developed under a worldwide program coordinated by NBS under the authority of the National Standard Data Act (Public Law 90-396). NOTE: The Journal of Physical and Chemical Reference Data (JPCRD) is published quarterly for NBS by the American Chemical Society (ACS) and the American Institute of Physics (AIP). Subscriptions, reprints, and supplements are available from ACS, 1155 Sixteenth St., NW, Washington, DC 20056.

Building Science Series—Disseminates technical information developed at the Bureau on building materials, components, systems, and whole structures. The series presents research results, test methods, and performance criteria related to the structural and environmental functions and the durability and safety characteristics of building elements and systems.

Technical Notes—Studies or reports which are complete in themselves but restrictive in their treatment of a subject. Analogous to monographs but not so comprehensive in scope or definitive in treatment of the subject area. Often serve as a vehicle for final reports of work performed at NBS under the sponsorship of other government agencies.

Voluntary Product Standards—Developed under procedures published by the Department of Commerce in Part 10, Title 15, of the Code of Federal Regulations. The standards establish nationally recognized requirements for products, and provide all concerned interests with a basis for common understanding of the characteristics of the products. NBS administers this program as a supplement to the activities of the private sector standardizing organizations.

Consumer Information Series—Practical information, based on NBS research and experience, covering areas of interest to the consumer. Easily understandable language and illustrations provide useful background knowledge for shopping in today's technological marketplace.

Order the above NBS publications from: Superintendent of Documents, Government Printing Office, Washington, DC 20402.

Order the following NBS publications—FIPS and NBSIR's—from the National Technical Information Service, Springfield, VA 22161.

Federal Information Processing Standards Publications (FIPS PUB)—Publications in this series collectively constitute the Federal Information Processing Standards Register. The Register serves as the official source of information in the Federal Government regarding standards issued by NBS pursuant to the Federal Property and Administrative Services Act of 1949 as amended, Public Law 89-306 (79 Stat. 1127), and as implemented by Executive Order 11717 (38 FR 12315, dated May 11, 1973) and Part 6 of Title 15 CFR (Code of Federal Regulations).

NBS Interagency Reports (NBSIR)—A special series of interim or final reports on work performed by NBS for outside sponsors (both government and non-government). In general, initial distribution is handled by the sponsor; public distribution is by the National Technical Information Service, Springfield, VA 22161, in paper copy or microfiche form.

U.S. Department of Commerce National Bureau of Standards Gaithersburg, MD 20899

Official Business Penalty for Private Use \$300





POSTAGE AND FEES PAID U.S. DEPARTMENT OF COMMERCE COM-215

SPECIAL FOURTH-CLASS RATE BOOK